MICHIGAN

PARTS MANUAL
No. 1469

RUTHZIL TRATOR COMERCIAL DE PEÇAS LTDA 11 97083-6812 ROLANDO CITRANGULO

MODEL 210
TRACTOR WAGON
(REAR DUMP)

Information contained herein pertains to Tractor Wagon (Rear Dump Section) only on Machine Serial Numbers 70U3 thru 70U12.

Tractor Wagon (Tractor Section) See Parts Manual No. 1392.

Tractor Scraper (Body Section) See Parts Manual No. 1475.

Record Your Machine Serial Number Here

_____


CLARK EQUIPMENT

CLARK EQUIPMENT COMPANY
Construction Machinery Division
BENTON HARBOR, MICHIGAN, U.S.A.
In Canada: Canadian Clark, Ltd., St. Thomas, Ontario

MICHIGAN

SC6158996

Printed in U.S.A.



MODEL 210 TRACTOR WAGON (Rear Dump)

TS-2249-P

WHEN ORDERING REPAIR PARTS

To assure the best results and to maintain the original quality built into the machine it is important that genuine "Clark" Parts be used when new parts are required.

IMPORTANT: Always furnish the distributor with the machine serial number when ordering parts.

Order through your nearest Clark Distributor, for THE MICHIGAN LINE.

Always give serial number of machine.

Furnish: Quantity, Part Number and Description.

WHEN PARTS ARE RECEIVED

Check immediately for quantity, correctness and condition.

Advise your Michigan Distributor of any error.

Claims for damages, during shipment, should be made to the carrier, immediately.

INDEX MODEL 210 TRACTOR WAGON (Rear Dump)

This index covers the Tractor Wagon (Rear Dump) Section only. Refer to Parts Manual No. 1392 for Tractor Section parts of Model 210 Tractor Wagon that are not covered in this index.

A

	Page
Air Chamber — Rear Brake	4
Air Compressor Governor	7
Air Lines — Rear Dump	5
Air Lines — Tractor (Rear Dump)	7
Axle — Rear Dump Stub	3

B

Bowl Assembly and Dump Limit Cables	1
Brake Air Chamber — Rear	4
Brake Air Lines — Rear Dump	5
Brake Air Lines — Tractor (Rear Dump)	7
Brake Assembly — Rear	4
Brake Hand Valve	7
Brake Slack Adjuster	4

C

Cable, Dump Limit	1
Chamber, Air Brake — Rear	4
Control Valve, Rear Dump	9
Cylinder, Dump	11

D

Decals	13
Drive Shaft Rock Guards	13
Dump Cylinder	11
Dump Hydraulic System	10
Dump Limit Cable, Bowl	1

G

Governor, Air Compressor	7

H

Hydraulic Cylinder, Dump	11
Hydraulic System, Dump	10

R

Rock Guards	13

T

Tools	13
Transmission and Drive Shaft Rock Guards	13

V

Valve, Rear Dump Control	9


W

Wheel and Tire Data	12

Y

Yoke, Rear Dump	2


NOTES



BOWL ASSEMBLY AND DUMP LIMIT CABLE

Item No.	Part No.	Description	No. Req'd.
1	1F-1040	COTTER, Cable Pin	4
2	944671	PIN, Cable Attaching	4
3	582066	CABLE, Dump Limit (Inc. 1, 2)	2
4	593917	BOWL ASSY, Rear Dump	1
5	2C-10112	BOLT, Pin Retaining	2
6	594019	PIN, Cylinder to Bowl	2
7	4E-10	LKWSHR, Pin Retaining	2
8	2D-10	NUT, Pin Retaining	2
9	593737	PLATE, Bowl Cover	1
10	4E-06	LKWSHR, Cover Plate	4
11	2C-616	BOLT, Cover Plate	4


WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE



YOKE ASSEMBLY

Item No.	Part No.	Description	Mfr. Req'd.
1	594390	YOKE ASSY (Inc. 6 thru 9, 11, 20, 23)	1
2	580887	PLATE, Cover	1
3	619027	WASHER, Cover Plate	8
4	4E-08	LKWSHR, Cover Plate	8
5	2C-816	BOLT, Cover Plate	8
6	24C-20144	BOLT, Trunnion Bearing	4
7	583002	WASHER, Trunnion Bearing	1
8	580799	CAP, Trunnion Bearing	2
9	583002	WASHER, Trunnion Bearing	1
10	680-20	NUT, Trunnion Bearing	4
11	10H-25	FITTING, Trunnion Bearing Grease	1
12	10H-25	FITTING, Trunnion Bearing Grease	1
13	580797	BEARING ASSY, Trunnion (Inc. 6, 7, 8)	2
14	2C-10112	BOLT, Pin Retaining	2
15	4E-10	LKWSHR, Pin Retaining	2
16	2D-10	NUT, Pin Retaining	2
17	590708	PIN, Cylinder to Yoke	2
18	2D-06	NUT, Block Retaining	2
19	4E-06	LKWSHR, Block Retaining	2
20	593908	BLOCK, Body Stop	2
21	14C-6136	BOLT, Block Retaining	2
22	592785	BUSHING, Lower Yoke	1
23	10H-25	FITTING, Yoke Grease	1
24	10H-25	FITTING, Yoke Grease	1
25	591623	BUSHING, Upper Yoke	1

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE




STUB AXLE

Item No.	Part No.	Description	No. Req'd.
1	109137	STUD, Wheel	32
2	107985	NUT, Wheel	32
3	107729	NUT, Spindle — Outer	2
4	107730	LOCK, Spindle Nut	2
5	1C-718	BOLT, Hub Cap	12
6	4E-07	LKWSHR, Hub Cap	12
7	742262	CUP, Outer Hub Bearing	2
8	111461	BOLT, Drum to Hub	24
9	111656	WASHER, Drum to Hub	24
10	742262	CUP, Inner Hub Bearing	2
11	108705	SEAL, Hub Oil	2
12	———	BRAKE ASSY — See Index	—
13	108472	BOLT, Spindle & Brake Attaching	24
14	111658	WASHER, Spindle & Brake Attaching	24
15	107732	NUT, Spindle & Brake Attaching	24
16	4E-06	LKWSHR, Dust Cover	12
17	1C-630	BOLT, Dust Cover	12
18	———	§Part of Bowl	—
19	108477	COVER, Dust	4
20	655673	SPACER, Dust Cover	6
21	108464	DRUM, Brake	2
22	107983	CATCHER, Oil	2
23	742263	CONE, Inner Hub Bearing	2
24	108498	SPINDLE	2
25	731989	CONE, Outer Hub Bearing	2
26	107728	NUT, Spindle — Inner	2
27	108707	GASKET, Hub Cap	2
28	108706	CAP, Hub	2
29	109135	HUB ASSY (Inc. 7, 10)	2

§Not Sold Separately

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE




BRAKE ASSEMBLY — REAR

Item No.	Part No.	Description	No. Req'd.
A	108456	BRAKE ASSY (Inc. 1 thru 6, 8, 11, 12, 13, 28 thru 34)	2
		NOTE: 2 Brake Assemblies required per axle. Quantities listed below are for 1 Brake Assembly.	
1	109598	PIN, Brake Cam Roller	2
2	1F-308	COTTER, Roller Pin Lock Pin	2
3	110855	PIN, Cam Roller Pin Lock	2
4	107707	ROLLER, Brake Cam	2
5	107713	SPIDER, Brake	1
6	110814	SPRING, Brake Shoe Return	1
7	107735	WASHER, Cam Shaft Thrust	1
8	110126	PIN, Spring Anchor	2
9	12H-15	FITTING, Brake Spider Grease	1
10	107940	CAM SHAFT — R.H.	1
10A	107941	CAM SHAFT — L.H.	1
11	----	§SHOE, Brake — See 34	2
12	111056	LINING, Brake Shoe	4
13	111305	BOLT, Lining to Shoe	32
14	107739	BUSHING, Brake Spider	1
15	107736	WASHER, Cam Shaft Retaining	2
16	11E-135	RETAINER, Cam Shaft Grease	2
17	12H-15	FITTING, Air Chamber Bracket Grease	1
18	108476	*ADJUSTER, Brake Slack — B.W. #226655	1
19	110206	*AIR CHAMBER — B.W. #229403	1
20	224032	RING, Slack Adjuster Retaining	1
21	107010	WASHER, Slack Adjuster Retaining	1
22	1C-1236	BOLT, Air Chamber Bracket	2
22A	4E-12	LKWSHR, Air Chamber Bracket	2
23	108467	BRACKET, Air Chamber — R.H.	1
23A	108468	BRACKET, Air Chamber — L.H.	1
24	107739	BUSHING, Air Chamber Bracket	1
25	660516	RING, Cam Shaft Retaining	2
26	11E-135	RETAINER, Cam Shaft Grease	1
27	25K-60124	"O" RING, Cam Shaft	1
28	24E-06	LKWSHR, Lining to Shoe	32
29	21D-06	NUT, Lining to Shoe	32
30	16F-04	PLUG, Anchor Pin	1
31	109599	PIN, Brake Shoe Anchor	2
32	109597	SET SCREW, Anchor Pin	2
33	107709	BUSHING, Brake Shoe	2
34	111053	SHOE ASSY, Brake (Inc. 1, 2, 3, 4, 8, 11, 12, 13, 28, 29, 33)	2

§Not Sold Separately
*NOTE: Your local authorized Bendix Westinghouse Distributor or Dealer is equipped to service and supply these parts.

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE




BRAKE AIR LINES — REAR DUMP

Item No.	Part No.	Description	No. Req'd.
1	26F-2	ELBOW, Air Chamber	1
2	36F-2	ADAPTER UNION	1
3	———	AIR CHAMBER — See Index	—
4	593829	HOSE, Relay Valve to Air Chamber	1
5	593959	PIPE, R.H. (On Yoke)	1
6	593958	PIPE, L.H. (On Yoke)	1
7	13F-04	PLUG, Relay Valve	1
8	593966	PIPE, R.H. (On Yoke)	1
9	36F-3	ADAPTER UNION	1
10	36F-3	ADAPTER UNION	1
11	592741	HOSE, Pipe to Pipe	1
12	36F-4	ADAPTER UNION	1
13	594439	HOSE, Pipe to Relay Valve	1
14	592742	HOSE, Pipe to Pipe	1
15	25F-2	ELBOW, Air Filter to Relay Valve	1
16	71T186	ADAPTER UNION	1
17	T08573	FILTER, Air	1
18	507815	*VALVE, Safety — B.W. #205105	1
19	594438	HOSE, Pipe to Air Reservoir	1
20	33F-4	ADAPTER UNION	1
21	36F-4	ADAPTER UNION	1
22	593963	PIPE, L.H. (On Yoke)	1
23	———	AIR CHAMBER — See Index	—
24	36F-2	ADAPTER UNION	1
25	26F-2	ELBOW, Air Chamber	1
26	593829	HOSE, Relay Valve to Air Chamber	1
27	515125	*VALVE, Relay — B.W. #~~294497~~	1
28	25K-40024	"O" RING, Relay Valve	1
29	13F-08	PLUG, Relay Valve	1
30	4E-06	LKWSHR, Relay Valve Attaching	3
31	2C-616	BOLT, Relay Valve Attaching	3
32	592741	HOSE, Pipe to Pipe	1
33	592742	HOSE, Pipe to Pipe	1
34	36F-3	ADAPTER UNION	1
35	36F-4	ADAPTER UNION	1

*NOTE: Your local authorized Bendix Westinghouse Distributor or Dealer is equipped to service and supply these parts.

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE




BRAKE AIR LINES — TRACTOR (FOR TRACTOR WAGON — REAR DUMP — MACHINES) TS-2266-P

BRAKE AIR LINES — TRACTOR

Item No.	Part No.	Description	No. Req'd.
1	———	AIR CHAMBER — See Parts Manual No. 1392	†
2	593474	HOSE, Q.R.V. to Air Chamber	1
3	594143	PIPE ASSY, Firewall	1
4	36F-4	ADAPTER UNION	1
5	594132	HOSE, Firewall Pipe to Steering Assy Pipe	1
6	36F-3	ADAPTER UNION	1
7	594133	HOSE, Firewall Pipe to Steering Assy Pipe	1
8	2C-508	BOLT, Air Horn Attaching	1
8A	2D-05	NUT, Air Horn Attaching	1
8B	4E-05	LKWSHR, Air Horn Attaching	1
9	593388	*HORN, Air — B.W. #223585	1
10	36F-1	ADAPTER UNION	1
11	2D-05	NUT, Q.R.V. to Bracket	2
11A	4E-05	LKWSHR, Q.R.V. to Bracket	2
12	36F-2	ADAPTER UNION	1
13	593478	BRACKET, Quick Release Valve	1
14	31F-3	ADAPTER UNION	1
15	2C-512	BOLT, Q.R.V. to Bracket	2
16	507816	*VALVE, Quick Release — B.W. #205000	1
17	36F-2	ADAPTER UNION	1
18	594091	HOSE, Foot Valve to Q.R.V.	1
19	33F-3	ADAPTER UNION	1
20	593449	HOSE, Q.R.V. to Air Chamber	1
21	30H-45	CLIP, Hose	2
21A	1D-04	†NUT, Clip	2
21B	4E-04	†LKWSHR, Clip	2
22	593371	HOSE, Double Check Valve to Hand Valve	1
23	592291	*VALVE, Brake Hand — B.W. #224491	1
24	593371	HOSE, Foot Valve Cross to Hand Valve	1
25	356614	BUSHING, Foot Valve Reducing	1
26	711186	ADAPTER UNION	1
27	652402	GROMMET, Hose	1
28	592784	HOSE, Double Check Valve to Pipe	1
29	31F-2	ADAPTER UNION	1
30	2C-412	BOLT, Horn Valve Attaching	2
31	530663	*VALVE, Horn — B.W. #228672	1
32	4E-04	LKWSHR, Horn Valve Attaching	2
33	17F-2	TEE, Horn Valve	1
34	2D-04	NUT, Horn Valve Attaching	2
35	593438	HOSE, Cross to Horn Valve	1
36	———	AIR CHAMBER — See Parts Manual No. 1392	1
37	356611	BUSHING, Tee Reducing	1
38	940643	SENDER UNIT, Air Pressure	1
39	594408	*VALVE, Double Check — B.W. #227239	1
40	13F-04	PLUG, Double Check Valve	1
41	36F-2	ADAPTER UNION	1
42	356615	BUSHING, Cross Reducing	1
43	21F-4	CROSS, Foot Valve	1
44	301841	ADAPTER UNION	1
45	31F-4	ADAPTER UNION	1
46	592783	HOSE, Pipe to Cross	1
47	5K-409	NIPPLE, Cross to Foot Valve	1
48	13F-08	PLUG, Foot Valve	2
49	———	BRAKE CONTROLS — See Parts Manual No. 1392	—
50	593435	HOSE, Horn Valve to Horn	1
51	26F-4	ELBOW, Check Valve to Pipe	1
52	593370	*VALVE, Check — B.W. #228194	1
53	593280	HOSE, Compressor to Pipe	1
54	356616	BUSHING, Tee Reducing	1
55	36F-4	ADAPTER UNION	1
56	18F-4	TEE, Discharge Fitting	1
57	1C-516	BOLT, Discharge Fitting	2
58	5K-409	NIPPLE, Tee to Discharge Fitting	1
59	4E-05	LKWSHR, Discharge Fitting	2
60	510452	*FITTING, Discharge — B.W. #213042	1
61	951948	*GASKET, Discharge Fitting — B.W. #204920	1
62	942646	*GASKET, Governor — B.W. #223577	1
63	942645 540306	*GOVERNOR, Air Compressor — B.W. #226363	1
64	31F-1	ADAPTER UNION	1
65	593650	HOSE, Governor to Tee	1
66	4E-05	LKWSHR, Governor to Compressor	2
67	1C-548	BOLT, Governor to Compressor	2

*NOTE: Your local authorized Bendix Westinghouse Distributor or Dealer is equipped to service and supply these parts.
†Not Illustrated

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE



TS-1692-P
CONTROL VALVE — REAR DUMP

CONTROL VALVE — REAR DUMP

Item No.	Part No.	Description	No. Req'd.
A	580950	VALVE ASSY (Inc. 1 thru 97)	1
1	944156	RETAINER, Plunger Spring	1
2	940166	SPRING, Check Plunger	1
3	943197	COVER	1
4	4E-08	LKWSHR, Cover Bolt	2
5	944147	GASKET, Detent Cover	1
6	25K-40208	"O" RING, Cover	1
7	2C-820	BOLT, Cover	2
8	943184	VALVE, Plunger Check	1
9	———	§HOUSING — See "A"	—
10	4E-08	LKWSHR, Cover Bolt	2
11	2C-820	BOLT, Cover	2
12	943197	COVER	1
13	———	§SPOOLS — See "A"	—
14	25K-40208	"O" RING, Cover	1
15	25K-60204	"O" RING, Valve to Reservoir	1
16	944144	VALVE, Plunger Check	1
17	743593	SPACER, Check Valve Spring	1
18	944145	SPRING, Check Valve	1
19	4E-05	LKWSHR, Retainer Plate	6
20	16F-02	PLUG	1
21	1C-512	BOLT, Retainer Plate	6
22	943187	WIPER, Plunger	1
23	943179	"O" RING, Plunger Eye	1
24	89F-3	CONNECTOR, Oil Line Tube	1
25	944146	TUBE, Oil Line	1
26	943180	EYE, Plunger	1
27	943181	QUAD RING, Plunger	1
28	943186	PLATE, Wiper Retaining	1
29	16F-08	PLUG, Clean Out	2
30	943181	QUAD RING, Plunger	1
31	943179	"O" RING, Plunger Eye	1
32	943180	EYE, Plunger	1
33	943187	WIPER, Plunger	1
34	2C-820	BOLT, Cover	4
35	4E-08	LKWSHR, Cover	4
36	943191	COVER	2
37	25K-40128	"O" RING, Cover	2
38	943186	PLATE, Wiper Retaining	1
39	943187	WIPER, Plunger	1
40	943180	EYE, Plunger	1
41	943179	"O" RING, Plunger Eye	1
42	943181	QUAD RING, Plunger	1
43	943186	PLATE, Wiper Retaining	1
44	863045	NUT, Relief Valve Acorn	1
45	8D-06	NUT, Adjusting Screw Jam	1
46	943196	CAP, Relief Valve Adjusting	1
47	940278	SCREW, Relief Valve Adjusting	1
48	943195	GUIDE, Relief Valve Spring	1
49	519251	SPRING, Relief Valve	1
50	25K-40124	"O" RING, Relief Valve Adjusting Cap	1
51	2C-820	BOLT, Cover	2
52	4E-08	LKWSHR, Cover	2
53	943488	PLATE, Cylinder Port Cover	1
54	25K-40128	"O" RING, Cover Plate	1
55	16F-04	PLUG, Cover Plate	1
56	943193	PLUNGER, Relief Valve	1
57	943192	SEAT, Relief Valve Plunger	1
58	25K-40116	"O" RING, Relief Valve Plunger Seat	1
59	943184	VALVE, Plunger Check	1
60	940166	SPRING, Check Valve	1
61	943181	QUAD RING, Plunger	1
62	943188	GASKET, Spring Cover	1
63	25K-40124	"O" RING, Housing Cover	1
64	943190	CAP, Relief Valve Housing	1
65	943182	RETAINER, Plunger Spring	1
66	943179	"O" RING, Plunger Cap	1
67	943183	SPRING, Plunger Return	1
68	943189	COVER, Plunger Spring	1
69	943182	RETAINER, Plunger Spring	1
70	4E-05	LKWSHR, Spring Cover	4
71	1C-512	BOLT, Spring Cover	4
72	943185	CAP, Plunger	1
73	943184	VALVE, Plunger Check	1
74	943183	SPRING, Plunger Return	1
75	4E-05	LKWSHR, Detent Housing	8
76	11G-512	BOLT, Detent Housing	8
77	944152	WASHER, Spring Stop	1
78	944150	RING, Detent Snap	1
79	944149	SPACER, Detent Spring	1
80	755762	RING, Detent Spring Retaining	1
81	944151	POPPET, Detent	1
82	675436	PIN, Plunger Cap Roll	1
83	944148	PIN, Plunger Cap	1
84	944157	HOUSING, Detent	1
85	660178	PIN, Plunger Cap Roll	1
86	940166	SPRING, Check Plunger	1
87	944153	CAP, Plunger End	1
88	943179	"O" RING, End Cap	1
89	944154	RETAINER, Plunger Spring	1
90	943181	QUAD RING, Plunger	1
91	944147	GASKET, Detent Cover	1
92	83F-3	ELBOW, Oil Line Tube	1
93	943185	CAP, Plunger End	1
94	944156	RETAINER, Plunger Spring	1
95	944155	COVER, Plunger Spring	1
96	943183	SPRING, Plunger Return	1
97	943179	"O" RING, End Cap	1
98	2C-880	†BOLT, Valve to Reservoir	3
99	4E-08	†LKWSHR, Valve to Reservoir	3

†Not Illustrated
§Not Sold Separately. Order complete Valve Assembly.


WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE



HYDRAULIC SYSTEM — DUMP

Item No.	Part No.	Description	No. Req'd.
1	———	DUMP CYLINDER — See Index	—
2	4E-04	LKWSHR, U-Bolt	4
3	2D-04	NUT, U-Bolt	4
4	25K-40110	"O" RING, Hose to Pipe	1
5	663093	FLANGE HALF, Hose to Pipe	2
6	25K-40116	"O" RING, Hose to Cylinder	1
7	663094	FLANGE HALF, Hose to Cylinder	2
8	4E-07	LKWSHR, Flange Half to Cylinder	4
9	1C-722	BOLT, Flange Half to Cylinder	4
10	580846	HOSE, Pipe to Cylinder	1
11	36F-6	ADAPTER UNION	2
12	593954	PIPE, Left Hand	1
13	516599	HOSE, Strg. Assy Pipe to Rear Pipe	1
14	36F-6	ADAPTER UNION	2
15	10F-16	PLUG, Scraper Pipes	2
16	516599	HOSE, Scraper Pipe to Rear Pipe	1
17	1C-722	BOLT, Flange Half to Cylinder	4
18	4E-07	LKWSHR, Flange Half to Cylinder	4
19	580846	HOSE, Pipe to Cylinder	1
20	25K-40116	"O" RING, Hose to Cylinder	1
21	663094	FLANGE HALF, Hose to Cylinder	2
22	25K-40110	"O" RING, Hose to Cylinder Pipe	1
23	663093	FLANGE HALF, Hose to Cylinder Pipe	2
24	4E-06	LKWSHR, Flange Half to Cylinder Pipe	4
25	1C-620	BOLT, Flange Half to Cylinder Pipe	4
26	4E-06	LKWSHR, Cylinder Pipe to Cylinder	4
27	1C-620	BOLT, Cylinder Pipe to Cylinder	4
28	581050	PIPE, R.H. Cylinder	1
29	25K-40110	"O" RING, Pipe to Cylinder	1
30	———	DUMP CYLINDER — See Index	—
31	594020	HOSE, Pipe to Cylinder Pipe	1
32	36F-6	ADAPTER UNION	2
33	593950	PIPE, Right Hand	1
34	594020	HOSE, Pipe to Cylinder Pipe	1
35	1C-620	BOLT, Flange Half to Cylinder Pipe	4
36	4E-06	LKWSHR, Flange Half to Cylinder Pipe	4
37	594355	U-BOLT, Cylinder Pipe to Cylinder	1
38	581049	PIPE, L.H. Cylinder	1
39	1C-620	BOLT, Cylinder Pipe to Cylinder	4
40	4E-06	LKWSHR, Cylinder Pipe to Cylinder	4
41	25K-40110	"O" RING, Cylinder Pipe to Cylinder	1

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE




CYLINDER DUMP

Item No.	Part No.	Description	No. Req'd.
A		*CYLINDER ASSY (Inc. 1 thru 24)	
B	580794	Right Hand	1
C	580789	Left Hand	1
		*NOTE: 2 Cylinders used on machine — Quantities listed below are for 1 Cylinder.	
1	512726	BUSHING, Piston Rod	1
2	941589	WIPER, Piston Rod	1
3	512747	RETAINER, Piston Rod Wiper	1
4	532272	PACKING SET, Cylinder Cap	1
5	25K-40800	"O" RING, Cylinder Cap	1
6	514740	ADAPTER, Male Chevron Packing	2
7	536382	ROD ASSY, Piston (Inc. 1)	1
8		CYLINDER TUBE (Inc. 15)	
8A	580795	Right Hand	1
8B	580790	Left Hand	1
9	528180	PISTON ...2 - 541582 SUPERSEDES 528180	1
10	514755	‡SHIM, Piston Packing	—
11	514753	ADAPTER, Female Chevron Packing	2
12	509956 [illegible]	PACKING SET, Piston	1
13	514752	ADAPTER, Male Chevron Packing	2
14	536038	NUT, Piston Rod	1
15	512726	BUSHING, Cylinder Tube	1
16	12H-15	FITTING, Cylinder Grease	1
17	524057	RING, Piston Wear	2
18	25K-40216	"O" RING, Piston Rod	1
19	68D-16 180-16	NUT, Cylinder Cap	4
20	24C-16128	BOLT, Cylinder Cap	4
21	581957	**CAP, Cylinder	1
22	528103	GLAND, Packing	1
23	4C-820	BOLT, Packing Gland	4
24	10H-25	FITTING, Piston Rod Grease	1

**NOTE: 581957 Cap can be used only with 528180 Piston (illustrated as item 9). Machines with old style cap must install 528180 Piston when installing 581957 Cap.

‡As Required

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE



WHEEL AND TIRE DATA

Item No	24.5 x 29	27.5 x 25	DESCRIPTION	No. Req'd.
1	———	———	TIRE	2
2	523253	580274	RING, Lock	2
3	529107	509445	VALVE STEM	2
4	551684	———	ADAPTER, Valve Stem	2
5	551685	———	CAP, Valve	2
6	582124	581649	*WHEEL	2
7	523252	~~580278~~ 522363	BAND, Bead Seat	2
8	513117	580278	"O" RING	2
9	580479	522329	FLANGE	4

*NOTE: 529370 PLUG must be used with each 581649 Wheel.

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE

DECALS


Item No.	Part No.	Description	No. Req'd
1	[illegible]	[illegible]	1
2	551741	DECAL, Clark Equipment	2
3	593211	DECAL, Model	2
4	502776	DECAL, Michigan	2
5	528694	DECAL, Patent	1

542074 - Plate, Patent plus (4) 6C-605 Screw replaces 528694 Patent Decal. Scrap stock of 528694 Decal.

Item No.	Part No.	Description	No. Req'd
6	553412	WRENCH, Wheel	1
7	552164	HANDLE, Wheel Wrench	1
8	522996	WRENCH, Hub Bearing — 8 1/16"	1
9	522997	WRENCH, Hub Bearing — 5 15/16"	1
10	523029	SLEEVE, Piston Rod Wiper Taper	1
11	515201	RING, Packing Compressor	1

TRANSMISSION AND DRIVE SHAFT ROCK GUARD

Item No.	Part No.	Description	No. Req'd
1	580869	ROCK GUARD, Transmission	1
2	2C-820	BOLT, Guard Attaching	2
3	2D-08	NUT, Guard Attaching	2
4	4E-08	LKWSHR, Guard Attaching	2
5	580872	ROCK GUARD, Drive Shaft — L.H.	1
6	580873	ROCK GUARD, Drive Shaft — R.H.	1
7	2C-816	BOLT, L.H. Guard to R.H. Guard	2
8	2D-08	NUT, L.H. Guard to R.H. Guard	2
9	4E-08	LKWSHR, L.H. Guard to R.H. Guard	2
10	2C-624	BOLT, Guards to Frame	4
11	2D-06	NUT, Guards to Frame	4
12	4E-06	LKWSHR, Guards to Frame	4



TS-2628-F

*NOTE: 945960 Lamp Kit consists of 1 - 547416 Lamp Assy, 3 #12E-10 Lkwshr, 3 #120-10 Nut and 1 - 002128 Template Form. The serviceable items of 547416 Lamp Assy are 551245 Sealed Beam Unit and 944976 Frame and Retainer Assy.

Item No.	Part No.	Description	No. Req'd.
1	580976	CLAMP, Wire Assy — Double	2
1A	2C-410	†BOLT, Clamp Attaching	1
1B	2D-04	†NUT, Clamp Attaching	1
1C	4E-04	†LKWSHR, Clamp Attaching	1
2	580984	WIRE ASSY	1
3	580976	CLAMP, Wire Assy — Double	2
3A	2C-410	†BOLT, Clamp Attaching	1
3B	2D-04	†NUT, Clamp Attaching	1
3C	4E-04	†LKWSHR, Clamp Attaching	1
4	----	YOKE — See Index	—
5	1D-04	NUT, Clamp Attaching	2
6	12D-8	NUT, Lamp Attaching	6
7	13E-8	LKWSHR, Lamp Attaching	6
8	550745	WIRE, Ground	1
9	551282	LAMP ASSY (Inc. 9A) 945960	1
9A	551245	†SEALED UNIT, Lamp	1
10	4E-04	LKWSHR, Clamp Attaching	2
11	30H-7	CLAMP, Wire	2
12	550745	WIRE, Ground	1
13	551282	LAMP ASSY (Inc. 13A) 945960	1
13A	551245	†SEALED UNIT, Lamp	1
14	2C-410	BOLT, Clamp Attaching	1
15	2D-04	NUT, Clamp Attaching	1
16	4E-04	LKWSHR, Clamp Attaching	1
17	580991	WIRE ASSY	1
18	30H-45	CLAMP, Wire	1
19	2C-408	BOLT, Clamp Attaching	1
20	580994	WIRE	1
21	2D-04	NUT, Clamp Attaching	1
22	4E-04	LKWSHR, Clamp Attaching	1
23	580976	CLAMP, Wire Assy — Double	2
24	580920	WIRE	1
25	580999	WIRE	1
26	580975	CLAMP, Wire Assy — Double	2
27	2C-408	BOLT, Clamp Attaching	1
28	581000	WIRE	1
29	30H-7	CLAMP, Wire	1
30	4E-04	LKWSHR, Clamp Attaching	1
31	2D-04	NUT, Clamp Attaching	1
32	30H-45	CLAMP, Wire Assy	1
33	2D-04	NUT, Clamp Attaching	2
34	4E-04	LKWSHR, Clamp Attaching	2
35	581001	WIRE ASSY	1
36	580975	CLAMP, Wire Assy	4
37	2C-410	BOLT, Clamp Attaching	2

†Not Illustrated

WHEN ORDERING PARTS, ALWAYS STATE MODEL AND SERIAL NO. OF MACHINE

NUMERICAL INDEX

Part No.	Page No.
1C-512	9
1C-516	7
1C-548	7
1C-620	10
1C-630	3
1C-718	3
1C-722	10
1C-1236	4
1D-04	7, 14
1F-308	4
1F-1040	1
2C-408	14
2C-410	14
2C-412	7
2C-508	7
2C-512	7
2C-616	1, 5
2C-624	13
2C-816	2, 13
2C-820	9, 13
2C-860	9
2C-10812	1, 2
2D-04	7, 10, 14
2D-05	7
2D-06	2, 13
2D-08	13
2D-10	1, 2
4C-820	11
4E-04	7, 10, 14
4E-05	7, 9
4E-06	1, 2, 3, 5, 10, 13
4E-07	3, 10
4E-08	2, 9, 13
4E-10	1, 2
4E-12	4
5K-409	7
8D-05	9
10M-25	2, 11
11E-135	4
11G-512	9
12D-8	14
12M-15	4, 11
13E-8	14
13F-04	5, 7
13F-08	5, 7
13F-16	10
24C-6136	2
16F-02	9
16F-04	4, 9
16F-08	9
17F-2	7
18F-4	7
21D-06	4
21F-4	7
24C-16128	11
24C-18136	2
24E-06	4
25F-2	5
25K-40024	3
25K-40110	10
25K-40116	9, 10
25K-40124	9
25K-40128	9
25K-40208	9
25K-40216	11
25K-40800	11
25K-60124	4
25K-60204	9
26F-2	5
26F-4	7
30H-7	14
30H-45	7, 14
31F-1	7
31F-2	7
31F-3	7
31F-4	7
33F-3	7
33F-4	5
36F-1	7
36F-2	5, 7
36F-3	5, 7
36F-4	5, 7
36F-6	10
62D-16	2
66D-16 180-16	11
83F-3	9
89F-3	9
102439	3
102766	3
107010	4
107707	4
107709	4
107713	4
107728	3
107729	3
107730	3
107732	3
107735	4
107736	4
107739	4
107940	4
107941	4
107983	3
107985	3
108456	4
108464	3
108467	4
108468	4
108472	3
108476	4
108477	3
108498	3
108573	5
108705	3
108706	3
108707	3
109135	3
109137	3
109597	4
109598	4
109599	4
110126	4
110208	4
110814	4
110855	4
111053	4
111056	4
111905	4
111461	3
224032	4
301841	7
356611	7
356614	7
356615	7
356616	7
502776	13
507815	3
507816	7
509356	11
509445	12
510452	7
512726	11
512747	11
513117	12
514740	11
514752	11
514753	11
514755	11
515125	3
515201	13
516599	10
519251	9
522329	12
522996	13
522997	13
523029	13
523252	12
523253	12
524057	11
528103	11
528180	11
528694	13
529107	12
530860	7
532772	11
536058	11
536382	11
550745	14
551245	14
551282	14
551684	12
551685	12
551741	13
552164	13
553412	13
580273	12
580274	12
580278	12
580477	12
580479	12
580789	11
580790	11
580794	11
580795	11
580797	2
580799	2
580846	10
580869	13
580872	13
580873	13
580887	2
580920	14
580950	9
580975	14
580976	14
580984	14
580991	14
580994	14
580999	14
581000	14
581001	14
581049	10
581050	10
581957	11
582066	1
590708	2
591623	2
592291	7
592741	5
592742	5
592783	7
592784	7
592785	7
592811	13
593280	7
593370	7
593371	7
593388	7
593435	7
593436	7
593449	7
593474	7
593476	7
593618	12
593650	7
593737	1
593829	5
593908	2
593917	1
593950	10
593954	10
593958	5
593959	5
593960	5
593966	5
594019	1
594020	10
594091	7
594132	7
594133	7
594143	7
594355	10
594390	2
594408	7
594438	5
594439	5
619027	2
652402	7
653673	3
660178	9
660516	4
663093	10
663094	10
675436	9
711186	5, 7
731959	3
742262	3
742263	3
743593	9
755762	9
863045	9
940186	9
940278	9
940643	7
941569	11
942645	7
942646	7
943179	9
943180	9
943181	9
943182	9
943183	9
943184	9
943185	9
943186	9
943187	9
943188	9
943189	9
943190	9
943191	9
943192	9
943193	9
943195	9
943196	9
943197	9
943488	9
943593	9
944144	9
944145	9
944146	9
944147	9
944148	9
944149	9
944150	9
944151	9
944152	9
944153	9
944154	9
944155	9
944156	9
944157	9
944273	13
944671	1
951948	7

NOTES