부품 매뉴얼
PARTS MANUAL

RUTHZIL TRATOR COMERCIAL DE PEÇAS LTDA 11 97083-6812 ROLANDO CITRANGULO


CQ 20/25/30 L

TRUCK MODEL : CQ20-30L

SERIAL NUMBER : CQ230L - XXXX - 8284 CNF (MMC)

부품 청구시 항상 장비의 SERIAL NO. 도 함께 알려 주십시오.

ALWAYS GIVE TRUCK SERIAL NUMBER WHEN ORDERING PARTS.



Publication Date : Jan. 2013

CLARK
THE FORKLIFT

(Head office) 202-1 Ojung-Dong, Ojung-Gu,
Bucheon-city, Kyunggi-do, Korea
(Factory) No.18 Huaihedong Road,
Huangdao Economic & Technical Development Area,
Qingdao Shandong Province, China

00-094 SHORT BLOCK AND ENGINE GASKET SETS
숏 블록 & 엔진 가스킷 세트

00-248 CRANKSHAFT
크랭크 축

00-391 ENGINE MOUNTING
엔진 어셈블리

00-395 GOVERNOR
가버너

00-511 ENGINE BALANCER ASSEMBLY
엔진 발란서

00-586 ENGINE SUB-ASSEMBLY MOUNTING
엔진 서브 어셈블리 마운팅

00-594 ENGINE SUB-ASSEMBLY MOUNTING
엔진 서브 어셈블리 마운팅

00-742 ROCKER COVER
로커 커버

00-743 OIL PAN
오일 팬

00-776 CYLINDER HEAD (GAS/LP)
실린더 헤드

00-818 CRANKCASE
크랭크케이스

00-861 CAMSHAFT
캠 축

01-276 COOLING SYSTEM
냉각 장치

01-506 OIL PUMP
오일 펌프

01-901 FAN MOUNTING
팬 마운팅

02-457 ACCELERATOR LINKAGE
악셀레이터 링케이지

03-157 MANIFOLD
매니폴드

03-158 EXHAUST MANIFOLD
배기 매니폴드

03-299 LPG TANK MOUNTING
LPG 탱크 마운팅

03-350 FUEL LOCK-OFF VALVE
연료 잠금 밸브

03-529 FUEL SYSTEM
연료 시스템

03-581 SWITCH INSTALLATION
스위치 조립그룹

03-693 INTAKE SYSTEM
흡기 시스템 (듀얼)

03-699 EXHAUST SYSTEM
배기 장치

06-068 HYDRATORK TRANSMISSION
하이드로토크 트랜스미션

06-114 CONTROL VALVE ASSEMBLY
컨트롤 밸브 어셈블리

06-603 HYDRATORK TRANSMISSION
하이드로토크 트랜스미션

06-608 TRANSMISSION CLUTCH PACKS
트랜스미션 클러치 팩

07-045 TRANSAXLE MOUNTING
트랜스액슬 마운팅

10-072 TRANS COOLING LINES
트랜스미션 쿨링 라인

11-040 DISTRIBUTOR
디스트리뷰터

11-099 CRANKING MOTOR ASSEMBLY
크랭킹 모터

11-205 IGNITION SYSTEM
점화 시스템

12-030 ALTERNATOR ASSEMBLY
알터네이터 어셈블리

12-031 BATTERY MOUNTING
베터리 어셈블리

13-035 INSTRUMENT PANEL
계기판

13-146 STROBE LIGHT
경광등

13-162 STROBE LIGHT MOUNTING
경광등 어셈블리

13-228 BACK-UP ALARM INSTALLATION
백-업 알람 조립그룹

13-238 CLUSTER GROUP
클러스터 그룹

13-240 KEY SWITCH GROUP
키스위치 그룹

14-083 ELECTRICAL WIRING
전기장치 와이어링

14-369 ELECTRICAL COMPONENTS
전기장치 구성품

14-438 STATIC STRAP
스태틱 스트랩

20-084 DIFFERENTIAL & CARRIER
차동장치 & 캐리어

20-423 DRIVE AXLE
드라이브 액슬

20-424 DIFFERENTIAL & CARRIER
차동장치 & 캐리어

22-013 DRIVE WHEEL & TIRE MOUNTING
드라이브휠 & 타이어 마운팅

22-014 STEER WHEEL & TIRE MOUNTING
스티어휠 & 타이어 마운팅

22-024 DRIVE WHEEL & TIRE (SOLID TYPE)
*

22-026 DRIVE WHEEL & TIRE (SOLID TYPE)
*

22-027 STEER WHEEL & TIRE (SOLID TYPE)
*

22-033 DUAL DRIVE WHEEL & TIRE MOUNTING
*

22-043 DRIVE WHEEL AND TIRE
드라이브 휠 및 타이어

22-044 STEER WHEEL & TIRE
스티어링 휠 & 타이어

22-135 BRAKE ASSEMBLY RH
브레이크 어셈블리 - 우

22-136 BRAKE ASSEMBLY LH
브레이크 어셈블리 - 좌

23-214 INCHING MASTER CYLINDER
인칭 마스터 실린더

23-229 PARKING BRAKE MOUNTING
파킹브레이크 마운팅

23-434 BRAKE & INCHING LINES
브레이크 및 인칭라인

23-467 BRAKE LINES
브레이크 라인

25-044 STEERING COLUMN MOUNTING
스티어링 칼럼 마운팅

26-182 STEERING AXLE
스티어링 액슬

26-240 STEERING CYLINDER
스티어링 실린더

26-280 HYDRAULIC STEERING LINES
스티어링 라인

26-342 STEER AXLE INSTALLATION
스티어링 액슬 조립그룹

29-178 HYDRAULIC PUMP ASSEMBLY
유압 펌프 어셈블리

29-215 HYDRAULIC TANK & COMPONENTS MOUNTING
유압탱크 & 구성품 마운팅

29-244 HYDRAULIC RETURN LINES
유압 리턴 라인

29-576 HYDRAULIC PUMP MOUNTING
유압 펌프 마운팅

30-512 HYDRAULIC CONTROL VALVE-2 SPOOL
유압 컨트롤 밸브 - 2 스풀

30-513 HYDRAULIC CONTROL VALVE-3 SPOOL
유압 컨트롤 밸브 - 3 스풀

30-514 HYDRAULIC CONTROL VALVE-4 SPOOL
유압 컨트롤 밸브 - 4 스풀

30-614 HYDRAULIC VALVE MOUNTING
유압 밸브 마운팅

31-136 TILT LIMIT WITH OVERRIDE
틸트 제한해제

31-201 AUX. VALVE PLUMBING
보조 밸브 라인

31-202 AUX. VALVE PLUMBING
보조 밸브 라인

31-360 HYDRAULIC LIFT & TILT LINES
유압 리프트 & 틸트 라인

31-841 HYDRAULIC SUPPLY LINES
유압 공급 라인

32-139 TILT CYLINDER
틸트 실린더

32-142 TILT CYLINDER
틸트 실린더

32-144 ACCUMULATOR
어큐물레이터

32-153 TILT CYLINDER
틸트 실린더

32-157 TILT CYLINDER MOUNTING
틸트 실린더 어셈블리

32-167 TILT AMOUNT GROUP
틸트 어마운트 그룹

33-069 RELIEF VALVE ASSEMBLY
릴리프 밸브 어셈블리

33-130 SELECTOR SOLENOID VALVE
셀렉터 솔레노이드 밸브

34-044 LOAD BACK REST
로드 백 레스트

34-134 LIFT CARRIAGE ASSEMBLY
리프트 캐리지 어셈블리

34-209 CARRIAGE ASSEMBLY
캐리지 어셈블리

34-998 LIFT CARRIAGE ASSEMBLY
리프트 캐리지 어셈블리

37-118 HOOD MOUNTING
후드 마운팅

37-124 SEAT ARMREST ASSEMBLY
아암레스트 어셈블리

38-113 FRAME & COUNTERWEIGHT
프레임 & 카운터웨이트

38-270 FRAME TANK BOTTOM PLUG
프레임 탱크 하단 플러그

39-104 E SEAT ASSEMBLY
시트 어셈블리

39-147 E SEAT ASSEMBLY
시트 어셈블리

39-195 SEAT MOUNTING
시트 어셈블리

39-519 LOAD BACK REST
로드 백 레스트

39-569 SEAT MOUNTING
시트 어셈블리

39-585 SEAT ASSEMBLY (SUSPENSION)
시트 어셈블리

39-661 SEAT ASSEMBLY
시트 어셈블리

39-771 SEAT MOUNTING
시트 어셈블리

39-829 SEAT MOUNTING
시트 어셈블리

39-834 SEAT ASSEMBLY (SUSPENSION)
시트 어셈블리

39-912 SHEET METAL
시트 메탈

39-988 OVERHEAD GUARD MOUNTING
오버헤드가드 마운팅

40-260 TRUCK FLUIDS
트럭 유체

40-288 DECALS
데칼

40-289 MODEL & SPECIFICATION DECALS
*

41-008 STORAGE CONSOLE
저장 콘솔

47-000 SEAT WING KIT
시트윙 키트

47-006 ENGINE SHUTDOWN CONTROL GROUP
엔진 셧다운 컨트롤 그룹

50-171 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

50-172 HIGH TERMINATION FOR DEVICE HOSE ADAPTATION
*

50-232 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-269 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-270 ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)
*

50-284 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

50-289 ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)
*

50-290 ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)
*

50-291 ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT)
*

50-407 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-410 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-432 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-439 ATTACHMENT HOSE ADAPTATION (UPRIGHT)
작업장치 호스 적용 (업라이트)

50-791 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

50-794 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

50-796 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

50-797 ATTACHMENT HOSE ADAPTATION (CARRIAGE)
작업장치 호스 적용 (캐리지)

53-008 SIDESHIFT CYLINDER
사이드 쉬프트 실린더

53-024 FORK POSITIONER
포크 포지셔너

53-084 FORK POSITIONER
포크 포지셔너

53-146 F/P SIDESHIFT CYLINDER
포크포지셔너 사이드쉬프트실린더

53-164 FORK POSITIONER
포크 포지셔너

53-168 FORK POSITIONER (SHIFTING)
포크 포지셔너 (쉬프트 타입)

53-187 SIDE SHIFT ASSEMBLY
*

53-198 SIDESHIFT CYLINDER
사이드 쉬프트 실린더

66-018 UPRIGHT MOUNTING
업라이트 마운팅

66-058 FORK
포크


66-999 EXTENTION FORK
익스텐션 포크

75-(33)014 VARIABLE RELIEF VALVE INSTALLATION
가변 릴리프 밸브 어셈블리

75-(33)045 DEVICE HYDRAULIC PRESSURE GAUGE INSTALLATION
디바이스 유압 압력계이지 조립그룹

75-(33)130 SOLENOID VALVE
솔레노이드 밸브

75-012 SEAT OPERATED BRAKE SWITCH
시트 조작 브레이크 스위치




00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.010 SHORT ENGINE ASSEMBLY
숏엔진

00.100 GASKET KIT, ENGINE OVERHAUL
가스켓킷

00.101 VALVE GRIND GASKET KIT (TOP SET)
밸브가스켓



PISTON & CRANKSHAFT 00-248

00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.260 BEARING, CONNECTING ROD (CYL. #1)
베어링

00.261 BEARING, CONNECTING ROD (CYL. #2)
베어링

00.262 BEARING, CONNECTING ROD (CYL. #3)
베어링

00.263 BEARING, CONNECTING ROD (CYL. #4)
베어링


00.350 CRANKSHAFT
크랭크샤프트

00.380 PULLEY, CRANKSHAFT
풀리

00.390 WASHER, CRANKSHAFT PULLEY
와셔

00.395 FASTENER, CRANKSHAFT PULLEY
패스너

00.405	KEY, CRANKSHAFT TIMING GEAR 키
00.450	FLYWHEEL 플라이휠
00.453	GEAR, FLYWHEEL RING 기어
00.456	FASTENER, CRANKSHAFT TO FLYWHEEL 패스너
00.760	ROD ASSEMBLY, CONNECTING 로드
00.767	FASTENER, CONNECTING ROD BEARING CAP 패스너
00.806	LOCATOR,CYLINDER SLEEVE 로케이터
00.820	PISTON RING 피스톤링
04.301	BEARING, PILOT (IN FLYWHEEL) 베어링
90.255	NUT, CONNECTING ROD BEARING CAP FASTENER 너트
94.961	LOCKWASHER, CRANKSHAFT ACCESS DRIVE PULLEY FASTENE 로크와셔
94.962	FASTENER, CRANKSHAFT PULLEY SPACER 패스너



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.035 FASTENER, ENGINE FRONT SUPPORT
패스너

00.056 MOUNT, ENGINE RH
마운트

00.065 FASTENER, ENGINE MOUNT
패스너

00.071 MOUNT, ENGINE LH
마운트


00.081 FASTENER, ENGINE MOUNT (RH)
패스너

00.083 FASTENER, ENGINE MOUNT (LH)
패스너

00.086 FASTENER, RH ENGINE MOUNT
패스너

00.089 DAMPENER, LH ENGINE MOUNT VIBRATION
댐프너

00.098	WASHER, ENGINE MOUNTING TO FRAME RH 와셔
00.099	WASHER, ENGINE MOUNTING TO FRAME RH (LOWER) 와셔
91.753	WASHER, ENGINE MOUNT FASTENER 와셔
91.754	NUT, ENGINE MOUNT FASTENER 너트



00.265 BALL, ENGINE GOVERNOR LOCKWIRE
볼

00.266 LOCKWIRE, ENGINE GOVERNOR
로크와이어

00.900 GOVERNOR ASSEMBLY , ENGINE
거버너

00.924 ADJUSTOR, GOVERNOR SPRING
어드져스터

00.928 FASTENER, GOVERNOR ADJUSTING LEVER
패스너


00.930 SPRING, GOVERNOR
스프링

00.947 LEVER & SHAFT, GOVERNOR
레버와샤프트

00.952 FASTENER, GOVERNOR THROTTLE
패스너

00.992 CAP, ENGINE GOVERNOR SEAL (SPEED ADJUSTMENT)
캡

00.993	COVER, GOVERNOR ACCESS 커버
00.994	GASKET,GOVERNOR ACCESS COVER 가스켓
00.995	PISTON,GOVERNOR STABILIZER 피스톤
00.996	SHAFT, GOVERNOR STABILIZER PISTON 샤프트
00.997	FITTING,GOVERNOR FUEL 피팅
00.998	GASKET, GOVERNOR ACCESS COVER 가스켓
00.999	COVER, GOVERNOR ACCESS 커버
03.900	THROTTLE PLATE, ENGINE GOVERNOR 트로틀
94.994	FASTENER, ENGINE GOVERNOR SPEED ADJUSTING SEAL CAP 패스너
94.995	LOCKWASHER,ENGINE GOVERNOR SPEED ADJUSTING SEAL CA 로크와셔
96.028	FASTENER, GOVERNOR ACCESS COVER 패스너
96.029	FASTENER, GOVERNOR STABILIZER PISTON 패스너
96.030	WASHER, GOVERNOR STABILIZER PISTON 와셔
96.031	FASTENER, GOVERNOR ACCESS COVER 패스너
96.032	LOCKWASHER, GOVERNOR ACCESS COVER FASTENER 로크와셔
96.033	FASTENER, GOVERNOR ACCESS COVER 패스너
96.034	FASTENER, GOVERNOR SPRING 패스너



ENGINE BALANCER ASSEMBLY

00-511

00.300 BALANCER ASSEMBLY, ENGINE
발란서

00.308 WEIGHT, ENGINE BALANCER
발란서웨이트

00.315 GEAR, BALANCER WEIGHT DRIVEN
기어

00.316 RETAINER, BALANCER WEIGHT GEARS
리테이너

00.320 FASTENER, ENGINE BALANCER DRIVE GEAR
패스너

00.324 GEAR, BALANCER WEIGHT DRIVE
기어

00.331 WEIGHT, ENGINE BALANCER
발란서웨이트


00.373 SPACER, ENGINE BALANCER WEIGHT DRIVEN GEAR
스페이서

00.374 SEAL, ENGINE BALANCER WEIGHT RETAINER
시일

00.454 CHAIN,ENGINE BALANCER DRIVE
체인

95.475 FASTENER, ENGINE BALANCER WEIGHT RETAINER
패스너

96.444 WASHER, BALANCER DRIVEN GEAR
와셔




00.000	PRODUCTION ENGINE ASSEMBLY 엔진	01.582	ELBOW, WATER OUTLET 엘보우
00.250	FITTING, WATER PUMP 피팅	01.586	FASTENER, WATER OUTLET ELBOW - FANSIDE 패스너
00.831	TIMING INDICATOR PLATE 타이밍플레이트	01.589	GASKET, WATER OUTLET ELBOW 가스켓
00.851	FASTENER, ENGINE TIMING POINTER 패스너	01.596	THERMOSTAT, ENGINE 써머스태트
01.405	FASTENER, FAN BLADE 패스너	01.619	LINE, WATER PUMP BLEEDER 라인
01.418	BELT, WATER PUMP 벨트	01.620	FITTING, WATER PUMP BLEEDER LINE 피팅
01.430	PUMP ASSEMBLY, ENGINE WATER 펌프	01.621	CLAMP, WATER PUMP BLEEDER LINE 클램프
01.432	PULLEY, WATER PUMP 풀리	12.103	FASTENER, ALTERNATOR TO BRACKET 패스너
01.434	COVER, WATER PUMP 커버	12.105	STRAP, ALTERNATOR ADJUSTING 스트랩
01.438	FASTENER, WATER PUMP 패스너	12.106	FASTENER, ADJUSTING STRAP MOUNTING 패스너
01.439	FASTENER, WATER PUMP 패스너	12.107	FASTENER, ADJUSTING STRAP TO ALTERNATOR 패스너
01.441	GASKET, ENGINE WATER PUMP ATTACHING 가스켓	12.200	ALTERNATOR ASSEMBLY 알터네이터
01.442	DRAIN COCK, ENGINE WATER PUMP 드레인콕	13.011	CONTROL, ENGINE TEMPERATURE INDICATOR 컨트롤
01.466	FASTENER, WATER PUMP COVER 패스너	13.013	CONTROL, ENGINE OIL PRESSURE INDICATOR 컨트롤
01.519	SEAL, WATER PUMP BLEEDER LINE FITTING 시일	94.099	FASTENER, WATER PUMP DISCHARGE FLANGE 패스너

94.702 FASTENER, WATER PUMP BLEEDER LINE CLIP
패스너

95.425 NUT, CONTROL PANEL CAPACITOR MOUNTING
너트

95.765 FASTENER, WATER PUMP
패스너



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.017 BRACKET, ENGINE FRONT SUPPORT
브라켓

00.019 FASTENER, ENGINE FRONT SUPPORT BRACKET
패스너

00.172 COVER, CRANKCASE FUEL PUMP HOLE
커버

00.178 FASTENER, CRANKCASE FUEL PUMP HOLE COVER
패스너


00.243 CLAMP, ENGINE AIR GOVERNOR VENT LINE
클램프

00.244 LINE, ENGINE AIR GOVERNOR VENTILATION
라인

00.900 GOVERNOR ASSEMBLY , ENGINE
거버너

00.951 THROTTLE ASSEMBLY, GOVERNOR
트로틀

00.953	GASKET, GOVERNOR THROTTLE MOUNTING 가스켓
01.364	FITTING, OIL PRESSURE GAUGE LINE 피팅
02.100	CARBURETOR ASSEMBLY 기화기
02.116	GASKET, CARBURETOR MOUNTING 가스켓
02.320	BRACKET, ACCELERATOR LEVER ATTACHING 브라켓
02.337	BRACKET, ACCELERATOR LEVER MOUNTING 브라켓
11.020	MOTOR ASSEMBLY, STARTING 모터
11.034	FASTENER, STARTING MOTOR 패스너
11.300	DISTRIBUTOR ASSEMBLY 디스트리뷰터
90.920	NUT, CARBURETOR MOUNTING FASTENER 너트
91.492	LOCKWASHER, CARBURETOR MOUNTING FASTENER 로크와셔
91.717	NUT, DISTRIBUTOR FASTENER 너트
92.319	WASHER, DISTRIBUTOR MOUNTING CLAMP FASTENER 와셔



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.133 TUBE, CRANKCASE VENT
튜브

00.136 CLIP, CRANKCASE VENT TUBE
클립

00.139 VALVE, CRANKCASE VENT TUBE
밸브

00.435 LINE, CRANKCASE BREATHER
라인

00.437 CLAMP, CRANKCASE BREATHER LINE
클램프

00.439 CLAMP, CRANKCASE VENT LINE
클램프

00.663 COVER, ROCKER ARM
커버

00.664 GASKET, ROCKER ARM COVER
가스켓

00.665 FASTENER, ROCKER ARM COVER
패스너

00.702 SEAL, ROCKER ARM COVER FASTENER
시일


00.733 PLUG, CRANKCASE HEAD END COVER
플러그

00.789 PLUG, ROCKER ARM COVER
플러그


01.283 CAP, CRANKCASE OIL FILLER
캡

01.286 GASKET, OIL FILLER CAP
가스켓

90.434 WASHER, ROCKER ARM COVER FASTENER
와셔



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.238	COVER, TIMING BELT UNDER LOWER 커버
00.240	COVER, TIMING BELT FRONT UPPER 커버
00.241	GASKET, TIMING BELT FRONT UPPER COVER 가스켓
00.396	SEAL, ENGINE FRONT GEAR COVER GASKET 시일
00.416	PLATE, ENGINE REAR 플레이트
00.496	PLUG, ENGINE FRONT GEAR COVER 플러그
00.527	GASKET, ENGINE FRONT GEAR COVER 가스켓
00.530	COVER, ENGINE FRONT GEAR 커버
00.545	FASTENER, ENGINE FRONT GEAR COVER 패스너
00.549	GASKET, ENGINE FRONT GEAR COVER SEAL 가스켓
00.562	FASTENER, ENGINE FRONT GEAR COVER 패스너
00.563	FASTENER, ENGINE FRONT GEAR COVER 패스너
00.831	TIMING INDICATOR PLATE 타이밍플레이트
00.843	FASTENER, FLYWHEEL HOUSING DUST SHIELD 패스너
00.844	SHIELD, FLYWHEEL HOUSING DUST 쉴드
01.075	PAN, CRANKCASE OIL 팬
01.076	FASTENER, CRANKCASE OIL PAN 패스너
01.077	FASTENER, OIL PAN TO CRANKCASE 패스너
01.099	PLUG, CRANKCASE OIL PAN DRAIN 플러그
01.100	GASKET, CRANKCASE OIL PAN DRAIN PLUG 가스켓
01.706	STRAINER, OIL PUMP OIL 스트레이너
01.725	GASKET, OIL STRAINER FRAME 가스켓
01.760	BOLT, OIL PUMP STRAINER FASTENER 볼트
01.761	LOCKWASHER, OIL PUMP STRAINER FASTENER 로크와셔
91.068	BOLT, ENGINE REAR PLATE 볼트
94.720	FASTENER, ENGINE REAR PLATE 패스너
94.960	NUT, OIL PUMP STRAINER FASTENER 너트
94.965	FASTENER, TIMING BELT FRONT UPPER COVER 패스너



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.064 SEAL, CAMSHAFT OIL
시일

00.151 PLUG, CRANKCASE HEAD REAR
플러그

00.600 HEAD ASSEMBLY, CRANKCASE
헤드

00.604 GASKET, CRANKCASE HEAD
가스켓

00.605 FASTENER, CRANKCASE HEAD
패스너

00.606 FASTENER, CRANKCASE HEAD
패스너

00.607 FASTENER, CRANKCASE HEAD
패스너

00.608 FASTENER, CRANKCASE HEAD
패스너

00.627 PLUG, CRANKCASE HEAD
플러그

00.628 PLUG, CRANKCASE HEAD
플러그

00.646 FASTENER, ENGINE ROCKER ARM PIVOT SUPPORT
패스너

00.683 SEAT, EXHAUST VALVE INSERT
시트


00.684 SEAT, INTAKE VALVE INSERT
시트

00.693 GUIDE, INTAKE VALVE
가이드

00.694 GUIDE, EXHAUST VALVE
가이드


00.734 SEAL, CRANKCASE HEAD PLUG
시일

00.793 BUSHING, ENGINE LOCKER ARM PIVOT SUPPORT
부싱




CYLINDER BLOCK 00-818

00.043	BUSHING, ENGINE REAR SUPPORT BRACKET 부싱	00.362	BEARING, NO. 3 MAIN JOURNAL 베어링
00.087	STUD, ENGINE FRONT SUPPORT 스터드	00.363	BEARING, NO. 4 MAIN JOURNAL 베어링
00.149	PLUG - EXPANSION, CRANKCASE SIDE 플러그	00.364	BEARING, NO. 5 MAIN JOURNAL 베어링
00.154	PLUG - EXPANSION, CRANKCASE END 플러그	00.413	PLUG & WASHER, CRANKCASE 플러그와셔
00.155	PLUG - EXPANSION, CRANKCASE END 플러그	00.427	SEAL, CRANKCASE REAR OIL 시일
00.196	PLUG-EXPANSION, CRANKCASE SIDE 플러그	00.455	FASTENER, REAR OIL SEAL HOUSING 패스너
00.200	FASTENER, CRANKSHAFT BEARING NO. 1 CAP 패스너	00.458	HOUSING, REAR OIL SEAL 하우징
00.204	FASTENER, CRANKSHAFT BEARING NO. 2 CAP 패스너	00.461	DOWEL, CRANKCASE HEAD 다웰
00.208	FASTENER, CRANKSHAFT BEARING NO. 3 CAP 패스너	00.808	DOWEL RING, CRANKCASE REAR ADAPTOR PLATE 다웰링
00.302	BEARING, BALANCER WEIGHT REAR 베어링	00.841	DOWEL RING, ENGINE FRONT GEAR COVER 다웰링
00.348	BEARING, ENGINE BALANCER SHAFT REAR 베어링	01.018	SEAL, OIL LEVEL DIPSTICK ADAPTOR 시일
00.349	BEARING, ENGINE BALANCER SHAFT FRONT 베어링	01.125	DIPSTICK, CRANKCASE OIL LEVEL 딥스틱
00.354	WASHER, CRANKSHAFT THRUST 와셔	01.134	ADAPTOR, CRANKCASE OIL LEVEL DIPSTICK 어댑터
00.360	BEARING, NO. 1 MAIN JOURNAL 베어링	95.969	FASTENER, ENGINE OIL LEVEL CONTROL 패스너
00.361	BEARING, NO. 2 MAIN JOURNAL 베어링		



00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.385	KEY, CRANKSHAFT PULLEY 키
00.404	GEAR, CRANKSHAFT TIMING 기어
00.644	PIVOT, ENGINE ROCKER ARM 피봇
00.645	SPRING, ENGINE ROCKER ARM 스프링
00.649	WASHER, ENGINE ROCKER ARM PIVOT 와셔
00.650	CAMSHAFT 캠샤프트
00.657	ROCKER ARM ASSEMBLY, ENGINE VALVE 로커
00.658	ROCKER ARM ASSEMBLY, ENGINE VALVE 로커
00.659	ADJUSTOR, ENGINE VALVE 어드져스터
00.677	GEAR, CAMSHAFT TIMING 기어
00.678	FASTENER, TIMING GEAR TO CAMSHAFT 패스너
00.685	VALVE, EXHAUST 밸브
00.688	VALVE, INTAKE 밸브
00.692	SPRING, ENGINE EXHAUST VALVE 스프링
00.696	PILOT, ENGINE VALVE SPRING 파일롯
00.697	SEAL, ENGINE VALVE 시일
00.698	LOCK, EXHAUST VALVE SPRING SEAT 로크
00.705	SEAT, EXHAUST VALVE SPRING 시트
00.726	SEAL, ENGINE VALVE 시일
00.728	CHAIN, CAMSHAFT TIMING 체인
00.769	TENSIONER, CAMSHAFT TIMING CHAIN 텐셔너
00.786	SPRING, CAMSHAFT TIMING CHAIN TENSIONER 스프링
00.788	PIVOT, ENGINE ROCKER ARM (RH) 피봇
00.798	DAMPENER, CAMSHAFT TIMING CHAIN TENSIONER SPRING 댐프너
01.789	GEAR, OIL PUMP DRIVE 기어
11.302	PIN, DISTRIBUTOR GEAR 핀
90.722	NUT, OIL PUMP FASTENER 너트
94.974	WASHER, CAMSHAFT TIMING BELT TENSIONER FASTENER 와셔
94.978	FASTENER, CAMSHAFT TIMING BELT TENSIONER 패스너



01.130 BRACKET, RADIATOR
브라켓

01.151 GUARD, RADIATOR FAN
가드

01.520 COMPENSATION TANK, COOLING SYSTEM
보상기

01.521 COVER, COMPENSATION TANK
커버

01.523 LINE, COOLING SYSTEM COMPENSATION TANK
라인


01.528 CLIP, RADIATOR OVERFLOW LINE
클립

01.529 CLAMP, RADIATOR OVERFLOW LINE
클램프

01.537 PAD, RADIATOR MOUNTING LOWER
패드


01.547 DRAIN COCK, RADIATOR
드레인콕

01.550	RADIATOR 라디에터
01.555	LINE, RADIATOR OVERFLOW 라인
01.561	FASTENER, RADIATOR MOUNTING 패스너
01.563	FASTENER, RADIATOR MOUNTING BRACKET 패스너
01.566	PAD, RADIATOR MOUNTING 패드
01.570	CAP, RADIATOR 캡
01.577	HOSE, RADIATOR UPPER 호스
01.579	CLAMP, RADIATOR UPPER HOSE 클램프
01.600	HOSE, RADIATOR LOWER 호스
01.601	CLAMP, RADIATOR LOWER HOSE 클램프
01.602	TUBE, RADIATOR LOWER 튜브
01.607	HOSE, ENGINE WATER PUMP INLET 호스
01.640	FASTENER, RADIATOR SHROUD EXTENTION 패스너
01.660	SHROUD, RADIATOR 슈라우드
01.693	DAMPENER, RADIATOR VIBRATION 댐프너
94.870	FASTENER, RADIATOR MOUNTING BRACKET 패스너



OIL PUMP & OIL FILTER 01-506

00.000	PRODUCTION ENGINE ASSEMBLY 엔진
00.270	CASE AND OIL PUMP, ENGINE FRONT END 오일펌프케이스
00.271	GASKET, ENG FRONT END CASE AND OIL PUMP ASSY 가스켓
00.489	PLUG, ENGINE FRONT GEAR COVER 플러그
00.490	SEAL, ENGINE FRONT GEAR COVER PLUG 시일
00.547	SEAL, ENGINE FRONT GEAR COVER 시일
00.570	FASTENER, BACKING PLATE 패스너
00.571	FASTENER, BACKING PLATE 패스너
00.572	FASTENER, BACKING PLATE 패스너
00.573	FASTENER, BACKING PLATE 패스너
00.574	FASTENER, BACKING PLATE 패스너
01.243	BASE, ENGINE OIL FILTER 베이스
01.244	PLUG, ENGINE OIL FILTER BASE 플러그
01.245	GASKET, ENGINE OIL FILTER BASE PLUG 가스켓
01.248	PLUG, ENGINE OIL FILTER ADAPTOR 플러그
01.256	SEAT, ENGINE OIL FILTER SPRING 시트
01.293	FASTENER, ENGINE OIL FILTER ATTACHING 패스너
01.294	FITTING, ENGINE OIL FILTER OUTLET 피팅
01.295	FASTENER, ENGINE OIL FILTER ATTACHING 패스너
01.296	FASTENER, ENGINE OIL FILTER ATTACHING 패스너
01.307	CARTRIDGE & GASKET, ENGINE OIL FILTER 카트리지와가스켓
01.319	SPRING, ENGINE OIL FILTER 스프링
01.322	GASKET, ENGINE OIL FILTER ADAPTOR 가스켓
01.702	FASTENER, OIL PUMP 패스너
01.704	FASTENER, OIL PUMP COVER 패스너
01.715	GASKET, OIL PUMP COVER 가스켓
01.727	DOWEL, OIL PUMP BODY 다월
01.730	GEAR, OIL PUMP DRIVE IDLER 기어
01.790	GEAR, OIL PUMP DRIVEN 기어



00.381 PULLEY, CRANKSHAFT ACCESSORY DRIVE
풀리

00.382 FASTENER, CRANKSHAFT ACCESS DR PULLEY
패스너

01.378 BRACE, FAN BRACKET
브레이스

01.381 BLADE, FAN
블레이드

01.399 BRACKET, FAN MOUNTING
브라켓


01.404 FASTENER, FAN BRACKET
패스너

01.406 BELT, FAN
븜트셋

01.408 SHEAVE ASSEMBLY, IDLER
쉬브

01.409 SPACER, IDLER ADJUSTMENT
스페이서

01.411	RETAINER, IDLER SHEAVE 리테이너
01.412	RETAINER, IDLER SHEAVE BEARING 리테이너
01.413	BEARING, BELT IDLER SHEAVE 베어링
01.416	SPACER, FAN BLADE 스페이서
01.417	PULLEY, FAN 풀리
01.419	BRACKET, IDLER SHEAVE 브라켓
01.429	FASTENER, FAN CONTROL 패스너
01.465	FASTENER, FAN BLADE SPACER 패스너
01.489	SHIM, WATER PUMP PULLEY FASTENER 심
01.501	PIVOT, FAN DRIVE IDLER SHEAVE BRACKET 피봇
94.866	FASTENER, FAN BLADE MOUNTING BRACKET GUIDE 패스너
95.403	FASTENER, RADIATOR SHROUD BRACKET 패스너
96.577	FASTENER, FAN MOUNTING BRACKET 패스너
96.578	FASTENER, FAN MOUNTING BRACKET 패스너



ACCELERATOR LINKAGE **02-457**

02.280 PEDAL, ACCELERATOR
페달

02.282 ROD, ACCELERATOR PUSH
로드

02.283 PIN, ACCELERATOR PEDAL TO BRACKET PIVOT
핀

02.285 STOP, ACCELERATOR PEDAL LINKAGE
스톱

02.286 FASTENER, PUSH ROD
패스너


02.288 BRACKET, ACCELERATOR PEDAL ATTACHING
브라켓

02.289 FASTENER, ACCELERATOR PEDAL BRACKET ATTACHING
패스너

02.320 BRACKET, ACCELERATOR LEVER ATTACHING
브라켓

02.321 FASTENER, ACCELERATOR LEVER BRACKET
패스너

02.326	BEARING, ACCELERATOR LEVER 베어링
02.337	BRACKET, ACCELERATOR LEVER MOUNTING 브라켓
02.475	ROD, ACCELERATOR CONTROL 로드
02.781	CLIP, ACCELERATOR CABLE TO BRACKET 클립
02.782	FASTENER, BRACKET CLIP 패스너
03.461	PIN, ACCELERATOR CONTROL ROD END 핀
03.462	SPRING, ACCELERATOR PEDAL RETURN 스프링
90.951	RETAINER, ACCELERATOR PEDAL STOP 리테이너
90.957	RETAINER, ACCELERATOR LINKAGE LEVER PIN 리테이너
94.735	RETAINER, ACCELERATOR CONTROL ROD END PIN 리테이너



MANIFOLD 03-157

00.000 PRODUCTION ENGINE ASSEMBLY
엔진

00.464 BRACKET, ENGINE LIFTING
브라켓

01.582 ELBOW, WATER OUTLET
엘보우

01.586 FASTENER, WATER OUTLET ELBOW - FANSIDE
패스너

01.589 GASKET, WATER OUTLET ELBOW
가스켓


01.596 THERMOSTAT, ENGINE
써머스태트

02.122 FASTENER, CARBURETOR
패스너

02.539 PLUG - PIPE, MANIFOLD
플러그

02.548 MANIFOLD, INTAKE
매니폴드

02.557	FASTENER, MANIFOLD TO CRANKCASE 패스너
02.559	FASTENER, MANIFOLD TO CRANKCASE 패스너
02.929	GASKET, INTAKE MANIFOLD 가스켓
90.253	NUT, MANIFOLD FASTENER 너트
90.556	LOCKWASHER, MANIFOLD FASTENER 로크와셔



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

02.549 MANIFOLD, EXHAUST
매니폴드

02.554 FASTENER, MANIFOLD TO CRANKCASE
패스너

02.589 SHIELD, HEAT (AT MANIFOLD)
쉴드


02.631 FASTENER, HEAT SHIELD
패스너

02.928 GASKET, EXHAUST MANIFOLD
가스켓


03.457 SHIELD, MANIFOLD HEAT
쉴드

90.736 WASHER, MANIFOLD FASTENER
와셔

90.738 NUT, MANIFOLD FASTENER
너트



02.011	FASTENER, TANK REAR MOUNTING BRACKET 패스너
02.017	SUPPORT, GAS TANK MOUNTING 서포트
02.020	TANK, FUEL 탱크
03.299	SPACER, LPG TANK GUARD MOUNTING FASTENER 스페이서
39.486	FASTENER, GAS TANK SHIELD 패스너
62.003	CLAMP, LPG TANK 클램프



02.050 VALVE, LPG LOCK OFF
밸브

02.753 GASKET, FUEL FILTER BODY
가스켓

02.754 ELEMENT, FUEL FILTER
엘리먼트

02.772 FASTENER, FUEL FILTER COVER
패스너

03.396 REPAIR KIT, FUEL VALVE AND FILTER
리페어킷

03.397 FULCRUM, FUEL VALVE OPERATING VALVE LEVER
지지대

03.398 LEVER, FUEL VALVE OPERATING VALVE
레버

03.399 SPRING, FUEL VALVE OPERATING VALVE
스프링

92.931 FASTENER, FUEL VALVE DIAPHRAGM COVER
패스너

92.932 LOCKWASHER, FUEL VALVE DIAPHRAGM COVER FASTENER
로크와셔

92.933 FASTENER, FUEL VALVE OPERATING VALVE LEVER FULCRUM
패스너

92.934 RETAINER, FUEL VALVE OPERATING VALVE SEAL
리테이너


92.935 FASTENER, LOCK-OFF VALVE AND FILTER
패스너

92.936 LOCKWASHER, LOCK-OFF VALVE AND FILTER FASTENER
로크와셔

92.937 LOCKWASHER, FUEL VALVE OPERATING VALVE SPRING FAST
로크와셔

92.938 FASTENER, FUEL FILTER COVER FASTENER
패스너

92.939 LOCKWASHER, FUEL FILTER COVER FASTENER
로크와셔



LPG FUEL SYSTEM **03-529**


01.627	LINE, VAPORIZER WATER OUTLET 라인	02.059	FITTING, LPG VAPORIZER INLET 피팅
01.629	FITTING, VAPORIZER WATER INLET 피팅	02.065	FITTING, LOCK OFF VALVE INLET 피팅
01.630	LINE, VAPORIZER WATER INLET 라인	02.092	FITTING, LPG VAPORIZER OUTLET 피팅
01.638	CLAMP, VAPORIZER WATER OUTLET LINE 클램프	02.095	FITTING, LPG THREE WAY ADAPTOR 피팅
02.040	COUPLER, LPG QUICK DISCONNECT 커플러	02.601	REGULATOR,VAPORIZER ASSY 레귤레이터
02.041	LINE, LP GAS TANK OUTLET 라인	02.717	FITTING, CARBURETOR INLET 피팅
02.042	FITTING, LPG COUPLER TO LINE 피팅	02.868	SHIELD, LPG LINE 쉴드
02.044	VALVE, HYDROSTATIC RELIEF 밸브	03.143	COUPLER, LPG QUICK DISCONNECT 커플러
02.045	ADAPTOR, THREE WAY THRU HOOD 어댑터	03.322	BRACKET, LPG REGULATOR MOUNTING 브라켓
02.046	FASTENER, ADAPTOR 패스너	03.326	FASTENER, LPG REGULATOR MOUNTING BRACKET 패스너
02.047	FITTING, LPG ADAPTOR OUTLET 피팅	03.400	LINE, FUEL LOCK-OFF VALVE OUTLET 라인
02.049	LINE, ADAPTOR OUTLET 라인	03.402	LINE, LPG LOCK-OFF VALVE VACUUM 라인
02.050	VALVE, LPG LOCK OFF 밸브	03.403	FITTING, LPG LOCK-OFF VALVE VACUUM PORT 피팅
02.052	CLAMP, REGULATOR OUTLET HOSE 클램프	03.733	SWITCH,LPG PRESSURE 스위치
02.053	LINE, REGULATOR OUTLET 라인	03.921	HOSE, RELIEF VALVE 호스

03.942 CLAMP, RELIEF VALVE HOSE
클램프

03.943 VALVE, HYDROSTATIC RELIEF
밸브


90.898 LOCKWASHER, ADAPTOR FASTENER
로크와셔

92.935 FASTENER, LOCK-OFF VALVE AND FILTER
패스너



SWITCH INSTALLATION **03-581**

03.733 SWITCH,LPG PRESSURE
스위치



00.130 LINE, CRANKCASE VENT
라인

02.221 CLAMP, MAIN AIR CLEANER OUTLET HOSE
클램프

02.225 CLEANER ASSEMBLY, ENGINE INTAKE AIR
에어클리너

02.232 CLAMP, INTAKE AIR CLEANER
클램프

02.235 CAP, ENGINE INTAKE AIR CLEANER INLET
캡

02.238 TUBE, MAIN AIR CLEANER INLET
튜브

02.239 BAND, ENGINE INTAKE AIR CLEANER
밴드

02.242 ELEMENT & GASKET, ENGINE INTAKE AIR CLEANER
엘리먼트와가스켓


02.246 FASTENER, ENGINE INTAKE AIR CLEANER ATTACHING
패스너

02.252 FITTING, MAIN AIR CLEANER OUTLET TUBE
피팅

02.264 TUBE, MAIN AIR CLEANER OUTLET
튜브

03.202 CLAMP, ENGINE AIR INTAKE ADAPTOR
클램프

03.517 BRACKET, AIR CLEANER MOUNTING
브라켓



02.569 FASTENER, EXHAUST PIPE FLANGE TO MANIFOLD
패스너

02.579 CLAMP, EXHAUST PIPE TO MUFFLER
클램프

02.581 EXTENSION, TAIL PIPE
익스텐션

02.582 MUFFLER
머플러

02.583 PIPE, TAIL
파이프


02.584 CLAMP, TAIL PIPE TO MUFFLER
클램프

02.589 SHIELD, HEAT (AT MANIFOLD)
쉴드

02.591 FASTENER, MUFFLER MOUNTING
패스너

02.594 FASTENER, TAIL PIPE MOUNTING BRACKET
패스너

02.783	DAMPENER, MUFFLER MOUNTING VIBRATION 댐프너
03.359	PIPE, EXHAUST 파이프
03.541	RING, EXHAUST PIPE MANIFOLD FLANGE SEALING 링
37.390	PLATE, OVERHEAD GUARD REINFORCING 플레이트
95.898	WASHER, MUFFLER ATTACHING FASTENER 와셔
96.531	NUT, MUFFLER MOUNTING BRACKET FASTENER 너트



05.000	CONVERTER ASSEMBLY, TORQUE 컨버터
05.001	GEAR, CONVERTER RING 기어
05.004	FASTENER, CONVERTER DRIVE & REINFORCING PLATE 패스너
05.023	SEAL, CONVERTER IMPELLER HUB 시일
05.030	GEAR, IMPELLER HUB 기어
05.033	STATOR SUPPORT ASSEMBLY, CONVERTER 스테이터
05.056	RING-RETAINING, PUMP DRIVE GEAR 링
05.057	GEAR, PUMP DRIVE 기어
05.067	GASKET, CONVERTER PUMP 가스켓
05.068	FASTENER, CONVERTER CHARGING PUMP 패스너
05.104	SPRING, INNER 스프링
05.130	SHAFT, CONVERTER PUMP IDLER GEAR 샤프트
05.132	THRUST WASHER, CONVERTOR PUMP IDLER GEAR 트러스트와셔
05.133	GEAR, CONVERTOR PUMP IDLER 기어
05.134	BEARING, CONVERTOR PUMP IDLER GEAR 베어링
05.136	BEARING, CONVERTER STATOR SUPPORT 베어링
05.137	LOCATOR, CONVERTER STATOR SUPPORT (OUTER) 로케이터
05.140	LOCATOR, CONVERTER STATOR SUPPORT (INNER) 로케이터
05.141	ADAPTOR, CONVERTER DRIVE 어댑터
05.145	WASHER, CONVERTER STATOR SUPPORT 와셔
05.192	LOCKWASHER, CONVERTER PUMP FASTENER 로크와셔
05.218	BODY, PRESSURE REGULATING VALVE 바디
05.222	CAPSCREW, CONVERTOR PUMP MOUNTING 캡스크류
06.220	GEAR, REVERSE IDLER 기어
06.400	CONTROL COVER & VALVE ASSEMBLY 컨트롤커버와밸브
06.408	GASKET, CONTROL COVER ATTACHING 가스켓
06.424	FASTENER, CONTROL COVER 패스너
06.581	BEARING, REVERSE GEAR 베어링
06.583	BEARING, REVERSE GEAR 베어링
06.704	VALVE, TRANSMISSION PRESSURE RELIEF 밸브

06.948 SLEEVE, CLUTCH OIL DISTRIBUTION
슬리브

10.105 ELEMENT & GASKET, OIL FILTER
엘리먼트와가스켓

20.100 TRANSAXLE ASSEMBLY
트랜스액슬

24.059 SHIM, OIL PUMP PISTON BUSHING
심

24.070 PISTON, OIL PUMP
피스톤

26.002 SNAP RING, PISTON ROD SEAL RETAINING
스냅링

29.016 VALVE, OIL FILTER CHECK
밸브

29.300 PUMP ASSEMBLY, CONVERTER CHARGING
펌프

44.124 SPRING, TRANSMISSION SAFETY VALVE
스프링

44.163 STOP, TRANSMISSION SAFETY VALVE
스톱

91.005 LOCKWASHER, CONTROL COVER FASTENER
로크와셔


91.428 LOCKWASHER, CONVERTER CHARGING PUMP FAST
로크와셔

92.127 LOCKWASHER, CONVERTER DRIVE AND REINFORCING PLAT
로크와셔

94.958 WASHER, CONVERTER DRIVE & REINFORCING PLATE FAST
와셔

95.426 FASTENER, CONVERTER DRIVE ADAPTOR
패스너

95.880 LOCKWASHER, CONVERTER DRIVE ADAPTOR FASTENER
로크와셔



05.511	SEAL, INCHING PISTON HOUSING 시일
05.515	SPOOL, INCHING 스풀
06.400	CONTROL COVER & VALVE ASSEMBLY 컨트롤커버와밸브
06.402	VENT, CONTROL COVER AIR 벤트
06.425	PLUG, CONTROL COVER OIL PASSAGE 플러그
06.472	PLUG, CONTROL VALVE HOUSING OIL PASSAGE 플러그
06.476	RETAINER, INCHING VALVE PISTON 리테이너
06.477	WASHER, INCHING VALVE PISTON 와셔
06.478	SPRING, INCHING PISTON RETURN 스프링
06.479	PISTON, INCHING 피스톤
06.480	SEAL, INCHING PISTON 시일
06.481	FITTING, INCHING VALVE PISTON PORT 피팅
06.513	SPRING, INCHING VALVE 스프링
06.514	ROD, INCHING VALVE 로드
06.517	SEAL, INCHING VALVE PISTON PORT FITTING 시일
06.540	SEAL, INCHING PISTON HOUSING 시일
06.544	HOUSING, INCHING PISTON 하우징
06.660	SOLENOID ASSEMBLY, TRANSMISSION 솔레노이드
06.717	SEAL, CONTROL COVER OIL PASSAGE 시일
06.847	FASTENER, ACCUMULATOR HOUSING 패스너
08.493	PLUG, SPEED CHANGE NEEDLE VALVE HOUSING 플러그
08.601	GASKET, MODULATION VALVE 가스켓
43.061	HOUSING, CONTROL VALVE INCHING PISTON 하우징
43.093	PLUG, CONTROL VALVE HOUSING 플러그
44.105	SPRING, TRANSMISSION ACCUMULATOR OUTER 스프링
44.106	SPRING, TRANSMISSION ACCUMULATOR MIDDLE 스프링
44.107	SPRING, TRANSMISSION ACCUMULATOR INNER 스프링
44.109	SEAL, TRANSMISSION ACCUMULATOR BORE PLUG 시일
44.131	SPOOL, FORWARD & REVERSE 스풀
44.145	SPOOL, MODULATOR 스풀

44.146 SPRING, MODULATOR SPOOL
스프링

44.147 HOUSING, TRANSMISSION CONTROL ACCUMULATOR
하우징

44.148 SPOOL, ACCUMULATOR
스풀

44.149 SEAL, ACCUMULATOR HOUSING TO CONTROL VALVE
시일

44.160 SEAT, TRANSMISSION SHIFT MODULATOR SPOOL SPRING
시트

44.161 STOP, TRANSMISSION ACCUMULATOR SPOOL
스톱

44.164 SPRING, TRANSMISSION FORWARD & REVERSE VALVE SPO
스프링

44.165 CAP, TRANSMISSION FORWARD & REVERSE VALVE SPOOL
캡

44.166 SEAL, TRANSMISSION FORWARD & REVERSE VALVE SPOOL
시일

44.170 COIL, TRANSMISSION CONTROL COVER SOLENOID
코일

44.194 LOCATOR, CONTROL COVER
로케이터

44.197 BLEEDER, CONTROL VALVE SLAVE CYLINDER
블리더

44.198 SEAT, SLAVE CYLINDER BRAKE LINE
시트

44.199 NUT, SLAVE CYLINDER ADJUSTING
너트

44.212 CARTRIDGE, CONTROL VALVE SHIFT SOLENOID
카트리지


44.213 SPRING, INCHING SPOOL BALANCE- OUTER
스프링

44.214 SPRING, INCHING SPOOL BALANCE- INNER
스프링

44.301 SEAL KIT, SOLENOID VALVE
시일킷

92.616 LOCKWASHER, ACCUMULATOR HOUSING FASTENER
로크와셔

95.082 FASTENER, CONTROL SELECTOR SOLENOID RELAY
패스너



05.095 PLUG, CONVERTER HOUSING OIL PASSAGE
플러그

05.114 FASTENER, CONVERTER TO CASE
패스너

05.119 FASTENER, CONVERTER CASE
패스너

05.120 FASTENER, CONVERTER TO CASE
패스너

05.121 FASTENER, CONVERTER TO CASE
패스너


05.144 SEAL, CONVERTER PUMP SUPPLY LINE FITTING
시일

05.167 FASTENER, CONVERTER PUMP INLET LINE
패스너

05.168 LINE, CONVERTER PUMP INLET
라인

05.525 PLUG, TRANSMISSION CASE
플러그

05.530	FITTING, TORQUE CONVERTER INLET LINE 피팅
06.377	PLUG, TRANSMISSION SUMP OIL LEVEL 플러그
06.386	ADAPTOR, CONVERTER END 어댑터
06.447	PLUG, TRANSMISSION CASE 플러그
06.456	GASKET, TRANSMISSION ADAPTOR 가스켓
06.471	HOUSING, CONVERTER 하우징
06.506	SEAL, CONVERTER HOUSING TO CASE-INNER 시일
06.522	SEAL AND GASKET KIT, TRANSMISSION 시일과가스켓킷
06.550	COVER, TRANSMISSION HOUSING INSPECTION 커버
06.656	LINE, TRANS VALVE PRESS PUMP INLET 라인
06.657	SEAL, TRANS VALVE PRESS PUMP INLET LINE 시일
06.954	DOWEL, TRANSMISSION CASE TO CONVERTER 다월
08.037	CASE, TRANSMISSION 케이스
13.010	CONTROL, CONVERTOR TEMPERATURE INDICATOR 컨트롤
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
91.126	DOWEL RING, FLYWHEEL HOUSING FASTENER 다월링
91.291	LOCKWASHER, CONVERTER TO CASE FASTENER 로크와셔
95.783	NUT, CONVERTER OIL SUCTION TUBE FASTENER 너트



06.310 SEAL, FORWARD CLUCH PISTON INNER
시일

06.311 SEAL, FORWARD CLUTCH PISTON OUTER
시일

06.312 PISTON, FORWARD CLUTCH
피스톤

06.314 DISC, FORWARD CLUTCH INNER
디스크

06.315 DISC, FORWARD CLUTCH OUTER
디스크


06.317 PLATE, FORWARD CLUTCH DISC END
플레이트

06.318 RING, FORWARD CLUTCH DISC END PLATE RET
링


06.372 SPRING, REVERSE CLUTCH DISC RELEASE
스프링

06.393 WASHER KIT, FORWARD CLUTCH CYLINDER THRUST
와셔킷

06.434	SHAFT & GEAR, CLUTCH DRIVE 샤프트와기어
06.521	BALL, INCHING RELIEF VALVE 볼
06.556	DISTRIBUTOR, TRANSMISSION DIRECTION SEL OIL 디스트리뷰터
06.557	SEAL, TRANSMISSION DIRECTION SELECTOR OIL DIST 시일
06.573	BEARING, FORWARD GEAR 베어링
06.574	GEAR & BEARING FORWARD 기어와베어링
06.579	FASTENER, REVERSE CLUTCH SPRING RETAINER 패스너
06.580	THRUST WASHER, REVERSE CLUTCH HUB & DRUM 트러스트와셔
06.582	GEAR & BEARING, REVERSE 기어욱뷩어링
06.949	RETAINER, CLUTCH OIL DISTRIBUTION SLEEVE 리테이너
06.975	BEARING, REVERSE CLUTCH HUB (AXLE END) 베어링
06.977	BEARING, REVERSE CLUTCH HUB (ENGINE END) 베어링
20.100	TRANSAXLE ASSEMBLY 트랜스액슬
44.181	BEARING, CLUTCH SHAFT THRUST 베어링
44.294	BEARING, REVERSE CLUTCH GEAR 베어링
44.353	PLUG, CLUTCH DRIVE SHAFT AND GEAR 플러그



05.007	FASTENER, CONVERTER TO FLYWHEEL 패스너
05.135	SPACER, CONVERTER PILOT SHAFT 스페이서
07.007	FASTENER, TRANSMISSION MOUNTING BRACKET LH 패스너
07.013	FASTENER, TRANSMISSION TO ENGINE 패스너
07.014	FASTENER, TRANSMISSION TO ENGINE 패스너
08.183	VENT, TRANSMISSION CASE 벤트
20.100	TRANSAXLE ASSEMBLY 트랜스액슬



10.015 FITTING, CONVERTOR SUMP INLET
피팅

10.017 LINE, COOLER OUTLET
라인

10.021 FASTENER, COOLER OUTLET LINE CLAMP
패스너

10.042 FASTENER, COOLER INLET LINE CLAMP
패스너

10.055 FITTING, COOLER OUTLET
피팅


10.056 FITTING, COOLER OUTLET
피팅

10.084 FITTING, COOLER INLET LINE
피팅

10.140 CLAMP, COOLER LINE
클램프

10.182 SEAL, TRANSMISSION COOLER OUTLET LINE FITTING
시일

10.187	LINE, TRANSMISSION COOLER INLET 라인
10.188	LINE, TRANSMISSION COOLER OUTLET 라인
10.215	VALVE, TRANSMISSION COOLER LINE RELIEF 밸브
10.231	FITTING, OIL COOLING LINES 피팅



11.233 INDUCTOR, DISTRIBUTOR ELECTRONIC TIMER
인덕터

11.258 HOUSING, DISTRIBUTOR
하우징

11.300 DISTRIBUTOR ASSEMBLY
디스트리뷰터

11.311 PLATE, DISTRIBUTOR BREAKER
플레이트

11.317 COVER - GASKET - SEAL, DISTRIBUTOR HOUSING
커버

11.318 ROTOR, DISTRIBUTOR
로터

11.319 CAP, DISTRIBUTOR
캡

11.328 SEAL, DISTRIBUTOR HOUSING
시일


11.350 ASSEMBLY, DISTRIBUTOR VACUUM ADVANCE
진공어드밴스

11.412 IGNITER KIT, DISTRIBUTOR
시동킷

11.413 PICKUP KIT, DISTRIBUTOR
픽업킷

11.414 CONNECTOR KIT, DISTRIBUTOR
커넥터킷

11.415 SCREW SET, DISTRIBUTOR
스크류셋



11.020 MOTOR ASSEMBLY, STARTING
모터

11.022 HOUSING & BUSHING, DRIVE END
하우징와부싱

11.025 LEVER, DRIVE SHIFT FORK
레버

11.027 SWITCH, SOLENOID
스위치

11.031 COLLAR, PINION STOP
칼라


11.032 ARMATURE, STARTING MOTOR
아마츄어

11.033 DRIVE ASSEMBLY, STARTING MOTOR
드라이브

11.034 FASTENER, STARTING MOTOR
패스너

11.042 BRUSH HOLDER & BRUSH (KIT)
브러쉬홀더

11.045	FRAME, COMMUTATOR END 프레임
11.046	FASTENER, THRU 패스너
11.065	BEARING, COMMUTATOR END FRAME 베어링
11.068	GASKET, STARTER MOTOR CENTER BEARING 가스켓
11.127	BALL, CRANKING MOTOR DRIVE 볼
11.172	BEARING, CRANKING MOTOR CENTER 베어링
11.180	KIT, CRANKING MOTOR ARMATURE SHAFT 킷
11.185	GEAR, PINION SHAFT DRIVE 기어
11.187	GEAR, STARTER REDUCTION INTERNAL 기어
11.188	GEAR, STARTER REDUCTION PINION 기어
11.189	CLUTCH, STARTER OVERRUNNING 클러치
11.399	HOUSING ASSEMBLY, CRANKING MOTOR 하우징



00.000 PRODUCTION ENGINE ASSEMBLY
엔진

11.201 COIL, IGNITION
코일

11.204 FASTENER, COIL STRAP
패스너

11.205 BRACKET, COIL MOUNTING
브라켓

11.206 FASTENER, COIL MOUNTING BRACKET
패스너


11.250 SPARK PLUG
스파크

14.031 KIT, HIGH TENSION WIRES & BOOTS
킷

15.386 BRACKET, SPARK PLUG WIRES
브라켓

15.387 BRACKET, SPARK PLUG WIRES
브라켓

15.546	SUPPORT, SPARK PLUG WIRES 서포트
15.547	SUPPORT, SPARK PLUG WIRES 서포트
15.549	SUPPORT, SPARK PLUG WIRES 서포트
15.555	WIRE, IGNITION LEAD 와이어
60.522	HARNESS, COIL TO DISTRIBUTOR 하네스



12.200 ALTERNATOR ASSEMBLY
알터네이터

12.201 FASTENER, ALTERNATOR PULLEY TO SHAFT
패스너

12.202 PULLEY, ALTERNATOR
풀리

12.205 FRAME, ALTERNATOR DRIVE END
프레임

12.209 BEARING, ALTERNATOR DRIVE END
베어링


12.212 FASTENER, ALTERNATOR DRIVE END BEARING RETAINER PL
패스너

12.214 ROTOR ASSEMBLY, ALTERNATOR
로터

12.216 STATOR ASSEMBLY, ALTERNATOR
스테이터

12.228 BEARING, ALTERNATOR SLIP RING FRAME END
베어링

12.230	FRAME, ALTERNATOR SLIP RING END 프레임
12.235	BRUSH KIT, ALTERNATOR 브러쉬킷
12.285	FASTENER, THROUGH 패스너
12.316	REGULATOR, ALTERNATOR VOLTAGE OUTPUT 레귤레이터
12.317	RECTIFIER ASSEMBLY, ALTERNATOR 정류기
93.555	FASTENER, ALTERNATOR RECTIFIER HOUSING COVER 패스너



BATTERY MOUNTING **12-031**

12.009 SUPPORT, BATTERY
서포트

12.010 BATTERY
배터리

12.011 CLAMP, BATTERY HOLD DOWN
클램프

12.012 STUD, BATTERY HOLD DOWN
스터드

12.013 FASTENER, BATTERY HOLD DOWN (AT CLAMP)
패스너

12.049 FASTENER, BATTERY SUPPORT
패스너

12.450 COVER, BATTERY HEAT SHIELD INSULATOR
*

12.451 FASTENER, BATTERY INSULATOR COVER
*

12.725 INSULATOR, BATTERY HEAT SHIELD
J抵떱툚謙

14.025 CABLE, BATTERY TO STARTER
케이블


14.026 CABLE, BATTERY GROUND
케이블

14.042 FASTENER, BATTERY GROUND CABLE
패스너

14.147 CABLE, BATTERY NEGATIVE
케이블

15.604 FASTENER, BATTERY NEGATIVE CABLE
패스너

18.088 CLAMP, BATTERY CABLE
클램프



INSTRUMENT PANEL **13-035**


13.000	PANEL, INSTRUMENT CLUSTER 판넬
13.023	METER, TRUCK HOUR 미터
13.040	BULB, PANEL LIGHT 전구
13.343	SWITCH, WARNING LIGHT/PREHEAT 스위치
17.900	SWITCH, DIRECTION CONTROL 스위치
39.500	PANEL, INSTRUMENT 판넬
39.510	HOUSING, INSTRUMENT PANEL 하우징
60.246	HOUSING, PANEL GAUGE CLUSTER 하우징
60.812	SWITCH, DASH PANEL ON-OFF 스위치

60.834 SWITCH, CLUSTER AUTO MANUAL
스위치

60.837 GLASS, CLUSTER WINDOW
글래스

93.937 FASTENER, PANEL GAUGE CLUSTER LENS
패스너

94.668 RETAINER, INSTRUMENT PANEL SIGNAL CLUSTER
리테이너




STROBE LIGHT 13-146

13.332 ASSEMBLY, WARNING LIGHT
경고등

13.333 BULB, WARNING LIGHT
전구

60.821 GLOBE, STROBE LIGHT
글로브

60.822 BASE, STROBE LIGHT
베이스




STROBE LIGHT MOUNTING **13-162**

13.330 BRACKET, WARNING LIGHT
브라켓

13.331 FASTENER, WARNING LIGHT BRACKET
패스너

13.332 ASSEMBLY, WARNING LIGHT
경고등




BACK-UP ALARM INSTALLATION **13-228**

13.681 FASTENER, WARNING DEVICE
패스너

42.001 WARNING DEVICE, AUDIBLE (AIR OPER)
경보장치


42.011 CLIP, AUDIBLE WARNING DEVICE CABLE
클립

■ INDICATES AN ASSEMBLY HAVING SERVICEABLE COMPONENTS ILLUSTRATED ELSEWHERE




CLUSTER GROUP **13-238**

14.339	WIRE, ELECTRICAL INSTALLATION 와이어
39.500	PANEL, INSTRUMENT 판넬
39.501	FASTENER, INSTRUMENT PANEL 패스너



KEY SWITCH GROUP **13-240**

13.047	SWITCH, CIRCUIT LOCKING 스위치
14.352	FUSE, CONTROL CIRCUIT 퓨즈
15.448	DIODE, HARNESS 다이오드
15.640	WIRING HARNESS, MACHINE COWL 와이어하네스
60.260	KEY, CIRCUIT LOCKING SWITCH 키
65.289	BODY, FUSE BOX *
65.832	COVER, FUSE BOX 커버
95.009	FASTENER, FUSE BOX MOUNTING 패스너



11.001 RELAY, STARTER
릴레이

11.002 FASTENER, STARTER RELAY
패스너

13.003 HORN
혼

13.004 FASTENER, HORN MOUNTING BRACKET
패스너

13.011 CONTROL, ENGINE TEMPERATURE INDICATOR
컨트롤


13.270 HEADLAMP, ADJUSTABLE
헤드램프

14.114 HARNESS, MACHINE WIRING
하네스

14.351 BRACKET, CONTROL CIRCUIT FUSE HOLDER
브라켓

14.612 CONNECTOR, WARNING LIGHT WIRE
커넥터

14.690	WIRE, HORN FILTER 와이어
15.433	GROMMET, CONTROL CIRCUIT WIRING HARNESS 그로멧
15.436	HARNESS, RH HEADLAMP WIRING 하네스
15.437	HARNESS, HEADLAMP WIRING 하네스
15.447	DIODE, HARNESS 다이오드
17.281	BLOCK, MAIN FUSE 블록
17.283	FASTENER, MAIN FUSE BLOCK 패스너
18.000	CLIP, WIRING HARNESS 클립
18.001	FASTENER, WIRING HARNESS CLIP 패스너
18.002	CLIP, WIRING HARNESS 클립
60.324	BULB, HEADLAMP 전구
60.449	SPACER, HEAD LAMP BRACKET MOUNTING 스페이서
60.755	FUSE, WIRING HARNESS 40AMP 퓨즈
60.756	FUSE, WIRING HARNESS 60AMP 퓨즈
60.797	GROMMET, REAR ACCESSORY WIRE 그룽멧
65.477	BRACKET, POWER FUSE MOUNTING 브라켓
96.200	FASTENER, WIRING HARNESS GROUND 패스너



13.001 RELAY, HORN
릴레이

13.062 SWITCH, LIGHT
스위치

13.063 KNOB, LIGHT SWITCH
노브

13.472 RELAY, MAIN POWER
*

13.655 SWITCH, TURN INDICATOR
스위치


13.980 SWITCH, PARK/SAFETY INTERLOCK
스위치

15.710 RELAY, ELECTRICAL
릴레이

15.714 FLASHER, UNIT
플래셔

15.723 FASTENER, ELECTRICAL RELAY
패스너


17.930	KNOB, FORWARD & REVERSE LEVER 노브
18.009	FASTENER, HARNESS CLIP 패스너
18.010	CLIP, HARNESS 클립
18.011	FASTENER, HARNESS CLIP 패스너
18.012	CLIP, WIRE HARNESS 클립
39.570	COVER ASSEMBLY, DASH 커버
39.571	FASTENER, DASH COVER 패스너
44.250	DIRECTIONAL CONTROL ASSEMBLY 방향컨트롤
60.657	SEAL, INSTRUMENT PANEL 시일
95.989	FASTENER, RELAY MOUNTING 패스너
97.156	FASTENER, DASH COVER 패스너



STATIC STRAP **14-438**

39.417 GROUND STRAP, ELECTRIC TRUCK
접지케이블

39.418 FASTENER, ELECTRIC TRUCK GROUND STRAP
패스너



06.964 RING, OUTPUT SHAFT GEAR LOCATING
링

09.005 GEAR, OUTPUT
기어

20.100 TRANSAXLE ASSEMBLY
트랜스액슬

20.201 SHIM, DIFF BRG CARRIER TO AXLE HOUSING
심

20.203 NUT, DIFFERENTIAL PINION COMPANION FLANGE
너트


20.232 CONE, DIFFERENTIAL PINION OUTER BEARING
콘

20.233 CUP, DIFFERENTIAL PINION OUTER BEARING
컵

20.238 SHIM KIT, DIFFERENTIAL PINION BEARING CAGE
심


20.240 SPACER, DIFFERENTIAL PINION BEARING
스페이서

20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링
20.264	CONE, DIFFERENTIAL BEARING 콘
20.265	CUP, DIFFERENTIAL BEARING 컵
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.281	FASTENER, DIFF SIDE PINION PIN 패스너
20.282	SPIDER, DIFFERENTIAL PINION 스파이더
20.283	GEAR, DIFFERENTIAL SIDE PINION 기어
20.284	WASHER, DIFF SIDE PINION GEAR THRUST 와셔
20.285	GEAR, DIFFERENTIAL SIDE 기어
20.286	WASHER, DIFFERENTIAL SIDE GEAR THRUST 와셔
20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스와기어
93.229	WASHER, DIFFERENTIAL CASE TO RING GEAR FASTENER 와셔



08.260	TUBE, TRAN OIL LEVEL DIPSTICK SUPPORT 튜브	20.575	CUP, DRIVE AXLE HUB OUTER BEARING 컵
08.261	DIPSTICK, TRANSMISSION OIL LEVEL 딥스틱	20.581	HUB ASSEMBLY, DRIVE AXLE 허브
20.100	TRANSAXLE ASSEMBLY 트랜스액슬	20.586	SHAFT, DRIVE AXLE 샤프트
20.101	HOUSING, TRANSAXLE WHEEL END - LH 하우징	20.602	SEAL, DRIVE AXLE HUB INNER OIL 시일
20.102	HOUSING, TRANSAXLE WHEEL END - RH 하우징	20.608	CONE, DRIVE AXLE HUB INNER BEARING 콘
20.244	SEAL, DIFFERENTIAL OIL LEVEL DIPSTICK SUPPORT 시일	20.612	CUP, DRIVE AXLE HUB INNER BEARING 컵
20.512	SHIM, DRIVE AXLE HUB BEARING 심	20.627	VENT, DIFFERENTIAL & AXLE 벤트
20.513	RETAINER, DRIVE AXLE HUB BEARING 리테이너	20.693	COVER, BRAKE ADJUSTER 커버
20.514	LOCKPLATE, DRIVE AXLE HUB BEARING RETAINER 로크플레이트	22.204	CLIP, BRAKE CABLE 클립
20.539	SUPPORT, DRIVE AXLE SPINDLE (RH) 서포트	22.481	SPACER, WHEEL BRAKE ASSEMBLY 스페이서
20.546	FASTENER, DRIVE AXLE END 패스너	22.548	SEAL, PARKING BRAKE CABLE 시일
20.547	FASTENER, DRIVE AXLE END 패스너	23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
20.554	FASTENER, DRIVE AXLE HUB CAP 패스너	23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
20.570	FASTENER, DRIVE WHEEL MOUNTING 패스너	23.246	FASTENER, BRAKE ASSEMBLY 패스너
20.571	CONE, DRIVE AXLE HUB OUTER BEARING 콘	23.272	CABLE, PARKING BRAKE 케이블

23.730	FASTENER, BRAKE ASSEMBLY 패스너
90.359	LOCKWASHER, DRIVE AXLE END FASTENER 로크와셔
90.361	LOCKWASHER, BRAKE ASSEMBLY FASTENER 로크와셔
90.661	LOCKWASHER, DRIVE AXLE HUB CAP FASTENER 로크와셔
90.667	NUT, WHEEL BRAKE ASSEMBLY FASTENER 너트
94.940	FASTENER, DRIVE AXLE HUB BEARING RETAINER 패스너
95.786	FASTENER, BRAKE ADJUSTOR ACCESS HOLE COVER 패스너
95.787	LOCKWASHER, BRAKE ADJUSTOR ACCESS HOLE COVER FAS 로크와셔



06.964 RING, OUTPUT SHAFT GEAR LOCATING
링

09.005 GEAR, OUTPUT
기어

20.100 TRANSAXLE ASSEMBLY
트랜스액슬

20.201 SHIM, DIFF BRG CARRIER TO AXLE HOUSING
심

20.203 NUT, DIFFERENTIAL PINION COMPANION FLANGE
너트


20.232 CONE, DIFFERENTIAL PINION OUTER BEARING
콘

20.233 CUP, DIFFERENTIAL PINION OUTER BEARING
컵

20.238 SHIM KIT, DIFFERENTIAL PINION BEARING CAGE
심

20.240 SPACER, DIFFERENTIAL PINION BEARING
스페이서


20.248	RING GEAR & PINION SET, DIFFERENTIAL 링
20.252	BEARING, DIFFERENTIAL PINION INNER 베어링
20.264	CONE, DIFFERENTIAL BEARING 콘
20.265	CUP, DIFFERENTIAL BEARING 컵
20.279	FASTENER, DIFFERENTIAL CASE TO RING GEAR 패스너
20.281	FASTENER, DIFF SIDE PINION PIN 패스너
20.282	SPIDER, DIFFERENTIAL PINION 스파이더
20.283	GEAR, DIFFERENTIAL SIDE PINION 기어
20.284	WASHER, DIFF SIDE PINION GEAR THRUST 와셔
20.285	GEAR, DIFFERENTIAL SIDE 기어
20.286	WASHER, DIFFERENTIAL SIDE GEAR THRUST 와셔
20.287	CASE & GEAR ASSEMBLY, DIFFERENTIAL 케이스와기어
93.229	WASHER, DIFFERENTIAL CASE TO RING GEAR FASTENER 와셔



23.030 DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠타이어

23.335 FASTENER, DRIVE WHEEL
패스너


■INDICATES AN ASSEMBLY HAVING SERVICEABLE COMPONENTS ILLUSTRATED ELSEWHERE




STEER WHEEL & TIRE MOUNTING **22-014**

23.026 FASTENER, STEER WHEEL
패스너

23.031 STEER WHEEL AND TIRE ASSEMBLY
휠




22.989	TIRE ASSEMBLY, DRIVE *
23.009	RIM ASSEMBLY, DRIVE WHEEL 림
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠타이어



DRIVE WHEEL & TIRE (SOLID TYPE) **22-026**


22.989	TIRE ASSEMBLY, DRIVE *
23.027	OUTER HALF, DRIVE WHEEL 아웃하프
23.028	INNER HALF, DRIVE WHEEL 인너하프
23.029	FASTENER, DRIVE WHEEL ASSEMBLY 패스너
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠타이어
23.393	FASTENER, DRIVE WHEEL 패스너



STEER WHEEL & TIRE (SOLID TYPE) **22-027**

22.990	TIRE ASSEMBLY, STEER *
23.031	STEER WHEEL AND TIRE ASSEMBLY 휠
23.033	FASTENER, STEER WHEEL 패스너
23.034	OUTER HALF, STEER WHEEL 아웃하프
23.035	INNER HALF, STEER WHEEL 인너하프
23.036	FASTENER, STEER WHEEL ASSEMBLY 패스너

■INDICATES AN ASSEMBLY HAVING SERVICEABLE COMPONENTS ILLUSTRATED ELSEWHERE



DUAL DRIVE TIRE MOUNTING **22-033**

22.809 SPACER, DRIVE WHEEL OFFSET MOUNTING
스페이서

23.012 SPACER, DRIVE WHEEL DUAL RIM
스페이서

23.017 EXTENSION, DRIVE WHEEL VALVE
익스텐션

23.030 DRIVE WHEEL AND TIRE ASSEMBLY
드라이브휠타이어

23.046 EXTENSION, DRIVE WHEEL
익스텐션


23.335 FASTENER, DRIVE WHEEL
패스너

23.393 FASTENER, DRIVE WHEEL
패스너


38.780 FENDER, RIGHT HAND FRONT
펜더

38.790 FENDER, LEFT HAND FRONT
펜더


39.632 FASTENER, FENDER SUPPORT
패스너



22.989	TIRE ASSEMBLY, DRIVE *
23.016	TIRE, DRIVE WHEEL 타이어
23.018	TUBE, DRIVE WHEEL 튜브
23.019	FLAP, DRIVE WHEEL TUBE 플랩
23.027	OUTER HALF, DRIVE WHEEL 아웃하프
23.028	INNER HALF, DRIVE WHEEL 인너하프
23.029	FASTENER, DRIVE WHEEL ASSEMBLY 패스너
23.030	DRIVE WHEEL AND TIRE ASSEMBLY 드라이브휠타이어
23.393	FASTENER, DRIVE WHEEL 패스너



22.990	TIRE ASSEMBLY, STEER *
23.006	TIRE, STEER WHEEL 타이어
23.007	TUBE, STEER WHEEL 튜브
23.008	FLAP, STEER WHEEL 플랩
23.031	STEER WHEEL AND TIRE ASSEMBLY 휠
23.033	FASTENER, STEER WHEEL 패스너
23.034	OUTER HALF, STEER WHEEL 아웃하프
23.035	INNER HALF, STEER WHEEL 인너하프
23.036	FASTENER, STEER WHEEL ASSEMBLY 패스너



22.280 SPRING, BRAKE SHOE GUIDE PIN
스프링

22.325 FASTENER, BRAKE SHOE ADJUSTOR
패스너

22.486 SEAT, PARKING BRAKE OPERATING ARM ANTI-RATTLE SPRI
시트

23.048 SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE
스프링

23.215 CYLINDER ASSEMBLY, RH BRAKE
실린더


23.216 REPAIR KIT, BRAKE CYLINDER (LH)
리페어킷

23.223 BLEEDER, BRAKE WHEEL CYLINDER
블리더

23.237 COVER, RH BRAKE ADJUSTOR
커버

23.243 PLATE, RH BRAKE BACKING
플레이트

23.244	BRAKE ASSEMBLY, RH DRIVE WHEEL 브레이크
23.247	SHOE SET, BRAKE LINING 슈
23.259	FASTENER, RH WHEEL CYLINDER 패스너
23.262	SPRING, BRAKE SHOE RETURN 스프링
23.292	ANCHOR, BRAKE SHOE 앵커
23.293	RING-RETAINING, BRAKE SHOE ANCHOR PIN 링
23.475	ADJUSTOR, BRAKE SHOE 어드져스터
23.762	ARM, PARKING BRAKE OPERATING 암
24.349	SPRING KIT, BRAKE SHOE 스프링킷



22.280 SPRING, BRAKE SHOE GUIDE PIN
스프링

22.325 FASTENER, BRAKE SHOE ADJUSTOR
패스너

22.486 SEAT, PARKING BRAKE OPERATING ARM ANTI-RATTLE SPRI
시트

23.048 SPRING, PARKING BRAKE OPERATING ARM ANTI-RATTLE
스프링

23.214 CYLINDER ASSEMBLY, LH BRAKE
실린더


23.216 REPAIR KIT, BRAKE CYLINDER (LH)
리페어킷

23.222 SCREW, BRAKE CYLINDER BLEEDER (LH)
스크류

23.237 COVER, RH BRAKE ADJUSTOR
커버

23.242 PLATE, LH BRAKE BACKING
플레이트

23.245	BRAKE ASSEMBLY, LH DRIVE WHEEL 브레이크
23.247	SHOE SET, BRAKE LINING 슈
23.249	SPRING, LH BRAKE RETURN 스프링
23.258	FASTENER, LH WHEEL CYLINDER 패스너
23.262	SPRING, BRAKE SHOE RETURN 스프링
23.292	ANCHOR, BRAKE SHOE 앵커
23.293	RING-RETAINING, BRAKE SHOE ANCHOR PIN 링
23.475	ADJUSTOR, BRAKE SHOE 어드져스터
23.762	ARM, PARKING BRAKE OPERATING 암
24.349	SPRING KIT, BRAKE SHOE 스프링킷



22.131 BOOT, INCHING MASTER CYLINDER
부트


23.800 CYLINDER ASSEMBLY, INCHING MASTER COMPLETE
실린더

23.811 REPAIR KIT, INCHING MASTER CYLINDER
리페어킷


24.319 FITTING,INCHING MASTER CYLINDER INLET
피팅

24.326 BOLT, INCHING MASTER CYLINDER INLET FITTING
볼트

24.327 SEAL, INCHING MASTER CYLINDER INLET FITTING
시일



08.050	PLUG, BRAKE LEVER HOLE 플러그
23.266	FASTENER, PARKING BRAKE CABLE CLAMP 패스너
23.267	LEVER, PARKING BRAKE 레버
23.271	FASTENER, PARKING BRAKE LEVER 패스너
23.273	CLAMP, PARKING BRAKE LEVER TO CABLE 클램프
23.389	RETAINER, PARKING BRAKE CABLE 리테이너
92.694	WASHER, PARKING BRAKE LEVER FASTENER 와셔



22.026 ROD END, BRAKE PEDAL LINKAGE
로드엔드

22.799 FASTENER, BRAKE PEDAL PIVOT BRACKET
패스너

22.858 FASTENER, BRAKE MASTER CYLINDER ACTUATING ROD ADJU
패스너

23.051 FASTENER, MASTER CYLINDER MOUNTING BRACKET
패스너

23.098 PEDAL, AUX BRAKE
페달

23.100 PEDAL, BRAKE
페달

23.101 SHAFT, BRAKE PEDAL
샤프트

23.114 PAD & FASTENER, BRAKE PEDAL
패드와패스너

23.136 SPRING, BRAKE PEDAL RETURN
스프링

23.145 FASTENER, BRAKE PEDAL SHAFT
패스너

23.150 CYLINDER ASSEMBLY, BRAKE MASTER COMPLETE
실린더

23.157 FASTENER, BRAKE MASTER CYLINDER ATTACHING
패스너

23.160 ROD, PUSH
로드

23.434 BRACKET, BRAKE PEDAL PIVOT
브라켓

23.435 FASTENER, BRAKE PEDAL PIVOT BRACKET
패스너

23.538 ARM, BRAKE LINKAGE PIVOT
암

23.589 RETAINER, BRAKE ACTUATING LEVER
리테이너


23.665 SPRING, INCHING PEDAL RETURN
스프링

23.786 FASTENER, INCHING BRAKE PEDAL
패스너

23.800 CYLINDER ASSEMBLY, INCHING MASTER COMPLETE EMBREAGEM
실린더

92.026 RETAINER, BRAKE MASTER CYLINDER ACTUATING ROD PIN
리테이너

94.699 FASTENER, BRAKE MASTER CYLINDER SUPPORT BRACKET
패스너



BRAKE LINES **23-467**

13.142 SWITCH, BRAKE INTERLOCK
스위치

22.338 CLAMP, BRAKE FLUID RESERVOIR
클룻프

22.452 CLAMP, BRAKE MASTER CYLINDER FILLER LINE
클램프

22.528 BLEEDER, BRAKE LINES ADAPTOR
블리더

22.604 CLAMP, BRAKE FLUID RESERVOIR LINE
클램프


23.186 LINE, BRAKE MASTER CYLINDER OUTLET
라인

23.199 FASTENER, BRAKE LINE TEE
패스너

23.207 LINE, LH DRIVE WHEEL BRAKE CYLINDER TO TEE
라인

23.208 LINE, RH DRIVE WHEEL BRAKE CYLINDER TO TEE
라인

23.616	LINE, BRAKE MASTER CYLINDER OUTLET 라인
23.792	RESERVOIR, BRAKE FLUID 리저버
23.795	FITTING, BRAKE MASTER CYLINDER INLET 피팅
23.901	FASTENER, SEAT BRAKE ACTUATING CYLINDER 패스너
23.921	LINE, RESERVOIR OUTLET 라인
23.941	LINE, BRAKE CYLINDER (LH) 라인
23.943	LINE, BRAKE CYLINDER LINE (RH) 라J



STEERING COLUMN MOUNTING **25-044**

25.002 HORN BUTTON KIT
혼버튼킷

25.003 NUT, HANDWHEEL
너트

25.004 HAND WHEEL, STEERING GEAR
핸드휠

25.012 CUSHION, STEERING COLUMN
쿠션

25.018 FASTENER, COLUMN JACKET
패스너


25.030 SHAFT ASSEMBLY, STEERING COLUMN
샤프트

25.034 FASTENER, STEERING GEAR ATTACHING
패스너

25.140 SHAFT & COLUMN ASSEMBLY, POWER STEERING
샤프트와컬럼


25.142 BEARING, STEERING GEAR SHAFT (LOWER)
베어링

25.150	GEAR BOX ASSEMBLY, STEERING 기어박스
25.187	BEARING, STEER SHAFT 베어링
25.219	KNOB, STEERING HAND WHEEL SPINNER 노브
25.269	BEARING, STEERING GEAR SHAFT (UPPER) 베어링
25.356	RETAINER, STEERING SHAFT BEARING 리테이너
25.466	RETAINER, STEERING SHAFT BEARING 리테이너
25.600	SPACER, STEERING COLUMN MOUNTING 스페이서
25.640	LOCKWASHER, HORN CONNECTOR FASTENER 로크와셔
25.841	BUSHING, STEERING GEAR SHAFT 부싱
38.269	FASTENER, STEERING COLUMN SUPPORT 패스너
39.532	GROMMET, STEERING COLUMN 그로멧
92.895	WASHER, STEERING COLUMN SUPPORT FASTENER 와셔
92.896	LOCKWASHER, STEERING COLUMN SUPPORT FASTENER 로크와셔
92.897	NUT, STEERING COLUMN SUPPORT FASTENER 너트



25.388	FITTING-LUB, STEERING ARM PIVOT 피팅	26.141	FASTENER, STEER WHEEL HUB 패스너
25.391	BEARING, STEERING ARM 베어링	26.143	CAP, STEER WHEEL HUB 캡
25.392	FITTING-LUB, STEERING ARM 피팅	26.144	FASTENER, STEER AXLE HUB CAP 패스너
26.000	CYLINDER ASSEMBLY, STEERING 실린더	26.148	KNUCKLE, STEER AXLE (LH) 너트
26.086	FASTENER, STEERING CYLINDER ANCHOR END 패스너	26.170	PLUG - EXPANSION, STEER AXLE KNUCKLE PIN 플러그
26.100	AXLE ASSEMBLY, STEERING 스티어액슬	26.190	SEAL, STEER AXLE KNUCKLE OIL 시일
26.119	AXLE, STEER 액슬	26.239	SEAL, STEER AXLE FORK COVER 시일
26.124	SHIM, STEER AXLE KNUCKLE 심	26.281	RETAINER, STEER AXLE HUB BRG KNUCKLE NUT 리테이너
26.126	ARM, RH STEERING 암	26.347	PIN, STEER ARM 핀
26.130	BEARING, STEER AXLE KNUCKLE PIN 베어링	26.348	LOCATOR, STEER CYLINDER 로케이터
26.131	BEARING, STEER AXLE KNUCKLE PIN LOWER 베어링	26.419	CUP & CONE, STEER WHEEL HUB BEARING (INNER) 컵과콘
26.132	KNUCKLE, STEER AXLE (RH) 너트	26.420	CUP & CONE, STEER WHEEL HUB BEARING (OUTER) 컵과콘
26.136	HUB & CUP, STEER WHEEL 허브와컵	93.700	FASTENER, STEER AXLE KNUCKLE PIN COVER 패스너
26.137	FASTENER, STEER WHEEL 패스너	93.793	WASHER, STEERING ARM PIVOT FASTENER 와셔
26.140	WASHER, STEER WHEEL HUB BEARING THRUST 와셔	94.853	FASTENER, STEER AXLE KNUCKLE PIN 패스너

94.855 RETAINER, STEERING ARM PIN
리테이너




26.000 CYLINDER ASSEMBLY, STEERING
실린더

26.003 SEAL KIT, PISTON ROD
시일킷

26.089 BARREL, STEERING CYLINDER
배럴

26.090 STEER CYLINDER PISTON
룽드욱피스톤

26.093 GLAND, STEERING CYLINDER
그랜드



STEERING LINES **26-280**

28.054 LINE, STEERING GEAR
라인

28.055 FITTING, STEERING GEAR
피팅

28.056 SEAL, STEERING GEAR FITTING
시일

28.272 LINE, STEER CYLINDER INLET
라인

28.397 FITTING, STEERING GEAR LINE
피팅


28.493 LINE, PRESSURE SENSING
라인

28.759 FITTING, STEER VALVE OUTLET PORT
피팅

31.138 FITTING, STEER VALVE OUTLET UPPER PORT
피팅

31.465 SEAL, STEER VALVE OUTLET PORT
시일

31.664	LINE, STEERING CYLINDER ANCHOR PORT 라인
31.665	FITTING, STEERING CYLINDER ANCHOR PORT 피팅
31.779	CLAMP, POWER STEERING LINES 클램프
31.793	CLAMP, POWER STEERING LINES 클램프
94.662	FASTENER, POWER STEERING LINES CLAMP 패스너




STEER AXLE MOUNTING 26-342

26.100 AXLE ASSEMBLY, STEERING
스티어액슬

26.173 FASTENER, SILENT BLOCK TO FRAME (FRONT)
패스너

26.174 SILENT BLOCK, AXLE MOUNTING (REAR)
사일런트블록

26.175 FASTENER, SILENT BLOCK TO FRAME (REAR)
패스너



HYDRAULIC PUMP ASSEMBLY **29-178**


29.028 SEAL KIT, HYDRAULIC UNIT PUMP
시일킷

29.100 PUMP ASSEMBLY, HYDRAULIC
펌프

29.186 SEAL, PUMP SHAFT
시일

29.198 FASTENER, PUMP HOUSING
패스너


■INDICATES AN ASSEMBLY HAVING SERVICEABLE COMPONENTS ILLUSTRATED ELSEWHERE



HYDRAULIC SUMP **29-215**

27.009	VALVE ASSEMBLY, HYDRAULIC PRIORITY 벨브
29.386	LINE, SUMP BREATHER 라인
29.738	FILTER ASSEMBLY, HYDRAULIC SUMP 필터
29.766	COVER, SUMP TANK 커버
29.767	SEAL, SUMP TANK COVER 시일
29.768	FASTENER, SUMP TANK COVER 패스너
29.781	CLAMP, SUMP BREATHER LINE 클램프
29.786	FASTENER, SUMP BREATHER 패스너
29.788	BREATHER, SUMP 브리더

29.798	SCREEN, HYDRAULIC SUMP PRE FILTER 스크린
29.799	ELEMENT, SUMP BREATHER 엘리먼트
29.809	DIPSTICK, SUMP LEVEL 딥스틱
33.018	FASTENER, FLOW VALVE 패스너



HYDRAULIC RETURN LINES **29-244**

28.033 FITTING, SUMP RETURN
피팅

28.506 LINE, SUMP RETURN
라인

31.001 LINE, SUMP OUTLET
라인


31.041 LINE, VALVE DISCHARGE
라인

31.163 CLAMP, SUMP RETURN LINE
클램프

31.386 LINE, VALVE TO SUMP RETURN
라인

31.387 CLAMP, MAIN VALVE TO SUMP LINE
클램프

31.388 LINE, VALVE SUMP RETURN
라인




29.100 PUMP ASSEMBLY, HYDRAULIC
펌프

29.106 FASTENER, PUMP TO PLATE
패스너

29.146 GASKET & SEAL KIT, PUMP
가스켓과시일


29.150 GASKET, HYDRAULIC PUMP MOUNTING
가스켓



HYDRAULIC CONTROL VALVE - 2 SPOOL **30-512**

30.000	VALVE ASSEMBLY, HYDRAULIC 벨브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.107	FASTENER, VALVE THRU 패스너
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 시일킷
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 시일킷
30.530	FASTENER, VALVE THRU 패스너
30.715	FASTENER, VALVE THRU 패스너
30.762	END COVER, HYDRAULIC VALVE 엔드커버
49.113	LIFT SECTION, HYDRAULIC VALVE 리프트섹션

49.114	TILT SECTION, HYDRAULIC VALVE 틸트섹션
49.196	SPOOL SEAL KIT, LIFT SECTION 스풀실킷
49.197	SPOOL SEAL KIT, TILT SECTION 스풀실킷



30.000	VALVE ASSEMBLY, HYDRAULIC 벨브
30.067	RELIEF VALVE KIT, VALVE INLET SECTION 릴리프밸브
30.107	FASTENER, VALVE THRU 패스너
30.406	SEAL KIT, HYDRAULIC VALVE (LIFT) 시일킷
30.507	SEAL KIT, HYDRAULIC VALVE (TILT) 시일킷
30.530	FASTENER, VALVE THRU 패스너
30.714	SEAL KIT, HYDRAULIC VALVE SECTION (AUX) 시일킷
30.715	FASTENER, VALVE THRU 패스너
30.762	END COVER, HYDRAULIC VALVE 엔드커버

49.113 LIFT SECTION, HYDRAULIC VALVE
리프트섹션


49.114 TILT SECTION, HYDRAULIC VALVE
틸트섹션

49.115 AUX SECTION, HYDRAULIC VALVE
보조섹션

49.196 SPOOL SEAL KIT, LIFT SECTION
스풀실킷

49.197 SPOOL SEAL KIT, TILT SECTION
스풀실킷

49.198 SPOOL SEAL KIT, AUX SECTION
스풀실킷



30.000 VALVE ASSEMBLY, HYDRAULIC
벨브

30.067 RELIEF VALVE KIT, VALVE INLET SECTION
릴리프밸브

30.107 FASTENER, VALVE THRU
패스너

30.250 SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
시일킷

30.406 SEAL KIT, HYDRAULIC VALVE (LIFT)
시일킷

30.507 SEAL KIT, HYDRAULIC VALVE (TILT)
시일킷

30.530 FASTENER, VALVE THRU
패스너

30.714 SEAL KIT, HYDRAULIC VALVE SECTION (AUX)
시일킷

30.715 FASTENER, VALVE THRU
패스너

30.762 END COVER, HYDRAULIC VALVE
엔드커버

49.113 LIFT SECTION, HYDRAULIC VALVE
리프트섹션

49.114 TILT SECTION, HYDRAULIC VALVE
틸트섹션

49.115 AUX SECTION, HYDRAULIC VALVE
보조섹션


49.179 AUX SECTION, HYDRAULIC VALVE
보조섹션

49.196 SPOOL SEAL KIT, LIFT SECTION
스풀실킷

49.197 SPOOL SEAL KIT, TILT SECTION
스풀실킷

49.198 SPOOL SEAL KIT, AUX SECTION
스풀실킷

49.199 SPOOL SEAL KIT, AUX SECTION
스풀실킷




HYDRAULIC VALVE MOUNTING **30-614**

30.000	VALVE ASSEMBLY, HYDRAULIC 벨브	30.952	DUST CAP, PRESSURE GAUGE PORT FITTING 더스트캡
30.033	FASTENER, HYDRAULIC VALVE MOUNTING 패스너	31.480	PLUG, PRESSURE GAUGE PORT 플러그
30.087	PIN, VALVE CONTROL LEVER PIVOT 핀	37.114	FASTENER, VALVE LINKAGE ACCESS COVER 패스너
30.088	FASTENER, VALVE CONTROL LEVER PIVOT PIN 패스너	37.374	COVER, HYDRAULIC VALVE 커버
30.089	LEVER, LIFT CONTROL 레버	39.556	COVER, VALVE LINKAGE ACCESS 커버
30.090	LEVER, TILT CONTROL 레버	39.572	COVER, AUXILIARY VALVE LEVER HOLE 커버
30.094	KNOB, LIFT CONTROL LEVER 노브	49.042	CAP, TILT CONTROL LEVER 캡
30.097	KNOB, TILT CONTROL LEVER 노브	49.081	CAP, LIFT CONTROL LEVER 캡
30.146	BRACKET, CONTROL LINKAGE LOWER 브라켓	49.124	CAP, AUXILIARY CONTROL LEVER 캡
30.196	FASTENER, SPOOL CENTERING SPRING GUIDE 패스너	49.126	FASTENER, HYDRAULIC VALVE MOUNTING 패스너
30.256	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	50.072	FITTING, 1ST AUXILIARY VALVE "B" PORT 피팅
30.787	BOOT, VALVE CONTROL LEVER 부트	50.073	FITTING, 2ND AUXILIARY VALVE "B" PORT 피팅
30.817	KNOB, AUXILIARY VALVE CONTROL LEVER 노브	50.075	SEAL, AUXILIARY VALVE PORT FITTING 시일
30.843	LEVER, AUXILIARY VALVE CONTROL (1ST AUX) 레버	50.440	FITTING, 1ST AUXILIARY VALVE "A" PORT 피팅
30.844	LEVER, AUXILIARY VALVE CONTROL (2ND AUX) 레버	50.441	FITTING, 2ND AUXILIARY VALVE "A" PORT 피팅

50.861 FITTING, AUXILIARY VALVE A PORT
피팅

50.863 FITTING, AUXILIARY VALVE B PORT
피팅

93.671 FASTENER, HYDRAULIC VALVE COVER
패스너



13.323 FASTENER, WARNING BUZZER
패스너

13.471 BUZZER, WARNING
부져

13.624 BRACKET, TILT LIMIT SWITCH
브라켓

13.625 FASTENER, TILT LIMIT SWITCH
패스너

15.083 CONDUCTOR, TILT LIMIT DEVICE FEED
컨덕터

32.136 RELAY, TILT LIMIT DEVICE
릴레이


32.147 WASHER, TILT LIMIT FASTENER
와셔

32.157 SWITCH, TILT LIMIT
스위치

32.158 BRACKET, TILT LIMIT SWITCH
브라켓

32.159 RETAINER, TILT LIMIT SWITCH BRACKET
리테이너

96.784 WASHER, TILT LIMIT SWITCH FASTENER
와셔



AUX.VALVE PLUMBING (DOUBLE) **31-201**

50.027 FITTING, 1ST AUXILIARY VALVE A PORT
피팅

50.206 FASTENER, DEVICE RH LINE CLAMP
패스너


50.220 LINE, 2ND AUXILIARY VALVE "A" PORT
라인

50.221 LINE, 2ND AUXILIARY VALVE "B" PORT
라인

50.425 LINE, 1ST AUXILIARY VALVE "A" PORT
라인

50.426 LINE, 1ST AUXILIARY VALVE "B" PORT
라인

51.438 CLIP, DEVICE HOSE
클립



AUX.VALVE PLUMBING (SINGLE) **31-202**


50.027 FITTING, 1ST AUXILIARY VALVE A PORT
피팅

50.206 FASTENER, DEVICE RH LINE CLAMP
패스너

50.425 LINE, 1ST AUXILIARY VALVE "A" PORT
라인

50.426 LINE, 1ST AUXILIARY VALVE "B" PORT
라인

51.438 CLIP, DEVICE HOSE
클립



HYDRAULIC LIFT & TILT LINES **31-360**

28.209 LINE, MAIN VALVE INLET
라인

28.225 FITTING, FLOW CONTROL VALVE BY-PASS PORT
피팅

28.798 SEAL, MAIN VALVE LIFT PORT LINE FITTING
시일

28.894 PROTECTOR, LIFT LINE
보호장치

31.030 LINE, VALVE TO LIFT CYLINDER
라인


31.036 FITTING, MAIN VALVE INLET PORT
피팅

31.061 FITTING, VALVE TILT PORT "A"
피팅

31.062 FITTING, VALVE TILT PORT "B"
피팅

31.072 LINE, RH TILT CYLINDER ROD PORT
라인

31.073	LINE, LH TILT CYLINDER ROD PORT 라인
31.083	LINE, RH TILT CYLINDER ANCHOR PORT 라인
31.158	LINE, LH TILT CYLINDER ANCHOR PORT 라인
31.175	LINE, VALVE TILT PORT "B" 라인
31.182	LINE, VALVE TILT PORT "A" 라인
31.200	FITTING, MAIN VALVE LIFT PORT 피팅
31.369	FITTING, VALVE TILT PORT "A" LINE 피팅
31.400	FITTING, VALVE TILT PORT "B" LINE 피팅
31.515	FITTING, VALVE TILT PORT "B" LINE 피팅
31.516	FITTING, VALVE TILT PORT "A" LINE 피팅
46.047	PIPE, VALVE TO LIFT CYLINDER 파이프
96.413	WASHER, TILT LINE FITTING 와셔



HYDRAULIC SUPPLY LINES **31-841**

28.247 SEAL, PS FLOW CONTROL VAL OUTLET PORT FTG
시일

28.248 FITTING, FLOW CONTROL VALVE OUTLET PORT
피팅

31.003 LINE, PUMP INLET
라인

31.006 LINE, PUMP INLET
라인


31.007 CLAMP, PUMP INLET LINE
클램프

31.008 FITTING, PUMP INLET
피팅

31.010 SEAL, PUMP INLET PORT
시일

31.013 SEAL, PUMP OUTLET
시일

31.014 FITTING, PUMP OUTLET
피팅



32.000 CYLINDER ASSEMBLY, TILT
실린더


32.002 CYLINDER ASSEMBLY, WELDED
실린더

32.017 GLAND, TILT CYLINDER
그랜드

32.018 BUSHING, TILT CYLINDER GLAND
부싱

32.036 ROD & PISTON ASSEMBLY, TILT CYLINDER
로드와피스톤

32.072 PACKING KIT, TILT CYLINDER
패킹킷



32.000 CYLINDER ASSEMBLY, TILT
실린더

32.002 CYLINDER ASSEMBLY, WELDED
실린더


32.017 GLAND, TILT CYLINDER
그랜드

32.018 BUSHING, TILT CYLINDER GLAND
부싱

32.036 ROD & PISTON ASSEMBLY, TILT CYLINDER
로드와피스톤

32.072 PACKING KIT, TILT CYLINDER
패킹킷

32.129 SPACER, TILT CYLINDER BARREL END
스페이서



ACCUMULATOR INSTALLATION **32-144**

32.196 ROD, HYDRAULIC ACCUMULATOR LINE
*

32.800 ACCUMULATOR, HYDRAULIC
어큐뮬레이터

32.801 CLAMP, HYDRAULIC ACCUMULATOR MOUNTING
클램프

32.802 BRACKET, HYDRAULIC ACCUMULATOR
브라켓

32.805 SEAL, HYDRAULIC ACCUMULATOR CONNECTOR
시일

32.806 CONNECTOR, HYDRAULIC ACCUMULATOR
커넥터


32.810 LINE, HYDRAULIC ACCUMULATOR
라인

32.814 FITTING, HYDRAULIC ACCUMULATOR LINE
피팅

32.819 LINE, HYDRAULIC ACCUMULATOR
라인

32.841 NUT, HYDRAULIC ACCUMULATOR FITTING
너트

32.842 SEAL, HYDRAULC ACCUMULATOR FITTING
시일



32.001 TILT CYLINDER ASSEMBLY (LH)
틸트실린더

32.002 CYLINDER ASSEMBLY, WELDED
실린더


32.017 GLAND, TILT CYLINDER
그랜드

32.018 BUSHING, TILT CYLINDER GLAND
부싱

32.036 ROD & PISTON ASSEMBLY, TILT CYLINDER
로드와피스톤

32.072 PACKING KIT, TILT CYLINDER
패킹킷

32.129 SPACER, TILT CYLINDER BARREL END
스페이서



TILT CYLINDER MOUNTING **32-157**


32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.029	FASTENER, TILT CYLINDER ROD END 패스너
32.030	PIN, TILT CYLINDER TO UPRIGHT 핀
32.032	FITTING, TILT CYLINDER TO UPRIGHT PIN LUB 피팅
32.043	BEARING, TILT CYLINDER FRAME MOUNTING 베어링
32.053	BEARING, TILT CYLINDER ROD END 베어링
32.056	SPACER, TILT CYLINDER ROD END 스페이서

32.084 CAPSCREW, TILT CYLINDER ROD END PIN RETAINER
캡스크류

32.102 SHIM, TILT CYLINDER STROKE ADJUSTING
심


90.438 NUT, TILT CYLINDER ROD END FASTENER
너트

■ INDICATES AN ASSEMBLY HAVING SERVICEABLE COMPONENTS ILLUSTRATED ELSEWHERE



TILT AMOUNT GP **32-167**

32.000	CYLINDER ASSEMBLY, TILT 실린더
32.001	TILT CYLINDER ASSEMBLY (LH) 틸트실린더
32.027	END, RH TILT CYLINDER ROD 엔드
32.056	SPACER, TILT CYLINDER ROD END 스페이서
32.102	SHIM, TILT CYLINDER STROKE ADJUSTING 심



33.600 RELIEF VALVE, DEVICE VARIABLE PRESSURE
릴리프밸브


33.601 LEVER, DEVICE VARIABLE RELIEF VALVE
레버

33.610 SEAL, DEVICE PRESS RELIEF VAL CHECK PORT PLUG
시일

33.613 SEAL, DEVICE RELIEF VALVE PISTON ADJ END
시일

33.618 CARTRIDGE KIT, DEVICE VARIABLE RELIEF VALVE
카트리지킷

33.631 FASTENER, DEVICE RELIEF VALVE
패스너




33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
벨브

33.384 FASTENER, DEV SELECTOR VALVE SOLENOID COIL
패스너

33.385 COIL, DEVICE SELECTOR VALVE SOLENOID
코일

33.387 SEAL KIT, DEVICE SELECTOR VALVE
시일킷


33.388 REPAIR KIT, DEVICE SELECTOR VALVE
리페어킷



LOAD BACK REST **34-044**

34.998 FASTENER, LOAD SAFETY BACK REST
패스너

66.431 RETAINER, LBR CAPSCREW
리테이너



LIFT CARRIAGE ASSEMBLY **34-134**

34.300 ASSEMBLY, FORK BARS & CARRIAGE
캐리지

34.301 ROLLER, CARRIAGE OUTER THRUST
롤러

34.307 ROLLER, CARRIAGE INNER THRUST
롤러

34.320 SHAFT, CARRIAGE OUTER THRUST ROLLER
샤프트

34.321 FASTENER, CARRIAGE ROLLER SHAFT
패스너

34.328 ROLLER, CARRIAGE CAPTIVE
롤러

34.329 RETAINER, CARRIAGE CAPTIVE ROLLER
리테이너

34.330 FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER
패스너

34.332 SHIM, CARRIAGE CAPTIVE ROLLER
심


34.340 CARRIAGE WELDED ASSEMBLY
캐리지용접물


This Carriage assembly was manufactured by the CASCADE CORPORATION and is not serviced by CLARK Material Handling Company.

CASCADE parts manuals, technical specifications and lists of worldwide distributors are available on-line at:

http://www.cascorp.com.

When ordering service parts, it will be necessary to provide CASCADE with the CASCADE model and serial numbers of the carriage. CASCADE will not recognize the CLARK carriage part number listed on the PIC or in PartsPRO.





LIFT CARRIAGE ASSEMBLY **34-998**

34.300 ASSEMBLY, FORK BARS & CARRIAGE
캐리지

34.301 ROLLER, CARRIAGE OUTER THRUST
롤러

34.307 ROLLER, CARRIAGE INNER THRUST
롤러

34.320 SHAFT, CARRIAGE OUTER THRUST ROLLER
샤프트

34.321 FASTENER, CARRIAGE ROLLER SHAFT
패스너


34.328 ROLLER, CARRIAGE CAPTIVE
롤러

34.329 RETAINER, CARRIAGE CAPTIVE ROLLER
리테이너

34.330 FASTENER, CARRIAGE CAPTIVE ROLLER RETAINER
패스너

34.332 SHIM, CARRIAGE CAPTIVE ROLLER
심

34.340 CARRIAGE WELDED ASSEMBLY
캐리지용접물



37.897 BUMPER, TOP HOOD
범퍼

37.934 SEAL, HOOD ACCESS COVER
시일

37.973 GROMMET, SEAT WIRING HARNESS
그로멧

39.423 FASTENER, TOP HOOD
패스너

39.535 BRACKET, TOP HOOD MOUNTING
브라켓


39.537 FASTENER, TOP HOOD MOUNTING BRACKET
패스너

39.594 HOOD, TOP
후드

39.595 FASTENER, TOP HOOD
패스너

39.643 CATCH, TOP HOOD LATCH
캐치

39.644	LATCH, TOP HOOD 래치
39.648	FASTENER, TOP HOOD LATCH CATCH 패스너
39.662	FASTENER, TOP HOOD LATCH BRACKET 패스너
39.702	PROP, HOOD 프롭
39.705	FASTENER, HOOD PROP 패스너
41.103	BACKING PLATE, FILLER OPENING SOUND SEAL 백킹플레이트
41.104	SOUND SEAL, RH SIDE HOOD 사운드시일
41.112	SOUND SEAL, RH SIDE HOOD FRONT 사운드시일
41.115	SCUFF PLATE, FLOOR PAD 스커프플레이트
41.392	SOUND SEAL, TOP HOOD 사운드시일
41.602	SOUND SEAL, ENGINE HOOD 사운드시일
41.603	SOUND SEAL, ENGINE HOOD 사운드시일
95.800	FASTENER, SOUND SEAL 패스너




SEAT ARMREST ASSEMBLY **37-124**

37.919 ARMREST LH, SEAT
암레스트

37.920 ARMREST RH, SEAT
암레스트

96.403 FASTENER, SEAT ARMREST BRACKET
패스너



FRAME & COUNTERWEIGHT **38-113**

38.020 FRAME ASSEMBLY
프레임


38.853 SHIM, COUNTERWEIGHT
심

38.869 COUNTERWEIGHT
카운터웨이트

38.871 FASTENER, COUNTERWEIGHT (UPPER) CONTINUED
패스너

38.920 PIN, COUPLER
핀


38.921 PIN, COUPLER PIN CROSS
핀



FRAME TANK BOTTOM PLUG **38-270**

38.246 PLUG, FRAME BOTTOM MAGNETIC
플러그

38.280 SEAL, FRAME BOTTOM MAGNETIC PLUG
실



37.204 COVER, SEAT BACK REST CUSHION
커버

37.404 BASE, SEAT FRAME
베이스

37.405 TRIM, SEAT MOUNTING PLATE
트림

37.409 HANDLE, SEAT CUSHION TENSION ADJUSTOR LEVER
핸들

37.410 LEVER, SEAT CUSHION TENSION ADJUSTOR
레버

37.411 ADJUSTOR, SEAT CUSHION TENSION
어드져스터

37.412 SPRING, SEAT SUSPENSION TENSION
스프링

37.449 BRACKET, SEAT SAFETY BELT MOUNTING
브라켓

37.588 LEVER, SEAT CUSHION ADJUSTING
레버

37.616 SWITCH, SEAT
스위치

37.801 KIT WEARING PARTS, SEAT ASSEMBLY
킷

37.918 SUSPENSION ASSEMBLY, SEAT
서스펜션

39.719 SEAT ASSEMBLY
시트

39.720 CUSHION, SEAT
쿠션

39.721 CUSHION, SEAT BACK REST
쿠션

39.722 FRAME ASSEMBLY, SEAT
프레임

39.726 ADJUSTOR, SEAT
어드져스터

39.761 PLATE, SEAT CUSHION MOUNTING
플레이트

47.001 ADJUSTOR,SEAT CUSHION TENSION
어드져스터


47.010 KIT WEARING PARTS, SEAT ASSY
킷

47.020 SHAFT, SEAT STOP MOUNTING
샤프트

47.030 REPAIR KIT,SEAT ASSEMBLY
리페어킷


47.040 REPAIR KIT,SEAT ASSEMBLY
리페어킷

94.032 RETAINER, SEAT FRAME
리테이너



37.865 FASTENER KIT, SEAT SAFETY BELT
패스너킷

39.719 SEAT ASSEMBLY
시트



SEAT MONUTING

39-195

37.447 RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트

37.607 RUBBER, SEAT CUSHION MOUNTING PLATE
러버

39.710 SUPPORT, SEAT ADJUSTOR (RH)
서포트

39.719 SEAT ASSEMBLY
시트

39.721 CUSHION, SEAT BACK REST
쿠션


39.728 FASTENER, SEAT FRAME TO ADJUSTOR
패스너

39.729 FASTENER, ADJUSTOR TO SEAT SUPPORT
패스너

92.525 NUT, SEAT SUPPORT FASTENER
너트

92.912 WASHER, SEAT SUPPORT FASTENER
와셔

94.537 FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너




34.977 RETAINER, LOAD BACK REST TRUNNION PIN
리테이너

34.991 FASTENER, LOAD SAFETY BACK REST EXT
패스너

34.995 FASTENER, LOAD SAFETY BACK REST
패스너

92.226 NUT, LOAD SAFETY BACK REST FASTENER
너트



37.439 SAFETY BELT, SEAT
세이프티벨트

39.710 SUPPORT, SEAT ADJUSTOR (RH)
서포트


39.712 SUPPORT, SEAT ADJUSTOR (LH)
서포트

39.719 SEAT ASSEMBLY
시트

39.728 FASTENER, SEAT FRAME TO ADJUSTOR
패스너

39.729 FASTENER, ADJUSTOR TO SEAT SUPPORT
패스너

94.518 FASTENER, SEAT SAFETY BELT
패스너




37.204	COVER, SEAT BACK REST CUSHION 커버	47.057	PIN, BACK FRAME SHOCK 핀
37.405	TRIM, SEAT MOUNTING PLATE 트림	47.058	SADDLE SPRING, SPRING ARM 샤들스프링
37.406	BRACKET, SEAT BACK REST COVER LH 브라켓	47.059	SADDLE BUSHING, SPRING ARM 샤들부싱
37.407	BRACKET, SEAT BACK REST COVER RH 브라켓	47.060	SPRING ARM, SUSPENSION SEAT 스프링
37.412	SPRING, SEAT SUSPENSION TENSION 스프링	47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
37.439	SAFETY BELT, SEAT 세이프티벨트	47.065	WEIGHT INDICATOR ASSEMBLY 웨이트인디케이터
39.719	SEAT ASSEMBLY 시트	47.066	SPACER, SEAT ASSEMBLY WEIGHT ADJUST SCREW 스페이서
39.720	CUSHION, SEAT 쿠션	47.067	CLIP, FRONT SEAT FRAME 클립
39.721	CUSHION, SEAT BACK REST 쿠션	47.068	BAR, WEIGHT ADJUSTER 바
39.726	ADJUSTOR, SEAT 어드져스터	47.105	SWITCH KIT, SEAT 스위치킷
39.727	ADJUSTOR, SEAT WITH LATCH 어드져스터	47.106	SHOCK ABSORBER, SUSPENSION SEAT 쇽압쇼버
39.745	BUMPER, SEAT SUPPORT 범퍼	47.107	COVER, MECHANISM 커버
39.747	PLATE, SEAT BACK REST CUSHION MOUNTING 플레이트	47.108	SPRING, SEAT ASSEMBLY PLUNGER 스프링
39.761	PLATE, SEAT CUSHION MOUNTING 플레이트	47.109	KNOB, FOLD DOWN SEAT 노브
47.053	LUMBAR FLEXOLATOR 룸바	47.110	PLUNGER, FOLD DOWN SEAT 플런저

94.032 RETAINER, SEAT FRAME
리테이너

94.044 FASTENER, SEAT CUSHION MOUNTING PLATE
패스너

94.047 FASTENER, SEAT BACK REST CUSHION
패스너



SEAT ASSEMBLY **39-661**

37.406 BRACKET, SEAT BACK REST COVER LH
브라켓

37.407 BRACKET, SEAT BACK REST COVER RH
브라켓

37.439 SAFETY BELT, SEAT
세이프티벨트

37.531 BRACKET, SEAT SAFETY BELT MOUNTING
브라켓

37.720 COVER, OPERATOR SEAT LATERAL RESTRAINT
커버


37.743 COVER, SEAT SUPPORT LATCH
커버

38.163 BRACKET, SEAT SUPPORT RH
브라켓

39.719 SEAT ASSEMBLY
시트

39.720 CUSHION, SEAT
쿠션

39.721	CUSHION, SEAT BACK REST 쿠션
39.726	ADJUSTOR, SEAT 어드져스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드져스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.732	SPACER, SEAT FRAME TO ADJUSTOR 스페이서
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
95.429	FASTENER, SEAT LATERAL RESTRAINT COVER 패스너




39.710 SUPPORT, SEAT ADJUSTOR (RH)
서포트


39.712 SUPPORT, SEAT ADJUSTOR (LH)
서포트

39.719 SEAT ASSEMBLY
시트

48.347 FASTENER, SEAT ASSEMBLY
패스너



39.719	SEAT ASSEMBLY 시트
48.347	FASTENER, SEAT ASSEMBLY 패스너
96.736	WASHER, SEAT ASSEMBLY FASTENER 와셔



37.406 BRACKET, SEAT BACK REST COVER LH
브라켓

37.407 BRACKET, SEAT BACK REST COVER RH
브라켓

37.439 SAFETY BELT, SEAT
세이프티벨트

37.915 SUSPENSION COVER, SEAT SUSPENSION
서스펜션

37.918 SUSPENSION ASSEMBLY, SEAT
서스펜션


38.163 BRACKET, SEAT SUPPORT RH
브라켓

39.719 SEAT ASSEMBLY
시트

39.720 CUSHION, SEAT
쿠션

39.721 CUSHION, SEAT BACK REST
쿠션

39.726	ADJUSTOR, SEAT 어드져스터
39.727	ADJUSTOR, SEAT WITH LATCH 어드져스터
39.729	FASTENER, ADJUSTOR TO SEAT SUPPORT 패스너
39.852	BRACKET, SEAT SUPPORT LH 브라켓
39.853	FASTENER, SEAT SUPPORT BRACKET 패스너
47.064	KNOB, SEAT ASSEMBLY WEIGHT ADJUSTER 노브
75.046	KIT, SEAT ACTUATED ENGINE SHUTDOWN 킷
93.739	FASTENER, SAFETY BELT ASSEMBLY 패스너
94.044	FASTENER, SEAT CUSHION MOUNTING PLATE 패스너
94.880	FASTENER, SEAT SUPPORT CATCH BRACKET 패스너
95.274	FASTENER, SEAT CUSHION SUSPENSION SUPPORT 패스너
96.412	FASTENER, SEAT SUSPENSION BACK SIDE COVER 패스너




37.201	PANEL, LH SIDE 판넬
37.202	PANEL, RH SIDE 판넬
37.741	SOUND ABSORBER, FLOOR PLATE 흡음재
39.266	WEATHERSEAL, CENTER FLOOR PLATE 웨더시일
39.472	PLATE, FRONT FLOOR LH 플레이트
39.474	PAD, FLOOR BOARD NON-SLIP 패드
39.475	PLATE, FRONT FLOOR 플레이트
39.547	FASTENER, COWL ASSEMBLY 패스너
41.252	SOUND SEAL, FLOOR PLATE FRONT 사운드시일

41.394 SOUND ABSORBER, FLOOR PLATE - REAR
흡음재


41.396 SOUND ABSORBER, SEAT SUPPORT PANEL
흡음재

91.489 FASTENER, FLOOR PLATE
패스너



13.299	GUARD, HEADLIGHT 가드
37.146	SOUND ABSORBER, OVERHEAD GUARD 흡음재
37.170	SOUND ABSORBER, FRONT SIDE PANEL 흡음재
37.290	DAMPENER, OVERHEAD GUARD VIBRATION 댐프너
37.367	FILLER, COWL (LH) 필러
37.421	GROMMET, OVERHEAD GUARD REAR SUPPORT PIVOT 그로멧
37.723	PLUG, RADIATOR COVER HOLE 플러그
37.746	PLUG, DRIVER OVERHEAD GUARD 플러그
39.546	COWL ASSEMBLY 카울

39.932	GUARD, OVERHEAD 가드
39.933	FASTENER, OVERHEAD GUARD 패스너
39.934	FASTENER, OVERHEAD GUARD 패스너
39.938	BRACKET, OVERHEAD GUARD REAR SUPPORT 브라켓
39.939	FASTENER, OVERHEAD GUARD REAR SUPPORT BRACKET 패스너
39.944	FASTENER, OVERHEAD GUARD BRACKET 패스너
41.124	SOUND ABSORBER, COWL 흡음재
41.131	SOUND ABSORBER, LOWER REAR PANEL 흡음재
41.397	SOUND ABSORBER, RADIATOR COVER 흡음재
41.431	SOUND SEAL, FRAME UPPER LH 사운드시일
47.003	COVER, RADIATOR 커버
47.004	SEAL, RADIATOR COVER 시일
47.081	FASTENER, COWL COVER MOUNTING BRACKET 패스너
94.868	FASTENER, RADIATOR SUPPORT 패스너
95.299	FASTENER, HEADLAMP GUARD 패스너



NOTE: All Trucks Do Not Use All Fluid Key Numbers

TRUCK FLUIDS 40-260

99.901 ENGINE OIL
엔진오일

99.902 TRANSMISSION FLUID
트랜스미션오일


99.903 DRIVE AXLE FLUID
드라이브액슬

99.904 HYDRAULIC SUMP OIL
유압섬프오일

99.905 BRAKE FLUID
브레이크오일

99.906 AXLE END FLUID
액슬엔드오일

99.907 ENGINE ANTIFREEZE
부동액



37.765 TAPE, CAB FRONT FRAME
테이프

40.000 PLATE, CAPACITY & SERIAL NUMBER
플레이트

40.001 FASTENER, CAPACITY & SERIAL PLATE
패스너

40.011 DECAL, UPRIGHT
데칼

40.012 DECAL, CLARK LOGO-SMALL
데칼


40.013 DECAL, CLARK LOGO-LARGE
데칼

40.024 PLATE, UNDERWRITERS LABEL
플레이트

40.046 DECAL, TIRE PRESSURE
데칼

40.068 DECAL, HYD-SYSTEM OIL
데칼

40.089	PLATE, SAFETY INSTRUCTION 플레이트
40.129	PLATE, DUEL FUEL SELECTOR SWITCH 플레이트
40.131	LEGEND, SAFETY 범례
40.134	DECAL, OPERATORS MANUAL LOCATION 데칼
40.138	DECAL, SAFETY 데칼
40.221	DECAL, FAN 데칼
40.236	DECAL, FUEL 데칼
40.240	DECAL, FUEL WARNING 데칼
40.241	DECAL, BRAKE OIL SPEC 데칼
40.260	DECAL, HOT SURFACE WARNING 데칼
40.279	DECAL, STARTING PROCEDURE 데칼
40.328	DECAL, WHEEL NUT WARNING 데칼
40.330	PLATE. ATTACHMENT NAME 플레이트
40.346	DECAL, OVERHEAD GUARD DROP TEST *
40.349	PLATE, LESS LP TANK *
40.353	DECAL, AUTHORIZED REPRESENTATIVE *
40.356	DECAL-FUEL WARNING *
40.357	DECAL, FUEL SELECTOR *




MODEL & SPECIFICATION DECAL **40-289**

40.014 DECAL, MODEL NAME
데칼

40.296 DECAL, TIRE PRESSURE
데칼


40.311 DECAL, SOUND POWER LEVEL
데칼



STORAGE CONSOLE MOUNTING **41-008**

41.028 CONSOLE, OPERATOR STORAGE CONSOLE
콘솔


41.030 FASTENER, STORAGE CONSOLE
패스너



37.447 RESTRAINT, OPERATOR SEAT LATERAL
레스트레인트

37.970 KIT, SEAT SAFETY
킷

94.537 FASTENER, OPERATOR SEAT LATERAL RESTRAINT
패스너




ENGINE SHUTDOWN CONTROL GROUP **47-006**

15.490 HARNESS, SEAT ACTUATED ENGINE SHUTDOWN WIRING
하네스


15.783 TRACTION DISABLE CONTROL
트랙션

15.785 FASTENER, TRACTION DISABLE CONTROL
패스너


18.087 CLIP, SEAT SAFETY SWITCH WIRE
클립



HINGED BUCKET (HB) / FORK (HF) - BASIC



ROTATING FORK (RF) - BASIC



LOAD STABILIZER (LS) - BASIC

ATTACHMENT HOSE ADAPTATION (CARRIAGE) 50-171

50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인


50.301 CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립

50.405 COUPLING, DEVICE HOSE
커플링

50.408 COUPLING, DEVICE HOSE
커플링

50.410 COUPLING, DEVICE HOSE
커플링

50.803 FITTING, DEVICE HYDRAULIC LINE
피팅



HIGH TERMINATION FOR DEVICE HOSE ADAPTATION **50-172**

59.134 LINE, DEVICE LH LINE FOR HIGH TERMINATION
*

59.135 LINE, DEVICE LH LINE FOR HIGH TERMINATION
*

59.136 LINE, DEVICE RH LINE FOR HIGH TERMINATION
*

59.137 LINE, DEVICE RH LINE FOR HIGH TERMINATION
*

59.142 FITTING, DEVICE LINE FOR HIGH TERMINATION
*

59.143 CAP, DEVICE LINE FITTING FOR HIGH TERMINATION
*


59.144 BRACKET, DEVICE LINE FOR HIGH TERMINATION
*

59.145 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
*

59.146 SEAL, DEVICE LINE FITTING FOR HIGH TERMINATION
*

97.235 FASTENER, DEVICE LINE CLAMP FOR HIGH TERMINATION
*

97.238 FASTENER, DEVICE LINE FITTING FOR HIGH TERMINATION
*



50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.610	FASTENER, DEVICE HOSE GUARD 패스너
50.132	BRACKET, DEVICE HOSE REEL 브라켓	50.811	NUT, DEVICE HOSE FITTING 너트
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
50.156	CLIP, DEVICE HOSE 클립	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.200	COUPLING, DEVICE HOSE 커플링	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라J
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.119	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라J
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES *

93.316 DOWEL, STEERING INTERLOCK SWITCH FASTENER
다월


93.451 FASTENER, DEVICE HOSE TERMINAL BRACKET
패스너

93.769 FASTENER, DEVICE LINE JUNCTION BLOCK
패스너

95.538 FASTENER, DEVICE HOSE REEL BRACKET
패스너

96.316 FASTENER, DEVICE HOSE REEL
패스너

97.181 FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET
*



50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.811	NUT, DEVICE HOSE FITTING 너트
50.132	BRACKET, DEVICE HOSE REEL 브라켓	59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
50.155	FASTENER, DEVICE HOSE CLIP 패스너	59.023	BRACKET, DEVICE HOSE REEL MOUNTING 브라켓
50.156	CLIP, DEVICE HOSE 클립	59.034	TUBE, DEVICE HOSE REEL MOUNTING BRACKET 튜브
50.200	COUPLING, DEVICE HOSE 커플링	59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	59.072	GUARD, DEVICE HOSE 가드
50.295	ROLLER, DEVICE HOSE UPPER 롤러	59.077	FASTENER, DEVICE HOSE GUARD 패스너
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	59.086	FASTENER, DEVICE HOSE CLIP BRACKET 패스너
50.316	GUARD, DEVICE RH HOSE 가드	59.101	TIE STRAP, AUXILIARY FUNCTION LINES 타이스트랩
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	59.118	LINE, DEVICE HYDRAULIC (OUTER RAIL) 라J
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
50.433	BRACKET, DEVICE HOSE CLAMP 브라켓	59.125	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.571	BRACKET, DEVICE HOSE 브라켓	59.126	BRACKET, DEVICE HOSE GUARD MOUNTING *
50.572	FASTENER, DEVICE HOSE BRACKET 패스너	75.015	MODULE, ATTACHMENT HOSE LINES *
50.610	FASTENER, DEVICE HOSE GUARD 패스너	93.316	DOWEL, STEERING INTERLOCK SWITCH FASTENER 다월


93.451 FASTENER, DEVICE HOSE TERMINAL BRACKET
패스너

93.769 FASTENER, DEVICE LINE JUNCTION BLOCK
패스너

95.538 FASTENER, DEVICE HOSE REEL BRACKET
패스너

96.316 FASTENER, DEVICE HOSE REEL
패스너

97.181 FASTENER, DEVICE HOSE GUARD MOUNTING BRACKET
*



ATTACHMENT HOSE & CABLE ADAPTATION (UPRIGHT) **50-270**

50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.294 PIVOT, DEVICE HOSE UPPER SHEAVE
피봇


50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너


50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.686 WIRE, DEVICE
와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



FORK POSITIONER (FP) - SHIFT
TYPE - 1



FORK POSITIONER (FP) - SHIFT
TYPE - 2

ATTACHMENT HOSE ADAPTATION (CARRIAGE) **50-284**

50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.301 CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립


50.405 COUPLING, DEVICE HOSE
커플링

50.408 COUPLING, DEVICE HOSE
커플링

50.410 COUPLING, DEVICE HOSE
커플링

50.803 FITTING, DEVICE HYDRAULIC LINE
피팅

59.085 COUPLING, DEVICE HOSE
커플링



50.006	SHEAVE, DEVICE HOSE UPPER 쉬브	50.588	BRACKET, DEVICE CABLE CLAMP 브라켓
50.007	RETAINER, DEVICE HOSE SHEAVE 리테이너	50.590	CLAMP, DEVICE CABLE LOWER 클램프
50.009	SHEAVE, DEVICE HOSE LOWER 쉬브	50.591	FASTENER, DEVICE CABLE CLAMP LOWER 패스너
50.101	SEAL, DEVICE HOSE SWIVEL COUPLING 시일	50.623	BRACKET, DEVICE CABLE LOWER SHEAVE 브라켓
50.124	PIVOT, DEVICE HOSE LOWER RH SHEAVE 피봇	50.624	SHEAVE, DEVICE CABLE 쉬브
50.156	CLIP, DEVICE HOSE 클립	50.625	RETAINER, DEVICE CABLE LOWER SHEAVE 리테이너
50.200	COUPLING, DEVICE HOSE 커플링	50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.215	TERMINAL BLOCK, DEVICE HOSE 터미널블록	50.686	WIRE, DEVICE 와이어
50.218	TERMINAL BLOCK, DEVICE LH HOSE 터미널블록	50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇	50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓	50.714	LOCK, DEVICE CABLE CONNECTOR *
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너	50.731	PLUG, DEVICE CABLE CONNECTOR *
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅	50.732	SPACER, DEVICE CABLE SHEAVE *
50.586	CLIP, DEVICE CABLE 클립	50.733	SPACER, DEVICE CABLE CLAMP BRACKET *
50.587	FASTENER, DEVICE CABLE CLIP 패스너	50.734	BRACKET, DEVICE CABLE TERMINAL CLAMP *

50.745 BRACKET, DEVICE CABLE TERMINAL CLAMP MOUNTING
*

50.746 FASTENER, DEVICE HOSE TERMINAL BLOCK
*

50.811 NUT, DEVICE HOSE FITTING
너트

50.826 TERMINAL, DEVICE CABLE
터미널

59.016 JUNCTION BLOCK, DEVICE HOSE
연결블록

59.054 PLUG, DEVICE HOSE JUNCTION BLOCK
플러그

59.090 BRACKET, DEVICE HOSE TERMINAL
브라켓

59.120 LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL)
라J

59.121 LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL)
라J

59.122 LINE, DEVICE HYDRAULIC (INNER RAIL)
라J


59.123 LINE, DEVICE HYDRAULIC (INNER RAIL)
라J

75.015 MODULE, ATTACHMENT HOSE LINES
*

93.451 FASTENER, DEVICE HOSE TERMINAL BRACKET
패스너

93.769 FASTENER, DEVICE LINE JUNCTION BLOCK
패스너

97.182 FASTENER, DEVICE CABLE LOWER SHEAVE BRACKET
*



50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.294 PIVOT, DEVICE HOSE UPPER SHEAVE
피봇


50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.686 WIRE, DEVICE
와이어

50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.007 RETAINER, DEVICE HOSE SHEAVE
리테이너

50.009 SHEAVE, DEVICE HOSE LOWER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.124 PIVOT, DEVICE HOSE LOWER RH SHEAVE
피봇


50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.218 TERMINAL BLOCK, DEVICE LH HOSE
터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.686	WIRE, DEVICE 와이어
50.697	CONNECTOR, DEVICE CABLE (PIN END) 커넥터
50.698	CONNECTOR, DEVICE CABLE (SOCKET END) 커넥터
50.714	LOCK, DEVICE CABLE CONNECTOR *
50.731	PLUG, DEVICE CABLE CONNECTOR *
50.811	NUT, DEVICE HOSE FITTING 너트
50.826	TERMINAL, DEVICE CABLE 터미널
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT) **50-407**

50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.007 RETAINER, DEVICE HOSE SHEAVE
리테이너

50.009 SHEAVE, DEVICE HOSE LOWER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.124 PIVOT, DEVICE HOSE LOWER RH SHEAVE
피봇


50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.218 TERMINAL BLOCK, DEVICE LH HOSE
터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.120	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.121	LINE, DEVICE HYDRAULIC (INTERMEDIATE RAIL) 라J
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



ATTACHMENT HOSE ADAPTATION (UPRIGHT) **50-410**

50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록


50.294 PIVOT, DEVICE HOSE UPPER SHEAVE
피봇

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅

50.811	NUT, DEVICE HOSE FITTING 너트
59.016	JUNCTION BLOCK, DEVICE HOSE 연결블록
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너
93.769	FASTENER, DEVICE LINE JUNCTION BLOCK 패스너



50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.007 RETAINER, DEVICE HOSE SHEAVE
리테이너

50.009 SHEAVE, DEVICE HOSE LOWER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.124 PIVOT, DEVICE HOSE LOWER RH SHEAVE
피봇


50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록

50.218 TERMINAL BLOCK, DEVICE LH HOSE
터미널블록

50.294	PIVOT, DEVICE HOSE UPPER SHEAVE 피봇
50.298	BRACKET, DEVICE HOSE TERMINAL 브라켓
50.355	FASTENER, DEVICE HOSE TERMINAL BLOCK 패스너
50.414	FITTING, DEVICE HOSE CONNECTOR 피팅
50.632	SPACER, DEVICE HOSE SHEAVE 스페이서
50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.090	BRACKET, DEVICE HOSE TERMINAL 브라켓
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
59.123	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



50.006 SHEAVE, DEVICE HOSE UPPER
쉬브

50.101 SEAL, DEVICE HOSE SWIVEL COUPLING
시일

50.156 CLIP, DEVICE HOSE
클립

50.200 COUPLING, DEVICE HOSE
커플링

50.215 TERMINAL BLOCK, DEVICE HOSE
터미널블록


50.294 PIVOT, DEVICE HOSE UPPER SHEAVE
피봇

50.298 BRACKET, DEVICE HOSE TERMINAL
브라켓

50.355 FASTENER, DEVICE HOSE TERMINAL BLOCK
패스너

50.414 FITTING, DEVICE HOSE CONNECTOR
피팅


50.811	NUT, DEVICE HOSE FITTING 너트
59.054	PLUG, DEVICE HOSE JUNCTION BLOCK 플러그
59.122	LINE, DEVICE HYDRAULIC (INNER RAIL) 라J
75.015	MODULE, ATTACHMENT HOSE LINES *
93.451	FASTENER, DEVICE HOSE TERMINAL BRACKET 패스너



50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.253 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.301 CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립



ATTACHMENT HOSE ADAPTATION (CARRIAGE) **50-794**

50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인


50.253 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.301 CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립

50.408 COUPLING, DEVICE HOSE
커플링

50.410 COUPLING, DEVICE HOSE
커플링

50.803 FITTING, DEVICE HYDRAULIC LINE
피팅




ATTACHMENT HOSE ADAPTATION (CARRIAGE) **50-796**

50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.301 CLIP, DEVICE RH HOSE (AT CARRIAGE)
클립

50.408 COUPLING, DEVICE HOSE
커플링

50.410 COUPLING, DEVICE HOSE
커플링



ATTACHMENT HOSE ADAPTATION (CARRIAGE) **50-797**

50.203 LINE, DEVICE HYDRAULIC (AT CARRIAGE)
라인

50.343 FITTING, DEVICE LH LINE
피팅


50.344 FITTING, DEVICE LH LINE
피팅

50.408 COUPLING, DEVICE HOSE
커플링

50.410 COUPLING, DEVICE HOSE
커플링

50.803 FITTING, DEVICE HYDRAULIC LINE
피팅

59.091 FITTING, DEVICE HYDRAULIC LINE
피팅



SIDESHIFT CYLINDER **53-008**

52.002 RING, CLAMP SIDE SHIFT LIMIT CYL PISTON WEAR
링

53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더

53.104 RING, SIDE SHIFTER CYL PISTON PACKING BACK-UP
링

53.106 SEAL, SIDE SHIFTER CYLINDER GLAND
시일

53.107 RING, SIDE SHIFT CYL GLAND SEAL BACK-UP
링

53.109 GLAND, SIDE SHIFTER CYLINDER
그랜드

53.112 WIPER, SIDE SHIFTER CYLINDER PISTON ROD
와이퍼

53.113 CYLINDER ASSEMBLY, WELDED SIDE SHIFTER
실린더

53.117 BUSHING, SIDE SHIFTER CYLINDER GLAND
부싱

53.215 FITTING, SIDE SHIFTER CYLINDER ROD PORT
피팅


53.216 SEAL, SIDE SHIFTER CYLINDER ROD PORT FITTING
시일

53.676 ROD, SIDE SHIFTER CYLINDER PISTON
로드


53.677 SEAL, SIDE SHIFTER CYLINDER PISTON
시일

54.222 PACKING KIT, SIDE SHIFTER CYLINDER
패킹킷

54.407 SEAL, SIDE SHIFTER CYLINDER PORT ROD
시일



37.457	HOOK, CAB CLOTHING HANGER 후크	53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
52.149	NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTIN 너트	53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더	54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
53.024	ANCHOR, SIDE SHIFTER CYLINDER BASE 앵커	54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
53.025	GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER 가이드	54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링	54.155	FITTING, SIDE SHIFTER CYLINDER ROD PORT LINE 피팅
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너	54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
53.090	FASTENER, SIDE SHIFTER MOVABLE FRAME 패스너	54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
53.180	SPACER, SIDE SHIFTER BEARING 스페이서	54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
53.182	FASTENER, SIDE SHIFTER HANGER 패스너	54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
53.201	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT 피팅	54.213	BEARING, SIDE SHIFTER (UPPER) 베어링
53.207	LINE, SIDE SHIFTER CYLINDER ANCHOR PORT 라인	54.403	FITTING-LUB, SIDE SHIFTER BASE PLATE ARM 피팅
53.209	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	66.162	STOP, CARRIAGE TRAVEL 스톱
53.210	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅	92.483	NIPPLE, LUBRICATION 니플
53.218	LINE, SIDE SHIFTER CYLINDER ROD PORT 라인		



FORK POSITIONER (BASIC) **53-084**

37.457 HOOK, CAB CLOTHING HANGER
후크

52.149 NUT, SIDE SHIFT CYLINDER ANCHOR PORT LINE FITTING
너트

53.025 GUIDE, SIDE SHIFTER MOVABLE FRAME LOWER
가이드

53.083 FASTENER, SIDE SHIFTER CYLINDER ANCHOR
패스너

53.090 FASTENER, SIDE SHIFTER MOVABLE FRAME
패스너


53.182 FASTENER, SIDE SHIFTER HANGER
패스너

53.207 LINE, SIDE SHIFTER CYLINDER ANCHOR PORT
라인

53.209 FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE
피팅


53.218 LINE, SIDE SHIFTER CYLINDER ROD PORT
라인

53.600	CYLINDER ASSEMBLY, INBOARD RH FORK 실린더
53.603	CYLINDER ASSEMBLY, INBOARD LH FORK 실린더
54.080	LINE, SIDE SHIFT CYLINDER ANCHOR PORT 라인
54.116	LINE, SIDE SHIFT CYLINDER ROD PORT 라인
54.152	FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE 피팅
54.187	FITTING, SIDE SHIFTER ANCHOR PORT LINE 피팅
54.197	FASTENER, SIDE SHIFTING BASE PLATE TO ARM 패스너
54.198	BEARING, SIDE SHIFTER BASE PLATE ARM 베어링
54.205	ATTACHMENT, FORK POSITIONER 어태치먼트
66.162	STOP, CARRIAGE TRAVEL 스톱



53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더

54.222 PACKING KIT, SIDE SHIFTER CYLINDER
패킹킷



FORK POSITIONER **53-164**

53.054 GUIDE, FORK
가이드

53.603 CYLINDER ASSEMBLY, INBOARD LH FORK
실린더

54.190 FASTENER, FORK HANGER SUPPORT
패스너

54.205 ATTACHMENT, FORK POSITIONER
어태치먼트

54.209 PLUG, FORK CYLINDER FLOW DIVIDER
플러그

54.224 PACKING KIT, LH FORK CYLINDER
패킹킷

54.446 FITTING - LUB, FORK POSITIONER
피팅

54.546 FITTING - LUB, FORK POSITIONER
피팅


54.548 HOOK, FORK POSITIONER HANGER
후크

54.549 STOP, FORK POSITIONER CYLINDER
스톱

54.552 FASTENER, FORK POSITIONER CYLINDER STOP
패스너

66.098 BEARING, FORK HORIZONTAL THRUST ROLLER
베어링

96.259 FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER
패스너



FORK POSITIONER (SHIFTING) **53-168**

53.020 CYLINDER ASSEMBLY, SIDE SHIFTER
실린더

53.024 ANCHOR, SIDE SHIFTER CYLINDER BASE
앵커

53.069 FASTENER, FORK CYLINDER ROD END
패스너

53.075 BEARING, SIDE SHIFTER (LOWER)
베어링

53.083 FASTENER, SIDE SHIFTER CYLINDER ANCHOR
패스너

53.180 SPACER, SIDE SHIFTER BEARING
스페이서

53.207 LINE, SIDE SHIFTER CYLINDER ANCHOR PORT
라인

53.210 FITTING, SIDE SHIFTER CYLINDER ANCHOR PORT LINE
피팅

53.218 LINE, SIDE SHIFTER CYLINDER ROD PORT
라인

53.603 CYLINDER ASSEMBLY, INBOARD LH FORK
실린더

54.080 LINE, SIDE SHIFT CYLINDER ANCHOR PORT
라인

54.116 LINE, SIDE SHIFT CYLINDER ROD PORT
라인

54.187 FITTING, SIDE SHIFTER ANCHOR PORT LINE
피팅

54.190 FASTENER, FORK HANGER SUPPORT
패스너

54.205 ATTACHMENT, FORK POSITIONER
어태치먼트

54.209 PLUG, FORK CYLINDER FLOW DIVIDER
플러그

54.213 BEARING, SIDE SHIFTER (UPPER)
베어링

54.224 PACKING KIT, LH FORK CYLINDER
패킹킷

54.403 FITTING-LUB, SIDE SHIFTER BASE PLATE ARM
피팅

54.446 FITTING - LUB, FORK POSITIONER
피팅

54.546 FITTING - LUB, FORK POSITIONER
피팅

54.548 HOOK, FORK POSITIONER HANGER
후크


54.549 STOP, FORK POSITIONER CYLINDER
스톱

54.552 FASTENER, FORK POSITIONER CYLINDER STOP
패스너

66.098 BEARING, FORK HORIZONTAL THRUST ROLLER
베어링

92.483 NIPPLE, LUBRICATION
니플

96.259 FASTENER, FORK CYLINDER ANCHOR END PIN RETAINER
패스너




40.343	DECAL, ATTACHMENT SAFETY *
53.016	FITTING-LUB, SIDE SHIFTER MOVABLE FRAME SUPPORT SH 피팅
53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.075	BEARING, SIDE SHIFTER (LOWER) 베어링
53.083	FASTENER, SIDE SHIFTER CYLINDER ANCHOR 패스너
53.099	SIDE SHIFTER, DEVICE 사이드쉬프트
53.182	FASTENER, SIDE SHIFTER HANGER 패스너
54.128	SPACER, SIDE SHIFTER MOVEABLE FRAME BEARING 스페이서
54.213	BEARING, SIDE SHIFTER (UPPER) 베어링

54.218 HOOK, SIDE SHIFTER HANGER
후크

54.219 SPACER, SIDE SHIFTING BASE PLATE HANGER
스페이서


54.314 SPACER, SIDE SHIFTER CYLINDER REAR
스페이서



SIDESHIFT CYLINDER **53-198**

53.020	CYLINDER ASSEMBLY, SIDE SHIFTER 실린더
53.109	GLAND, SIDE SHIFTER CYLINDER 그랜드
53.110	RETAINER, SIDE SHIFTER CYLINDER GLAND 리테이너
53.117	BUSHING, SIDE SHIFTER CYLINDER GLAND 부싱
53.215	FITTING, SIDE SHIFTER CYLINDER ROD PORT 피팅
53.676	ROD, SIDE SHIFTER CYLINDER PISTON 로드
54.222	PACKING KIT, SIDE SHIFTER CYLINDER 패킹킷
54.416	BARREL, SIDE SHIFT CYLINDER 배럴
54.556	BALL, SIDE SHIFTER CYLINDER ROD PORT *

97.241 SET SCREW, SIDE SHIFTER CYLINDER ROD PORT
*




UPRIGHT MOUNTING **66-018**

34.036 BUSHING, UPRIGHT TRUNNION
부싱

34.037 CAP, UPRIGHT TRUNNION
캡


34.038 FASTENER, UPRIGHT TRUNNION CAP
패스너

34.039 FITTING-LUB, UPRIGHT TRUNNION
피팅



34.350 FORK ASSEMBLY
포크


34.359 KIT, FORK STOP PIN (CAPTIVE)
킷




34.704 EXTENSION, FORK ASSEMBLY COMPLETE
익스텐션

66.465 PIN, EXTENTION FORK
핀


66.466 PIN, EXTENTION FORK
핀



30.956	SEAL, RELIEF VALVE PLUG 시일
33.054	PLUG, RELIEF VALVE PORT 플러그
33.055	SEAL, RELIEF VALVE PORT PLUG 시일
33.600	RELIEF VALVE, DEVICE VARIABLE PRESSURE 릴리프밸브
33.603	BRACKET, DEVICE CARIABLE RELIEF VALVE 브라켓
33.604	FASTENER, DEVICE VARIABLE RELIEF VALVE 패스너
33.617	SPACER, DEV VARIABLE RELIEF VAL BRKT 스페이서
33.661	FITTING, DEVICE RELIEF VALVE OUTLET PORT 피팅
33.701	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링
33.702	LINE, DEVICE RELIEF VALVE INLET 라인
33.703	COUPLING, DEVICE RELIEF VALVE INLET LINE 커플링
33.706	FITTING, DEVICE RELIEF VALVE INLET PORT 피팅
33.707	SEAL, DEVICE RELIEF VALVE INLET PORT FITTING 시일
33.710	FITTING, DEVICE RELIEF VALVE DISCHARGE PORT 피팅
33.711	SEAL, DEVICE RELIEF VALVE DISCHARGE PORT FTG 시일
33.712	COUPLING, DEVICE RELIEF VALVE DISCHARGE HOSE 커플링
33.713	LINE, DEVICE RELIEF VALVE DISCHARGE 라인
33.714	COUPLING, DEVICE RELIEF VALVE DISCHARGE LINE 커플링
33.732	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.733	FITTING, DEVICE RELIEF VALVE INLET 피팅
33.900	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.934	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
33.935	FITTING, DEVICE RELIEF VALVE DISCHARGE LINE 피팅
75.311	KIT, RELIEF VALVE INSTALLATION 킷
90.854	BOLT, DEVICE MOUNTING BRACKET FASTENER 볼트
90.855	LOCKWASHER, DEVICE MOUNTING BRACKET FASTENER 로크와셔
91.221	NUT, DEV VARIABLE RELIEF VALVE FASTENER 너트
91.712	LOCKWASHER, DEVICE RELIEF VALVE FASTENER 로크와셔



33.720	GAUGE, DEVICE HYDRAULIC PRESSURE 게이지
33.724	FITTING, DEVICE HYD PRESSURE GAUGE 피팅
75.301	DEVICE, HYDRAULIC PRESSURE GAUGE 디바이스



13.575 WIRE, DEV SELECTOR VALVE SWITCH FEED
와이어

18.090 CLIP, REEL WIRE HARNESS
클립

33.380 VALVE ASSEMBLY, DEVICE SELECTOR SOLENOID
벨브

33.381 FASTENER, DEVICE SELECTOR VALVE
패스너

33.382 BRACKET, DEVICE SELECTOR VALVE
브라켓

33.392 FASTENER, SECONDARY SELECTOR VALVE
패스너

33.588 CLIP, BY-PASS CLAMP LOCK VALVE
클립

33.589 FASTENER, BY-PASS CLAMP LOCK VALVE CLIP
패스너

33.761 FITTING, DEVICE SELECTOR VALVE C4 PORT
피팅

33.763 FITTING, DEVICE SELECTOR VALVE C4 PORT
피팅

33.765 LINE, DEVICE SELECTOR VALVE C4 PORT HYDRAULIC
라인

33.767 HOSE COUPLING, DEV SEL VALVE C1 PORT
호스커플링

33.773 SEAL, DEV SELECTOR VALVE C2 PORT
시일

33.778 HOSE COUPLING, DEV SEL VALVE C3 PORT
호스커플링


33.780 LINE, DEVICE SELECTOR VALVE C2 PORT HYDRAULIC
라인

33.788 BRACKET, DEVICE SEL VALVE HYDRAULIC LINE
브라켓

33.882 PLUG, DEVICE SEL VALVE "P" PORT
플러그

51.347 FITTING, SELECTOR VALVE P PORT
피팅

52.035 FITTING, SEC SEL VALVE C4 PORT LINE
피팅



39.706 SUPPORT, SEAT
서포트

39.719 SEAT ASSEMBLY
시트

75.046 KIT, SEAT ACTUATED ENGINE SHUTDOWN
킷