https://truckmanualshub.com/

UEPB005302

PARTS BOOK

KOMATSU

RUTHZIL TRATOR COMERCIAL DE PEÇAS LTDA 11 97083-6812 ROLANDO CITRANGULO

PC340LCD/ NLCD-7K

HYDRAULIC EXCAVATOR

HIGH REACH DEMOLITION MACHINE

MACHINE SERIAL NUMBER

K40575 and up

https://truckmanualshub.com/

CONTENTS

PARTS LIST

ELECTRICAL SYSTEM

E0200-01A0 : TILT CAB MAIN HARNESS (HARNESS, CLIP) 6

E0200-02A0 : TILT CAB MAIN HARNESS (CLIP).....8

E0200-03A0 : TILT CAB MAIN HARNESS (CLAMP) 10

MAIN/REVOLVING FRAME AND RELATED PARTS

J1110-01A0 : REVOLVING FRAME (TILT CAB) 14

J1110-02A0 : TILT FRAME (TILT CYLINDER AND PINS 16

J1110-03A0 : TILT FRAME (LUBRICATION PIPING) 18

J1110-04A0 : TILT FRAME (PIPING) 20

J1110-05A0 : PROXIMITY SWITCH 24

OPERATOR’S COMPARTMENT AND CONTROL SYSTEM

K0210-01A0 : OPERATOR’S CAB (FRONT WINDOW) 28

K0210-02A0 : OPERATOR’S CAB (ROOF WINDOW) 32

K0210-03A0 : OPERATOR’S CAB (DOOR LOCK) 34

K0210-04A0 : OPERATOR’S CAB (OPEN LOCK) 36

K0210-05A0 : OPERATOR’S CAB (ACCESSORIES) 38

K0210-06A0 : OPERATOR’S CAB (BLIND BOLT) 40

K0210-07A0 : OPERATOR’S CAB (ROOF WIPER) 42

K0210-08A0 : OPERATOR’S CAB (ROOF WIPER HOSE).....44

K0210-09A0 : OPERATOR’S CAB (CONTROL PANEL) 46

K0220-01A0 : OPG GUARD.....48

K0350-01A0 : WINDOW WASHER TANK G. 50

K1110-01A0 : FLOOR (FLOOR FRAME)(TILT CAB) 52

https://truckmanualshub.com/

K1110-02A0 : FLOOR (CONTROL GROUP)(TILT CAB) 54
K1110-03A0 : FLOOR (A/C HOSE)(TILT CAB) 56
K1110-04A0 : FLOOR (HEATER HOSE)(TILT CAB) 58
K1110-05A0 : FLOOR (PPC)(TILT CAB)(1/2) 60
K1110-06A0 : FLOOR (PPC)(TILT CAB)(2/2) 62
K1110-07A0 : SAFETY VALVE LINE 64
K1110-08A0 : TILT CAB HYDRAULICS (A) 66
K1110-09A0 : TILT CAB HYDRAULICS (B) 70
K1110-10A0 : TILT CAB HYDRAULICS (C) 74

GUARD

M1120-01A0 : FRAME (MACHINE CAB) 78
M1210-01A0 : COVER (UPPER)(MACHINE CAB) 80
M1510-01A0 : COUNTER WEIGHT 82
M1810-01A0 : DEMO CAB UNDERCOVERS (L.H.) 84
M1810-02A0 : DEMO CAB UNDERCOVERS (R.H.) 86
M1810-03A0 : DEMO CAB SIDE GUARDS 88
M1810-04A0 : TILT CAB UNDERCOVERS (R.H.) 90
M1810-05A0 : TILT CAB UNDERCOVERS (L.H.) 92
M1810-06A0 : TILT CAB SIDE GUARDS 94
M1810-07A0 : TILT CAB COVERS (CAB) 96

UNDERCARRIAGE

R1000-01A0 : HYDRAULIC TRACK FRAME 100
R1000-02A0 : HYD. TRACK FRAME CONTROL PIPING 102

WORK EQUIPMENT

T1110-01A0 : 1ST, 2ND, 3RD BOOM PINS AND BUSHINGS 106
T1110-02A0 : 1ST BOOM LUBE PIPING 108
T1110-03A0 : 1ST BOOM PIPING 110

https://truckmanualshub.com/

T1110-04A0 : 1ST BOOM PIPING CLAMPS 112
T1110-05A0 : 1ST BOOM QUICK CHANGE UNIT 116
T1110-06A0 : 1ST BOOM WORKLAMP 118
T1110-07A0 : 1ST BOOM ANGLE INDICATOR 120
T1110-08A0 : 2ND BOOM PIPING 122
T1110-09A0 : 3RD BOOM PIPING 124
T1110-10A0 : 1ST, 2ND, 3RD BOOM FASTER PIPING 128
T1110-11A0 : 1ST, 2ND, 3RD BOOM FASTER PIPE CLAMPS 132
T1110-12A0 : MID LINK PINS AND BUSHINGS 137
T1110-13A0 : DIG BOOM PIPING 139
T1120-01A0 : MID LINK CYLINDER DETAIL 143
T1140-01A0 : ARM CYLINDER DETAIL 147
T1210-01A0 : ARM PINS AND BUSHINGS 151
T1210-02A0 : MID LINK AND ARM PIPING 153
T1210-03A0 : MID LINK AND ARM PIPING CLAMPS 157
T1210-04A0 : MID LINK AND ARM CYLINDER S/V PIPING 159
T1210-05A0 : ARM 3.2M (DIG BOOM) 163
T1210-05A0 : ARM 2.5M (DIG BOOM) 165
T1220-01A0 : ATTACHMENT CYLINDER DETAIL 167
T1230-01A0 : LINK PINS AND BUSHINGS 169
X1000-01A0 : TRANSPORT PIN 171
X1000-02A0 : HIGH REACH WORK EQUIPMENT STANDS 173
X1000-03A0 : DIG BOOM STAND 175

https://truckmanualshub.com/

PC340LCD/NLCD-7K
HIGH REACH DEMOLITION
MACHINE PARTS LIST


https://truckmanualshub.com/

https://truckmanualshub.com/

ELECTRICAL SYSTEM

https://truckmanualshub.com/

E0200-01A0 : TILT CAB MAIN HARNESS (HARNESS, CLIP)




https://truckmanualshub.com/

E0200-01A0 : TILT CAB MAIN HARNESS (HARNESS, CLIP)

Item	Part No.	Description	Qty	Options
1	207-06-KA460	WIRING HARNESS	1	
	22U-06-11270	• FUSIBLE LINK(65A)	1	
	20Y-06-31660	• FUSIBLE LINK (30A)	2	
2	04434-51912	CLIP	1	
3	04434-51012	CLIP	1	
4	01010-81225	BOLT	1	
5	01643-31232	WASHER	1	
6	04434-51912	CLIP	1	
7	01010-81225	BOLT	1	
8	01643-31232	WASHER	1	
9	04434-51012	CLIP	1	
10	01010-81225	BOLT	1	
11	01643-31232	WASHER	1	
12	01010-81025	BOLT	1	
13	01643-31032	WASHER	1	
14	04434-51712	CLIP	6	
15	01010-81225	BOLT	6	
16	01643-31232	WASHER	6	
17	04434-51012	CLIP	5	
18	01010-81225	BOLT	5	
19	01643-31232	WASHER	5	
20	04434-51012	CLIP	3	
21	01010-81225	BOLT	3	
22	01643-31232	WASHER	3	
23	04434-51912	CLIP	3	
24	04434-52712	CLIP	1	
25	04434-51712	CLIP	1	
26	01010-81225	BOLT	1	
27	01643-31232	WASHER	1	
28	04434-52312	CLIP	1	
29	04434-51712	CLIP	1	
30	04434-52112	CLIP	2	
31	01010-81220	BOLT	1	
32	01643-31232	WASHER	1	
33	01010-81225	BOLT	1	
34	01643-31232	WASHER	1	
35	04434-51512	CLIP	1	
36	01010-81225	BOLT	1	
37	01643-31232	WASHER	1	
38	08034-20519	BAND	1	

https://truckmanualshub.com/

E0200-02A0 : TILT CAB MAIN HARNESS (CLIP)




https://truckmanualshub.com/

E0200-02A0 : TILT CAB MAIN HARNESS (CLIP)

Item	Part No.	Description	Qty	Options
1	04434-51412	CLIP	3	
2	01010-81225	BOLT	3	
3	01643-31232	WASHER	3	
4	04434-51412	CLIP	1	
5	01010-81225	BOLT	1	
6	01643-31232	WASHER	1	
8	04434-53212	CLIP	1	
9	01010-81225	BOLT	2	
10	01643-31232	WASHER	2	
11	04434-53212	CLIP	1	
12	01010-81225	BOLT	1	
13	01643-31232	WASHER	1	
14	04434-52312	CLIP	1	
15	01010-81225	BOLT	1	
16	01643-31232	WASHER	1	
16A	08034-20519	BAND	1	
17	01010-81020	BOLT	6	
18	01643-31032	WASHER	6	
19	04434-51712	CLIP	2	
20	01010-81225	BOLT	2	
21	01643-31232	WASHER	2	
22	04435-50812	CLIP	1	
23	04434-51012	CLIP	1	
24	01010-81225	BOLT	2	
25	01643-31232	WASHER	2	
26	04434-51712	CLIP	2	
27	01010-81225	BOLT	2	
28	01643-31232	WASHER	2	
29	08193-21012	CLIP	1	
30	01010-81225	BOLT	1	
31	01643-31232	WASHER	1	
32	04434-51412	CLIP	3	
33	01010-81225	BOLT	3	
34	01643-31232	WASHER	3	
35	04434-51412	CLIP	2	
36	08034-20519	BAND	1	

https://truckmanualshub.com/

E0200-03A0 : TILT CAB MAIN HARNESS (CLAMP)



https://truckmanualshub.com/

E0200-03A0 : TILT CAB MAIN HARNESS (CLAMP)

Item	Part No.	Description	Qty	Options
1	207-06-KA460	WIRING HARNESS	1	
2	07145-00075	SEAL,DUST	4	
3	07143-10707	BUSHING	2	
4	207-06-KA440	BRACKET	1	
5	01010-81230	BOLT	2	
6	01643-31232	WASHER	2	
7	207-06-KA450	BRACKET	1	
8	01010-81230	BOLT	2	
9	01643-31232	WASHER	2	
10	01010-81025	BOLT	6	
11	01643-31032	WASHER	6	
12	20Y-06-81750	COVER	1	
13	01010-81220	BOLT	2	
14	01643-31232	WASHER	2	
15	04434-53412	CLIP	1	
16	142-03-11160	SPACER	1	
17	04435-52212	CLIP	1	
18	04434-53412	CLIP	1	
19	01010-81255	BOLT	1	
20	01643-31232	WASHER	1	
21	142-03-11160	SPACER	1	
22	04435-52212	CLIP	1	
23	01010-81255	BOLT	1	
24	01643-31232	WASHER	1	
25	207-70-KD280	PLATE	1	
26	01010-81220	BOLT	2	
27	01643-31232	WASHER	2	
28	04434-52512	CLIP	1	
29	01010-81220	BOLT	2	
30	01643-31232	WASHER	2	
31	207-979-KB20	HOSE ASSY	1	
32	207-979-KB40	HOSE ASSY	1	
33	207-979-KA90	HOSE	1	
34	207-979-KB10	HOSE	1	
35	207-62-KC200	HOSE ASSY	1	
36	207-62-KC100	HOSE ASSY	1	
37	207-62-KC300	HOSE ASSY	1	
38	207-62-4140	HOSE ASSY	1	
39	207-62-KC180	HOSE ASSY	1	
40	207-62-K4150	HOSE ASSY	1	


https://truckmanualshub.com/

https://truckmanualshub.com/

MAIN/REVOLVING FRAME AND RELATED PARTS

https://truckmanualshub.com/

J1110-01A0 : REVOLVING FRAME (TILT CAB)




https://truckmanualshub.com/

J1110-01A0 : REVOLVING FRAME (TILT CAB)

Item	Part No.	Description	Qty	Options
1	207-46-KA520	TILT REVO FRAME	1	
2	207-54-KA930	FRAME	1	

https://truckmanualshub.com/

J1110-02A0 : TILT FRAME (TILT CYLINDER AND PINS




https://truckmanualshub.com/

J1110-02A0 : TILT FRAME (TILT CYLINDER AND PINS)

Item	Part No.	Description	Qty	Options
1	207-70-KC650	PIN	2	
2	01010-82035	BOLT	2	
3	01643-32060	WASHER	2	
4	207-70-KD250	SPACER	2	
5	207-70-KD210	SHIM	5	
6	207-70-KD220	SHIM	5	
7	207-70-KC660	PIN	2	
8	207-54-KB250	PLATE	2	
9	01010-81220	BOLT	4	
10	01643-31232	WASHER	4	
11	207-70-KC670	PIN	2	
12	207-54-KB250	PLATE	2	
13	01010-81220	BOLT	4	
14	01643-31232	WASHER	4	
15	207-70-KD230	SHIM	19	
16	207-70-KD240	SHIM	7	
17	207-54-KB220	BRACKET	2	
18	01010-81645	BOLT	8	
19	01643-31645	WASHER	8	
20	207-70-KC680	SHIM	5	
21	207-70-KC690	SHIM	5	
22	207-70-KD270	SHIM	10	
23	207-63-KA381	CYLINDER ASSY	2	

https://truckmanualshub.com/

J1110-03A0 : TILT FRAME (LUBRICATION PIPING)




https://truckmanualshub.com/

J1110-03A0 : TILT FRAME (LUBRICATION PIPING)

Item	Part No.	Description	Qty	Options
1	207-70-KD290	ADAPTER	6	
2	207-70-KD311	HOSE	2	
3	207-70-KD320	HOSE	2	
4	207-70-KD330	HOSE	1	
5	207-70-KD340	HOSE	1	
6	20Y-54-83760	ADAPTER	6	
7	20Y-54-83780	ELBOW	6	
8	07020-00000	FITTING	6	

https://truckmanualshub.com/

J1110-04A0 : TILT FRAME (PIPING)



https://truckmanualshub.com/

J1110-04A0 : TILT FRAME (PIPING)

Item	Part No.	Description	Qty	Options
1	07637-00315	HOSE	1	
2	07086-00325	HOSE	2	
3	07086-00522	HOSE	2	
4	07633-00320	HOSE	1	
5	07086-00520	HOSE	2	
6	07102-20520	HOSE	1	
7	07102-00507	HOSE	1	
8	207-06-KA510	WIRING HARNESS	2	
9	207-06-KA370	WIRING HARNESS	2	
10	21M-970-K990	VALVE ASSY	2	
11	21M-970-K840	BOLT KIT	1	
12	207-62-KB440	BOLT KIT	1	
13	207-62-KD240	PLATE	1	
14	207-62-KB430	VALVE ASSY	2	
15	207-62-KB450	BLOCK	2	
16	01010-81235	BOLT	4	
17	01643-31232	WASHER	4	
18	207-46-KA561	PLATE	1	
19	01010-81030	BOLT	2	
20	01643-31032	WASHER	2	
21	201-62-71810	JOINT	1	
22	07235-10522	ELBOW	1	
23	07002-12434	O-RING	2	
24	07235-10522	ELBOW	1	
25	07002-12434	O-RING	1	
26	07235-10522	ELBOW	2	
27	07002-12434	O-RING	2	
28	201-62-71810	JOINT	1	
29	207-62-56270	ELBOW	1	
30	07235-10522	ELBOW	1	
31	07002-12434	O-RING	3	
32	07235-10522	ELBOW	1	
33	07002-12434	O-RING	1	
34	209-62-57210	TEE	2	
35	07002-12034	O-RING	2	
36	207-46-KA390	BRACKET	1	
37	11Y-62-12820	TEE	1	
38	07002-11423	O-RING	1	
39	02896-11008	O-RING	1	
40	02896-11009	O-RING	1	
41	02760-00206	HOSE	2	
42	20Y-62-43460	NIPPLE	2	
43	07002-12034	O-RING	6	
44	02896-11008	O-RING	6	
45	198-33-12380	WASHER	4	
46	01010-81090	BOLT	4	
47	01643-31032	WASHER	4	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	11Y-62-12170	ELBOW	4	
49	702-19-22000	CHECK VALVE ASSY	2	
50	07040-12012	PLUG	4	
51	07002-12034	O-RING	4	
52	07235-10311	ELBOW	4	
53	07002-21423	O-RING	4	
54	07235-10522	ELBOW	4	
55	07002-12434	O-RING	4	
56	207-62-KB410	BLOCK	2	
57	07000-13025	O-RING	2	
58	01252-80850	BOLT	2	
59	207-62-61680	TEE	1	
60	07002-11423	O-RING	2	
61	02781-00210	NIPPLE	1	
62	02896-11008	O-RING	1	
63	207-62-56270	ELBOW	1	
64	07002-12434	O-RING	1	
65	207-06-KA370	WIRING HARNESS	1	
66	20G-60-K1301	VALVE ASSY	1	
67	01010-81065	BOLT	2	
68	01643-31032	WASHER	2	
69	02760-00214	HOSE	2	
70	207-46-KA370	PLATE	1	
71	01010-81240	BOLT	2	
72	01643-31232	WASHER	2	
73	02760-00210	HOSE	1	
74	02782-00210	ELBOW	2	
75	07002-11423	O-RING	4	
76	02896-11008	O-RING	4	
77	02760-00233	HOSE	1	
78	02782-00212	ELBOW	2	

https://truckmanualshub.com/

https://truckmanualshub.com/

J1110-05A0 : PROXIMITY SWITCH



https://truckmanualshub.com/

J1110-XXXX : PROXIMITY SWITCH

Item	Part No.	Description	Qty	Options
1	207-62-66571	BRACKET	1	
2	01010-81025	BOLT	2	
3	01643-31032	WASHER	2	
4	01010-80812	BOLT	1	
5	01643-30823	WASHER	1	
6	207-818-K552	SWITCH	1	
7	207-06-KA540	WIRING HARNESS	1	
8	04434-51012	CLIP	1	
9	01010-81220	BOLT	1	
10	01643-31232	WASHER	1	
11	207-06-81560	WIRING HARNESS	1	
12	04434-51012	CLIP	1	
13	01010-81220	BOLT	1	
14	01643-31232	WASHER	1	
15	04434-51012	CLIP	3	
16	01010-80812	BOLT	3	
17	01643-30823	WASHER	3	
18	08034-20519	BAND	24	
19	KV-A56-4241	BRACKET	1	
20	01010-81025	BOLT	2	
21	01643-31032	WASHER	2	


https://truckmanualshub.com/

https://truckmanualshub.com/

OPERATOR'S COMPARTMENT AND CONTROL SYSTEM

https://truckmanualshub.com/

K0210-01A0 : OPERATOR'S CAB (FRONT WINDOW)



https://truckmanualshub.com/

K0210-01A0 : OPERATOR'S CAB (FRONT WINDOW)

Item	Part No.	Description	Qty	Options
	20Y-54-01510	CAB ASSY	1	
	20Y-54-01520	• WINDOW ASSY	1	
1	20Y-54-54720	•• FRONT FRAME, (WINDOW)	1	
2	20Y-54-51522	•• GLASS (FRONT)	1	
3	20Y-54-51531	•• SEAL (DAM/FRONT W)	1	
4	20Y-54-51551	•• SEAL (FRONT/W LOWER)	1	
5	22B-54-15411	•• LOCK A. (L.H)	1	
6	22B-54-15440	•• CASE (L.H)	1	
7	22B-54-15470	•• KNOB (L.H)	1	
8	22B-54-15421	•• LOCK A. (R.H)	1	
9	22B-54-15450	•• CASE (R.H)	1	
10	22B-54-15480	•• KNOB (R.H)	1	
11	01435-40812	•• BOLT	2	
12	01435-40812	•• BOLT	2	
13	20Y-54-52621	•• ROLLER	2	
14	20Y-54-62681	•• ROLLER	2	
15	20Y-54-52691	•• PIN (L.H/UNDER)	1	
16	20Y-54-14590	•• HANDLE	2	
17	01023-10616	•• SCREW	4	
18	20Y-54-52632	•• BRACKET	1	
19	20Y-54-52642	•• BRACKET	1	
20	01245-00616	•• BOLT	6	
21	01643-70623	•• WASHER	6	
22	20Y-54-51670	• STOPPER	1	
23	20Y-54-51680	• STOPPER	1	
24	01252-80616	• BOLT	4	
25	01643-70623	• WASHER	4	
26	20Y-54-51633	• BLOCK (UNDER/L.H)	1	
27	20Y-54-52192	• BLOCK (UNDER/R.H)	1	
28	01252-80620	• BOLT	4	
29	01641-50608	• WASHER	4	
30	20Y-54-51652	• BLOCK (L.H)	1	
31	20Y-54-52282	• BLOCK (L.H)	1	
32	20Y-54-51663	• BLOCK (CORNER/R.H)	1	
32A	20Y-54-52940	• PLATE	1	
33	22B-54-15621	• STOPPER	2	
34	01224-70612	• SCREW	3	
35	01252-80616	• BOLT	4	
36	01641-50608	• WASHER	4	
37	22B-54-15432	• STRIKER (F/SASH)	2	
38	01435-40616	• BOLT	4	
39	21J-06-12440	• SWITCH	1	
40	01583-11811	• NUT	1	
41	20Y-54-11611	• STOPPER	2	
42	01580-11008	• NUT	2	
43	20Y-54-52491	• PLATE	1	
44	01435-40612	• BOLT	2	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
45	20Y-54-51621	• STRIKER	2	
46	20Y-54-51541	• TRIM SEAL (FRONT/W)	1	
47	20Y-54-51591	• SPRING ASSY	1	
48	01435-00616	• BOLT	2	
49	20Y-54-51640	• HOLDER	1	
50	20Y-54-51420	• SEAL	2	

https://truckmanualshub.com/

https://truckmanualshub.com/

K0210-02A0 : OPERATOR’S CAB (ROOF WINDOW)




https://truckmanualshub.com/

K0210-02A0 : OPERATOR'S CAB (ROOF WINDOW)

Item	Part No.	Description	Qty	Options
1	20Y-54-54640	GLASS	1	
2	20Y-54-54430	PLATE	1	
3	20Y-54-53421	SEAL	1	
4	20Y-54-54440	SHEET	1	
5	22B-54-18171	SHEET	1	
6	363-54-22140	CAP	9	
7	01643-70623	WASHER	9	

https://truckmanualshub.com/

K0210-03A0 : OPERATOR'S CAB (DOOR LOCK)




https://truckmanualshub.com/

K0210-03A0 : OPERATOR'S CAB (DOOR LOCK)

Item	Part No.	Description	Qty	Options
	20Y-54-01122	DOOR ASSY	1	
1	20Y-54-52200	LATCH ASSY	1	
2	20Y-54-52300	HANDLE ASSY	1	
3	20Y-54-52400	BELLCRANK ASSY	1	
4	01023-10612	SCREW	8	
5	20Y-54-52990	HANDLE	1	
6	01023-10612	SCREW	2	
7	01240-00616	SCREW	3	
8	195-Z11-1690	WASHER	3	
9	20Y-54-52820	LOCK ASSY	1	
10	20Y-54-51441	COVER	1	
11	22B-54-16461	RIVET	7	
12	207-54-KB340	STRIKER	1	
13	20Y-54-51341	PLATE	1	
14	01584-01008	NUT	2	
15	20Y-54-51490	COVER,STRIKER	1	
16	20Y-54-51392	GRIP,DOOR	1	
17	01010-B0820	BOLT	2	
18	01643-70823	WASHER	2	

https://truckmanualshub.com/

K0210-04A0 : OPERATOR’S CAB (OPEN LOCK)




https://truckmanualshub.com/

K0210-04A0 : OPERATOR'S CAB (OPEN LOCK)

Item	Part No.	Description	Qty	Options
	20Y-54-01510	CAB ASSY	1	
1	20Y-54-36380	LOCK	1	
2	01435-30820	BOLT	4	
3	20Y-54-51801	LEVER	1	
4	20Y-54-51972	PLATE	1	
5	20Y-54-51941	STOPPER	1	
6	01023-70616	SCREW	2	
7	20Y-54-51930	COVER,LOCK	1	
8	20Y-54-51941	STOPPER	2	
9	01580-11008	NUT	2	
10	20Y-54-51910	TRIM	1	
11	20Y-54-35470	STRIKER	1	
12	20Y-54-35480	SHIM	1	
13	01240-01025	SCREW	2	
14	207-54-KB350	JOINT	2	

https://truckmanualshub.com/

K0210-05A0 : OPERATOR'S CAB (ACCESSORIES)




https://truckmanualshub.com/

K0210-05A0 : OPERATOR'S CAB (ACCESSORIES)

Item	Part No.	Description	Qty	Options
1	20Y-54-53212	COVER (ROOF)	1	
2	20Y-54-18690	RIVET	20	
3	20Y-54-52422	LINING (R.H)	1	
4	20Y-54-18690	RIVET	6	
5	20Y-54-52432	LINING (L.H)	1	
6	205-54-51250	HANGAR	1	
7	01225-70412	SCREW	2	
	20Y-54-53290	COVER ASSY	1	
8	20Y-54-53232	RAIL	1	
9	20Y-54-53242	COVER	1	
10	01023-10410	SCREW	6	
11	20Y-54-53250	TRIM	1	
12	20Y-54-53330	SPACER	1	
13	20Y-54-52122	PLATE	1	
14	01435-00616	BOLT	3	

https://truckmanualshub.com/

K0210-06A0 : OPERATOR’S CAB (BLIND BOLT)




https://truckmanualshub.com/

K0210-06A0 : OPERATOR'S CAB (BLIND BOLT)

Item	Part No.	Description	Qty	Options
1	20Y-54-52440	CAP BOLT	3	
2	22B-54-17282	CAP	2	
3	09415-02512	CAP	2	
4	01245-01220	SCREW	6	
5	01643-71232	WASHER	6	
6	01245-01220	SCREW	9	
7	01643-71232	WASHER	9	
8	124-911-5750	RIVET	2	
9	01245-01016	SCREW	2	
10	01643-71032	WASHER	2	
11	01245-00612	SCREW	4	
12	01643-70623	WASHER	4	
13	20Y-54-62470	GROMMET	1	
14	20Y-54-36150	GROMMET	1	
15	01370-10308	SCREW	4	

https://truckmanualshub.com/

K0210-07A0 : OPERATOR'S CAB (ROOF WIPER)




https://truckmanualshub.com/

K0210-07A0 : OPERATOR'S CAB (ROOF WIPER)

Item	Part No.	Description	Qty	Options
1	421-56-21530	WIPER MOTOR	1	
2	01010-D0816	BOLT	2	
3	01643-70823	WASHER	2	
4	01010-D1020	BOLT	4	
5	01643-71032	WASHER	4	
6	22B-54-18541	COVER	1	
7	01010-D0816	BOLT	4	
8	01643-70823	WASHER	4	
9	14X-911-3330	WIPER BLADE	1	
10	22B-54-18420	WIPER ARM	1	
11	22B-54-18430	WIRING HARNESS	1	
12	22B-54-18550	GROMMET	1	
13	04434-50610	CLAMP	1	
14	01010-D1016	BOLT	1	
15	01643-71032	WASHER	1	
16	20Y-54-54420	WIRING HARNESS	1	

https://truckmanualshub.com/

K0210-08A0 : OPERATOR’S CAB (ROOF WIPER HOSE)




https://truckmanualshub.com/

K0210-08A0 : OPERATOR’S CAB (ROOF WIPER HOSE)

Item	Part No.	Description	Qty	Options
1	20Y-54-39511	NOZZLE	1	
2	01023-20412	SCREW	2	
3	20Y-54-54140	HOSE	1	
4	08037-01610	GROMMET	1	
5	20Y-54-52340	WIRING HARNESS	1	

https://truckmanualshub.com/

K0210-09A0 : OPERATOR’S CAB (CONTROL PANEL)




https://truckmanualshub.com/


K0210-09A0 : OPERATOR'S CAB (CONTROL PANEL)

Item	Part No.	Description	Qty	Options
1	207-43-KA120	PANEL	1	
2	01245-00820	SCREW	2	
3	01245-00816	SCREW	2	
4	01643-70823	WASHER	4	
5	207-43-81150	BRACKET	1	
6	01010-81025	BOLT	2	
7	01643-31032	WASHER	2	

https://truckmanualshub.com/

K0220-01A0 : OPG GUARD






https://truckmanualshub.com/

K0220-01A0 : OPG GUARD

Item	Part No.	Description	Qty	Options
1	20Y-954-KA11	GUARD TOP	1	
2	175-54-34170	WASHER	8	
3	20Y-954-KA21	BRACKET	1	
4	01011-81240	BOLT	4	
5	01011-81210	BOLT	3	
6	01643-31232	WASHER	6	
7	130-43-64260	COLLAR	6	
8	20Y-954-KA31	BRACKET	1	
9	01010-81020	BOLT	4	
10	01643-31032	WASHER	4	
11	20Y-954-KA41	BRACKET	2	
12	01011-81215	BOLT	1	
13	01643-31232	WASHER	2	
14	130-43-64260	COLLAR	2	
15	01010-81250	BOLT	6	
16	01643-31232	WASHER	6	
17	130-43-64260	COLLAR	6	
18	195-Z11-2970	CAP	6	

https://truckmanualshub.com/

K0350-01A0 : WINDOW WASHER TANK G.




https://truckmanualshub.com/

K0350 - 01A0 : WINDOW WASHER TANK G.

Item	Part No.	Description	Qty	Options
1	207-067-1810	BRACKET	1	
	175-54-34170	BOLT SEMS		
2	20Y-954-KA21	BOLT (DLF)	2	
3	01011-81240	WASHER	2	
4	14X-911-1160	WASHER TANK	1	
	0102480616	BOLT SEMS		
5	0101080616	BOLT DLF	2	
6	0164330623	WASHER	2	
7	20Y-0622520	HOSE	1	
8	207-06-KA470	HOSE	1	
9	1959798590	VALVE	2	
10	20Y-06-31730	WIRING HARNESS	1	

https://truckmanualshub.com/

K1110-01A0 : FLOOR (FLOOR FRAME)(TILT CAB)




https://truckmanualshub.com/

K1110-01A0 : FLOOR (FLOOR FRAME)(TILT CAB)

Item	Part No.	Description	Qty	Options
1	207-54-KB530	FLOOR FRAME	1	
2	20Y-54-65121	GROMMET	1	
3	207-54-71190	GROMMET	1	
4	20Y-54-65170	GROMMET	2	
5	22U-54-25581	GROMMET	1	
6	22U-54-25590	GROMMET	1	
7	07286-03828	HOSE	1	
8	07280-04726	CLAMP	1	
9	07048-01310	PLUG	2	
10	01010-81030	BOLT	2	
11	01643-31032	WASHER	2	
12	01010-81020	BOLT	1	
13	01643-31032	WASHER	1	
14	01010-D0816	BOLT	4	
15	01643-70823	WASHER	4	

https://truckmanualshub.com/

K1110-02A0 : FLOOR (CONTROL GROUP)(TILT CAB)




https://truckmanualshub.com/

K1110-02A0 : FLOOR (CONTROL GROUP)(TILT CAB)

Item	Part No.	Description	Qty	Options
1	207-62-K4170	HOSE	1	
2	207-62-K4160	HOSE	1	
3	207-62-K4160	HOSE	1	
4	207-62-K4180	HOSE	1	

https://truckmanualshub.com/

K1110-03A0 : FLOOR (A/C HOSE)(TILT CAB)




https://truckmanualshub.com/

K1110-03A0 : FLOOR (A/C HOSE)(TILT CAB)

Item	Part No.	Description	Qty	Options
1	20Y-979-6281	HOSE	1	
2	20Y-979-6291	HOSE	1	
3	207-979-KA90	HOSE	1	
4	20Y-979-3150	O-RING	2	
5	207-979-KB10	HOSE	1	
6	20Y-64-3130	O-RING	2	

https://truckmanualshub.com/

K1110-04A0 : FLOOR (HEATER HOSE)(TILT CAB)




https://truckmanualshub.com/

K1110-04A0 : FLOOR (HEATER HOSE)(TILT CAB)

Item	Part No.	Description	Qty	Options
1	207-979-KB20	HOSE	1	
2	207-979-KB40	HOSE	1	
3	09480-10100	CLAMP	2	

https://truckmanualshub.com/

K1110-05A0 : FLOOR (PPC)(TILT CAB)(1/2)




https://truckmanualshub.com/

K1110-05A0 : FLOOR (PPC)(TILT CAB)(1/2

Item	Part No.	Description	Qty	Options
	207-62-KC100	HOSE ASSY	1	
1	08034-00536	BAND	1	
2	207-62-KC140	HOSE	1	
3	207-62-KC150	HOSE	1	
4	207-62-KC160	HOSE	1	
5	207-62-KC170	HOSE	1	
6	20Y-62-22790	BAND (RED)	2	
7	20Y-62-22820	BAND (BLUE)	2	
8	20Y-62-22850	BAND (GREEN)	2	
	20Y-62-41471	HOSE ASSY	1	
9	02760-00211	HOSE	1	
10	08034-00519	BAND	2	
11	20Y-62-22790	BAND (RED)	2	
12	20Y-62-22820	BAND (BLUE)	2	
13	20Y-62-42251	HOSE	1	

https://truckmanualshub.com/

K1110-06A0 : FLOOR (PPC)(TILT CAB)(2/2)




https://truckmanualshub.com/

K1110-06A0 : FLOOR (PPC)(TILT CAB)(2/2)

Item	Part No.	Description	Qty	Options
	207-62-KC180	HOSE ASSY	1	
1	02760-00320	HOSE	1	
2	207-62-KC190	HOSE	1	
3	20Y-62-22790	BAND (RED)	2	
	207-62-KC200	HOSE ASSY	1	
4	08034-20536	BAND (T50L BLK)	2	
5	20Y-62-42230	HOSE	1	
6	20Y-62-42240	HOSE	1	
7	207-62-KC220	HOSE	1	
8	207-62-KC190	HOSE	2	
9	207-62-KC210	HOSE	1	
10	207-62-22790	BAND (RED)	2	
11	20Y-62-22810	BAND (YELLOW)	2	
12	20Y-62-22820	BAND (BLUE)	4	
	207-62-KC300	HOSE ASSY	1	
13	207-62-KC230	HOSE	1	
14	207-62-KC240	HOSE	1	
15	207-62-KC250	HOSE	1	
16	207-62-42210	HOSE	1	
17	207-62-42220	HOSE	1	
18	207-62-KC260	HOSE	1	
19	20Y-62-22790	BAND (RED)	2	
20	20Y-62-22820	BAND (BLUE)	2	
21	20Y-62-22830	BAND (WHITE)	2	
22	20Y-62-22840	BAND (BLACK)	2	
23	20Y-62-22850	BAND (GREEN)	2	
24	20Y-62-22860	BAND (BROWN)	2	
25	08034-00519	BAND (T50R)	1	

https://truckmanualshub.com/

K1110-07A0 : SAFETY VALVE LINE




https://truckmanualshub.com/

K1110-07A0 : SAFETY VALVE LINE

Item	Part No.	Description	Qty	Options
1	02762-00319	HOSE	1	
2	02753-00224	HOSE	1	
3	02762-00518	HOSE	1	
4	11Y-62-12250	TEE	1	
5	07002-11423	O-RING	1	
6	02896-11008	O-RING	2	
7	02782-10522	ELBOW	1	
8	07002-12434	O-RING	1	
9	02896-11015	O-RING	1	
10	20Y-62-43460	NIPPLE	1	
11	07002-12034	O-RING	1	
12	02896-11008	O-RING	1	
13	02781-00516	UNION	1	
14	07002-12034	O-RING	1	
15	02896-11015	O-RING	1	
16	02781-00315	UNION	1	
17	07002-12034	O-RING	1	
18	20Y-62-43640	TEE	1	
19	21W-62-42490	ELBOW	2	
20	11Y-62-12520	UNION	1	
21	20Y-60-22210	BODY	1	
22	07002-11423	O-RING	5	
23	02896-11009	O-RING	2	

https://truckmanualshub.com/

K1110-08A0 : TILT CAB HYDRAULICS (A)



https://truckmanualshub.com/

K1110-08A0 : TILT CAB HYDRAULICS (A)

Item	Part No.	Description	Qty	Options
1	207-62-84310	CLAMP	4	
2	207-62-84320	PLATE	4	
3	01010-81295	BOLT	12	
4	01643-31232	WASHER	24	
5	01580-11210	NUT	12	
6	07040-11812	PLUG	1	
7	07002-01823	O-RING	1	
8	07283-33442	CLIP	4	
9	01643-31032	WASHER	8	
10	01597-01009	NUT	8	
11	207-62-84281	BRACKET	1	
12	01010-81035	BOLT	4	
12	01643-31032	WASHER	4	
13	04434-51212	CLIP	2	
14	01010-81220	BOLT	2	
14	01643-31232	WASHER	2	
16	08034-20519	BAND	2	
17	02760-002A5	HOSE	1	
18	04435-51212	CLIP	1	
19	01010-81225	BOLT	1	
19	01643-31232	WASHER	1	
20	207-60-81170	COVER	1	
21	02782-10522	ELBOW	1	
22	07002-12434	O-RING	1	
23	02896-11015	O-RING	1	
24	02762-00507	HOSE	1	
25	04434-52512	CLIP	2	
26	01010-81225	BOLT	1	
26	01643-31232	WASHER	1	
27	02781-00522	UNION	1	
28	07002-12434	O-RING	1	
29	02896-11015	O-RING	1	
30	207-62-66560	BLOCK	1	
31	01010-81230	BOLT	4	
31	01643-31232	WASHER	4	
32	02896-11009	O-RING	1	
33	07002-11823	O-RING	1	
34	02782-10313	ELBOW	1	
35	07098-00520	DDC HOSE	1	
36	07000-13022	O-RING	2	
37	07371-30500	FLANGE	4	
38	01010-80830	BOLT	8	
38	01643-30823	WASHER	8	
39	07379-00500	FLANGE	1	
40	0709801021	HOSE	2	
41	07000-13032	O-RING	4	
42	07371-31049	FLANGE	4	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
43	07372-21035	BOLT	16	
43	01643-51032	WASHER	16	
44	07379-01044	FLANGE	2	
45	207-62-84360	FRAME	1	
46	01010-81240	BOLT	2	
46	01643-31232	WASHER	2	
47	01010-81245	BOLT	2	
47	01643-31232	WASHER	2	
48	01010-81235	BOLT	1	
48	01643-31232	WASHER	1	
49	02761-00206	HOSE	1	
50	11Y-62-12250	TEE	1	
51	07002-11423	O-RING	1	
52	02896-11008	O-RING	1	
53	02763-00405	HOSE	2	
54	02782-1021A	ELBOW	1	
55	07002-11423	O-RING	1	
56	02896-11008	O-RING	1	
57	11Y-62-12330	TEE	1	
58	07002-11423	O-RING	1	
59	02896-11008	O-RING	1	
61	02760-00207	HOSE	1	
62	02782-10210	ELBOW	1	
63	07002-11423	O-RING	1	
64	02896-11008	O-RING	1	
65	207-62-84450	DDC HOSE ASSY	1	
66	207-62-84410	HOSE ASSY	1	
67	08034-20536	BAND (T50L BLK)	1	
68	207-62-84440	DDC HOSE ASSY	1	
69	207-62-84460	HOSE ASSY	1	
70	04434-51512	CLIP	1	
71	01010-81260	BOLT	1	
71	01643-31232	WASHER	1	
72	142-03-11160	SPACER	1	
73	207-62-84470	HOSE ASSY	1	
74	207-62-84330	HOSE ASSY	1	
75	207-62-84340	HOSE ASSY	1	
76	08034-20536	BAND (T50L BLK)	1	

https://truckmanualshub.com/

https://truckmanualshub.com/

K1110-09A0 : TILT CAB HYDRAULICS (B)



https://truckmanualshub.com/

K1110-09A0 : TILT CAB HYDRAULICS (B)

Item	Part No.	Description	Qty	Options
1	07098-00520	DDC HOSE	2	
2	07000-13022	O-RING	4	
3	07371-30500	FLANGE	8	
4	01010-80830	BOLT	16	
4	01643-30823	WASHER	16	
5	07379-00500	FLANGE	5	
6	207-62-66540	FLANGE	2	
7	07000-13032	O-RING	2	
8	01252-71030	BOLT	8	
9	207-62-84290	BLOCK	2	
10	07000-13035	O-RING	2	
11	01010-81085	BOLT	8	
11	01643-31032	WASHER	8	
12	11Y-62-6212160	ELBOW	1	
13	007002-11423	O-RING	1	
14	02896-11008	O-RING	1	
15	02782-10425	ELBOW	1	
16	07002-12434	O-RING	1	
17	02896-11012	O-RING	1	
18	702-210-4601	VALVE A.	2	
19	207-62-84260	DDC TUBE	1	
20	07000-13035	O-RING	2	
21	01010-81035	BOLT	8	
21	01643-31032	WASHER	8	
22	207-62-84240	DDC TUBE	1	
23	07000-13035	O-RING	1	
24	01010-81035	BOLT	4	
24	01643-31032	WASHER	4	
25	02782-10311	ELBOW	1	
26	07002-11423	O-RING	1	
27	02896-11009	O-RING	1	
28	02783-10210	ELBOW	3	
29	07002-11423	O-RING	6	
30	0289611008	O-RING	6	
31	07043-70108	PLUG	3	
32	02782-10210	ELBOW	3	
35	207-62-66580	DDC SOLENOID VALVE	2	
36	20762-66510	BLOCK	1	
37	08053-01510	CLIP	2	
38	207-62-66490	PLATE	1	
39	01010-81025	BOLT	8	
39	01643-31032	WASHER	8	
40	206-06-61130	SWITCH	2	
41	20Y-62-16630	NIPPLE	4	
42	07002-11423	O-RING	4	
43	20Y-62-43430	BLOCK	1	
44	207-62-84420	PLATE	1	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
45	01010-80830	BOLT	2	
45	01643-30823	WASHER	2	
46	01010-80840	BOLT	2	
46	01643-30823	WASHER	2	
47	04434-53212	CLIP	2	
48	04435-51212	CLIP	2	
49	01010-81225	BOLT	4	
49	01643-31232	WASHER	4	

https://truckmanualshub.com/

https://truckmanualshub.com/

K1110-10A0 : TILT CAB HYDRAULICS (C)



https://truckmanualshub.com/

K1110-10A0 : TILT CAB HYDRAULICS (C)

Item	Part No.	Description	Qty	Options
1	02781-00420	UNION	1	
2	07002-11823	O-RING	1	
3	02896-11012	O-RING	1	
4	20Y-62-41930	TEE	1	
5	07002-12434	O-RING	1	
6	02896-11012	O-RING	2	
7	11Y-62-12160	ELBOW	1	
8	07002-12434	O-RING	1	
9	02896-11008	O-RING	1	
10	207-62-84250	DDC TUBE	1	
11	07000-13035	O-RING	2	
12	01010-81035	BOLT	8	
12	01643-31032	WASHER	1	
13	08034-20519	BAND	3	
15	207-62-84230	DDC TUBE	1	
16	07000-13035	O-RING	1	
17	01010-81035	BOLT	4	
17	01643-31032	WASHER	4	
18	207-62-84270	DDC TUBE	2	
19	07000-13035	O-RING	1	
20	01010-81060	BOLT	8	
20	01643-31032	BOLT	8	
21	02782-10311	ELBOW	2	
22	02896-11009	O-RING	2	
23	07002-11423	O-RING	2	
24	207-62-84370	BRACKET	1	
25	01010-81025	BOLT	2	
25	01643-31032	WASHER	2	
26	01010-81235	BOLT	2	
26	01643-31232	WASHER	2	
27	207-60-81160	BLOCK	1	
28	07043-70108	PLUG	1	
29	11Y-62-12520	UNION	1	
30	02896-11009	O-RING	1	
31	07002-11423	O-RING	1	
32	207-62-66580	DDC SOLENOID VALV	1	
33	02782-10312	ELBOW	1	
34	02896-11009	O-RING	1	
35	07002-11423	O-RING	1	


https://truckmanualshub.com/

https://truckmanualshub.com/

GUARD

https://truckmanualshub.com/

M1120-01A0 : FRAME (MACHINE CAB)




https://truckmanualshub.com/

M1120-01A0 : FRAME (MACHINE CAB)

Item	Part No.	Description	Qty	Options
1	207-54-71531	FRAME	2	
2	01010-81230	BOLT	4	
3	01643-31232	WASHER	4	
4	207-54-71561	FRAME	1	
5	207-54-71721	SHEET	1	
6	01010-81230	BOLT	5	
7	01643-31232	WASHER	5	
8	207-54-71571	FRAME	1	
9	01010-81230	BOLT	5	
10	01643-31232	WASHER	5	
11	207-54-83970	FRAME	1	
12	207-54-83980	SHEET	1	
13	01010-81230	BOLT	4	
14	01643-31232	WASHER	4	
15	01010-81220	BOLT	2	
16	01643-31232	WASHER	2	
17	207-54-71641	FRAME	1	
18	207-54-71740	SHEET	1	
19	01010-81230	BOLT	4	
20	01643-31232	WASHER	4	
21	01010-81230	BOLT	1	
22	175-54-34170	WASHER	1	

https://truckmanualshub.com/

M1210-01A0 : COVER (UPPER)(MACHINE CAB)




https://truckmanualshub.com/

M1210-01A0 : COVER (UPPER)(MACHINE CAB)

Item	Part No.	Description	Qty	Options
1	207-54-83960	COVER	1	
2	01010-81230	BOLT	4	
3	175-54-34170	WASHER	4	
4	01010-81230	BOLT	1	
5	01643-31232	WASHER	1	
6	20Y-54-19920	PLATE	1	
7	20Y-54-19930	COLLAR	1	

https://truckmanualshub.com/

M1510-01A0 : COUNTER WEIGHT




https://truckmanualshub.com/

M1510-01A0 : COUNTER WEIGHT

Item	Part No.	Description	Qty	Options
	207-46-K2530	WEIGHT	1	
1	207-46-K2520	WEIGHT	1	
2	207-46-74140	SHEET	1	
3	207-46-74160	SHEET	1	
4	207-46-81930	SHEET	1	
5	01370-00508	SCREW	1	
6	207-46-K2510	COVER	1	
7	01010-81250	BOLT	4	
8	01643-31232	WASHER	4	
9	207-46-81720	WEIGHT	1	
10	207-46-81740	BOLT	4	
11	01643-33080	WASHER	4	
12	20Y-46-11270	CAP	2	
13	01010-81220	BOLT	1	
14	01643-31232	WASHER	1	
15	04530-14870	EYE BOLT	2	

https://truckmanualshub.com/

M1810-01A0 : DEMO CAB UNDERCOVERS (L.H.)




https://truckmanualshub.com/

M1810-01A0 : DEMO CAB UNDERCOVERS (L.H.)

Item	Part No.	Description	Qty	Options
1	207-46-K2491	FRAME	1	
2	207-54-83-920	COVER	1	
3	207-54-83930	COVER	1	
4	01010-81230	BOLT	7	
5	175-54-34170	WASHER	7	
6	01010-81235	BOLT	6	
7	01643-31232	WASHER	6	
8	20Y-973-2430	COLLAR	6	
	207-54-83870	COVER ASSY	1	
9	207-54-83880	COVER	1	
10	22U-54-24760	GROMMET	1	
11	01010-81235	BOLT	5	
12	01643-31232	WASHER	5	
13	20Y-973-2430	COLLAR	5	
14	01010-81230	BOLT	3	
15	175-54-34170	WASHER	3	
16	207-54-83860	COVER	1	
17	01010-81235	BOLT	3	
18	01643-31232	WASHER	3	
19	20Y-973-2430	COLLAR	3	
20	01010-81230	BOLT	3	
21	175-54-34170	WASHER	3	
22	207-54-83910	COVER	1	
23	01010-81235	BOLT	3	
24	01643-31232	WASHER	3	
25	20Y-973-2430	COLLAR	3	
26	01010-81230	BOLT	3	
27	175-54-34170	WASHER	3	
28	207-54-KB410	COVER	2	
29	01010-81230	BOLT	8	
30	175-54-34170	WASHER	8	

https://truckmanualshub.com/

M1810-02A0 : DEMO CAB UNDERCOVERS (R.H.)




https://truckmanualshub.com/

M1810-02A0 : DEMO CAB UNDERCOVERS (R.H.)

Item	Part No.	Description	Qty	Options
1	207-54-83890	COVER	1	
2	01010-81235	BOLT	2	
3	01643-31232	WASHER	2	
4	20Y-973-2430	COLLAR	2	
5	01010-81230	BOLT	4	
6	175-54-34170	WASHER	4	
7	207-54-66310	COVER	1	
8	01010-81235	BOLT	2	
9	01643-31232	WASHER	2	
10	207-54-83840	COVER	1	
11	22U-54-23620	COVER	1	
12	195-57-11530	CATCH CLIP	1	
13	01023-20512	SCREW	3	
14	01010-81235	BOLT	4	
15	01643-31232	WASHER	4	
16	20Y-973-2430	COLLAR	4	
17	01010-81230	BOLT	2	
18	175-54-34170	WASHER	2	
19	207-54-83850	COVER	1	
20	01010-81235	BOLT	3	
21	01643-31232	WASHER	3	
22	20Y-973-2430	COLLAR	3	
23	01010-81230	BOLT	3	
24	175-54-34170	WASHER	3	
25	207-54-83940	COVER	1	
26	01010-81235	BOLT	3	
27	01643-31232	WASHER	3	
28	20Y-973-2430	COLLAR	3	
29	01010-81230	BOLT	3	
30	175-54-34170	WASHER	3	
31	207-54-83950	COVER	1	
32	01010-81235	BOLT	3	
33	01643-31232	WASHER	3	
34	20Y-973-2430	COLLAR	3	
35	01010-81230	BOLT	3	
36	175-54-34170	WASHER	3	
37	207-54-KB330	COVER	1	
38	01010-81230	BOLT	6	
39	175-54-34170	WASHER	6	

https://truckmanualshub.com/

M1810-03A0 : DEMO CAB SIDE GUARDS




https://truckmanualshub.com/

M1810-03A0 : DEMO CAB SIDE GUARDS

Item	Part No.	Description	Qty	Options
1	20Y-54-KA472	LH/RH GUARD	1	
2	01010-81240	BOLT	6	
3	01643-31232	WASHER	6	
4	20Y-54-KA492	RH GUARD	1	
5	01010-81240	BOLT	6	
6	01643-31232	WASHER	6	
7	207-54-KB231	GUARD,SIDE	1	
8	01010-81240	BOLT	6	
9	01643-31232	WASHER	6	
10	207-54-KB291	GUARD,SIDE	1	
11	01010-81240	BOLT	6	
12	01643-31232	WASHER	6	
13	20Y-54-KA492	RH GUARD	2	
14	01010-81240	BOLT	6	
15	01643-31232	WASHER	6	

https://truckmanualshub.com/

M1810-04A0 : TILT CAB UNDERCOVERS (R.H.)




https://truckmanualshub.com/

M1810-04A0 : TILT CAB UNDERCOVERS (R.H.)

Item	Part No.	Description	Qty	Options
1	207-46-KA520	FRAME	1	
2	207-54-83890	COVER	1	
3	01010-81235	BOLT	2	
4	01643-31232	WASHER	2	
5	20Y-973-2430	COLLAR	2	
6	01010-81230	BOLT	4	
7	175-54-34170	WASHER	4	
8	207-54-66310	COVER	1	
9	01010-81235	BOLT	2	
10	01643-31232	WASHER	2	
11	207-54-83840	COVER	1	
12	22U-54-23620	COVER	1	
13	195-57-11530	CATCH CLIP	1	
14	01023-20512	SCREW	3	
15	01010-81235	BOLT	4	
16	01643-31232	WASHER	4	
17	20Y-973-2430	COLLAR	4	
18	01010-81230	BOLT	2	
19	175-54-34170	WASHER	2	
20	207-54-83850	COVER	1	
21	01010-81235	BOLT	3	
22	01643-31232	WASHER	3	
23	20Y-973-2430	COLLAR	3	
24	01010-81230	BOLT	3	
25	175-54-34170	WASHER	3	
26	207-54-83940	COVER	1	
27	01010-81235	BOLT	3	
28	01643-31232	WASHER	3	
29	20Y-973-2430	COLLAR	3	
30	01010-81230	BOLT	3	
31	175-54-34170	WASHER	3	
32	207-54-83950	COVER	1	
33	01010-81235	BOLT	3	
34	01643-31232	WASHER	3	
35	20Y-973-2430	COLLAR	3	
36	01010-81230	BOLT	3	
37	175-54-34170	WASHER	3	
38	207-54-KB330	COVER	1	
39	01010-81230	BOLT	6	
40	175-54-34170	WASHER	6	

https://truckmanualshub.com/

M1810-05A0 : TILT CAB UNDERCOVERS (L.H.)




https://truckmanualshub.com/

M1810-05A0 : TILT CAB UNDERCOVERS (L.H.)

Item	Part No.	Description	Qty	Options
1	207-54-KB410	COVER	2	
2	01010-81235	BOLT	8	
3	01643-31232	WASHER	8	
4	207-54-83920	COVER	1	
5	207-54-83930	COVER	1	
6	01010-81230	BOLT	7	
7	175-54-34170	WASHER	7	
8	01010-81235	BOLT	6	
9	01643-31232	WASHER	6	
10	20Y-973-2430	COLLAR	6	
11	207-54-83880	COVER	1	
12	22U-54-24760	GROMMET	1	
13	01010-81235	BOLT	5	
14	01643-31232	WASHER	5	
15	20Y-973-2430	COLLAR	5	
16	01010-81230	BOLT	3	
17	175-54-34170	WASHER	3	

https://truckmanualshub.com/

M1810-06A0 : TILT CAB SIDE GUARDS




https://truckmanualshub.com/

M1810-06A0 : TILT CAB SIDE GUARDS

Item	Part No.	Description	Qty	Options
1	20Y-54-KA472	LH/RH GUARD	1	
2	01010-81240	BOLT	6	
3	01643-31232	WASHER	6	
4	20Y-54-KA482	LH GUARD	1	
5	01010-81240	BOLT	6	
6	01643-31232	WASHER	6	
7	207-54-KB231	GUARD,SIDE	1	
8	01010-81240	BOLT	6	
9	01643-31232	WASHER	6	
10	207-54-KB242	GUARD,SIDE	1	
11	01010-81240	BOLT	6	
12	01643-31232	WASHER	6	

https://truckmanualshub.com/

M1810-07A0 : TILT CAB COVERS (CAB)



https://truckmanualshub.com/

M1810-07A0 : TILT CAB COVERS (CAB)

Item	Part No.	Description	Qty	Options
1	207-54-KB260	PLATE	1	
2	01010-81230	BOLT	6	
3	01643-31232	WASHER	6	
4	207-54-KB271	PLATE	1	
5	01010-81230	BOLT	6	
6	01643-31232	WASHER	6	
7	20Y-54-KA492	RH GUARD	1	
8	01010-81240	BOLT	6	
9	01643-31232	WASHER	6	
10	207-54-KB280	BRACKET	1	
11	01010-81630	BOLT	4	
12	01643-31645	WASHER	4	
13	207-54-83970	FRAME	1	
14	07049-01215	PLUG	7	

https://truckmanualshub.com/

https://truckmanualshub.com/

UNDERCARRIAGE

https://truckmanualshub.com/

R1000-01A0 : HYDRAULIC TRACK FRAME




https://truckmanualshub.com/

R1000-01A0 : HYDRAULIC TRACK FRAME

Item	Part No.	Description	Qty	Options
1	207-30-KA670	UNDERCARRIAGE	1	

https://truckmanualshub.com/

R1000-02A0 : HYD. TRACK FRAME CONTROL PIPING



https://truckmanualshub.com/

R1000-02A0 : HYD. TRACK FRAME CONTROL PIPING

Item	Part No.	Description	Qty	Options
1	205-62-66181	ELBOW	2	
2	07002-12434	O-RING	2	
3	07096-00214	HOSE	2	
4	07235-10210	ELBOW	2	
5	07002-11423	O-RING	2	
6	207-62-KD580	FLANGE	2	
7	07000-13030	O-RING	2	
8	01010-81035	BOLT	8	
9	01643-31032	WASHER	8	
10	21P-970-K233	DDC VALVE	2	
11	01010-81045	BOLT	8	
12	01643-31032	WASHER	8	
13	207-62-KD570	BLOCK	2	
14	07000-13032	O-RING	6	
15	07373-21000	SPACER	2	
16	01010-81065	BOLT	8	
17	01643-31032	WASHER	8	
18	07040-11409	PLUG	2	
19	07002-11423	O-RING	2	
20	07098-01011	HOSE	2	
21	07000-13032	O-RING	2	


https://truckmanualshub.com/

https://truckmanualshub.com/

WORK EQUIPMENT

https://truckmanualshub.com/

T1110-01A0 : 1ST, 2ND, 3RD BOOM PINS AND BUSHINGS




https://truckmanualshub.com/

T1110-01A0 : 1ST, 2ND, 3RD BOOM PINS AND BUSHINGS

Item	Part No.	Description	Qty	Options
1	207-70-KC155	NO.1 BOOM	1	
2	207-70-KD512	NO. 2 BOOM	1	
3	207-70-KC192	NO. 3 BOOM	1	
4	07145-00110	SEAL,DUST	2	
5	207-70-K2320	BUSHING	2	
6	207-70-32150	BUSHING	4	
7	KV-B230-6190	BUSHING	8	
8	KV-B52-1131	BUSHING	2	
9	207-70-31172	PIN	1	
10	KV-B52-1120	PIN	1	
11	207-70-31230	PLATE	1	
12	01010-81640	BOLT	2	
13	01643-31645	WASHER	2	
14	207-70-11360	SPACER	1	
15	KV-B52-1140	HOLDER	1	
16	01010-82055	BOLT	3	
17	01643-32060	WASHER	3	
18	208-70-61240	PIN	1	
19	205-70-66580	PLATE	1	
20	01010-81235	BOLT	2	
21	01643-31232	WASHER	2	
22	207-70-11340	SHIM	3	
23	KV-B230-6170	PIN	3	
24	205-70-71310	PLATE	3	
25	01010-81240	BOLT	6	
26	01643-31232	WASHER	6	
27	KV-B230-6180	PLATE	3	
28	01010-82055	BOLT	9	
29	01643-32060	WASHER	9	
30	20Y-70-11410	SPACER	3	
31	20Y-70-11420	SPACER	6	

https://truckmanualshub.com/

T1110-02A0 : 1ST BOOM LUBE PIPING




https://truckmanualshub.com/

T1110-02A0 : 1ST BOOM LUBE PIPING

Item	Part No.	Description	Qty	Options
1	KV-B230-6410	TUBE	1	
2	207-70-81450	TUBE	1	
3	207-62-KB320	TUBE	1	
4	207-62-KB340	TUBE	1	
5	KV-X5X0-7070	NIPPLE	1	
6	07214-51013	CONNECTOR	3	
7	20G-68-12930	ELBOW	1	
8	07020-00000	FITTING	3	
9	205-70-51390	NIPPLE	2	
10	208-70-62190	DDC HOSE	2	
11	205-70-51380	ELBOW	1	
12	209-72-16550	HOSE	1	
13	07020-00675	FITTING	2	
14	208-70-11450	CLIP	2	
15	01010-80616	BOLT	4	
16	01643-30623	WASHER	4	
17	08036-01014	CLIP	5	
18	01010-81016	BOLT	5	
19	01643-31032	WASHER	5	

https://truckmanualshub.com/

T1110-03A0 : 1ST BOOM PIPING




https://truckmanualshub.com/

T1110-03A0 : 1ST BOOM PIPING

Item	Part No.	Description	Qty	Options
1	207-62-KB870	TUBE	1	
2	207-62-KB860	TUBE	1	
3	207-62-KB890	TUBE	1	
4	207-62-KB920	TUBE	1	
5	KV-B100-1290	TUBE	2	
6	207-62-KB310	TUBE	1	
7	207-62-KB240	TUBE	1	
8	KV-1B60-5160	TUBE	1	
9	207-62-KB910	TUBE	1	
10	207-62-KB230	TUBE	1	
11	207-62-KB880	TUBE	1	
12	207-62-KB850	TUBE	1	
13	207-62-83980	TUBE	1	
14	207-62-83960	TUBE	1	
15	07000-13035	O-RING	1	
16	01010-81060	BOLT	4	
17	01643-51032	WASHER	4	
18	207-62-KB840	TUBE	1	
19	KV-X2X0-1650	VALVE	2	
20	KV-X2X0-1780	VALVE ASSY	2	

https://truckmanualshub.com/

T1110-04A0 : 1ST BOOM PIPING CLAMPS



https://truckmanualshub.com/

T1110-04A0 : 1ST BOOM PIPING CLAMPS

Item	Part No.	Description	Qty	Options
1	07378-11000	HEAD	7	
2	07000-13032	O-RING	7	
3	07371-31049	FLANGE	14	
4	07372-21035	BOLT	28	
5	01643-51032	WASHER	28	
6	07378-11210	HEAD	1	
7	07000-13038	O-RING	1	
8	07371-51260	FLANGE	2	
9	07372-21245	BOLT	4	
10	01643-31232	WASHER	4	
11	07378-11410	HEAD	1	
12	07000-13048	O-RING	1	
13	07371-51470	FLANGE	2	
14	07372-21455	BOLT	4	
15	01643-31445	WASHER	4	
16	07000-13035	O-RING	8	
17	07372-21035	BOLT	32	
18	01643-51032	WASHER	32	
19	07379-01044	FLANGE	8	
20	07378-10500	HEAD	6	
21	07000-13022	O-RING	6	
22	07371-30500	FLANGE	12	
23	01010-80830	BOLT	24	
24	01643-50823	WASHER	24	
25	207-62-84220	CLAMP	1	
26	01010-81245	BOLT	4	
27	01643-31232	WASHER	4	
28	207-70-KB150	CLAMP	1	
29	205-62-73430	SEAT	16	
30	01010-81245	BOLT	4	
31	01643-31232	WASHER	4	
32	207-70-KB170	CLAMP	1	
33	01010-81245	BOLT	4	
34	01643-31232	WASHER	4	
35	KV-B27-1800	CLAMP	2	
36	01010-81245	BOLT	4	
37	01643-31232	WASHER	4	
38	KV-B27-1770	CLAMP	2	
39	01010-81245	BOLT	4	
40	01643-31232	WASHER	4	
41	207-62-31330	CLAMP	5	
42	207-62-54760	CLAMP	1	
43	01010-81235	BOLT	12	
44	01643-31232	WASHER	12	
45	01010-81270	BOLT	2	
46	01643-31232	WASHER	2	
47	207-62-84210	BRACKET	1	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	207-62-31330	CLAMP	2	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1110-05A0 : 1ST BOOM QUICK CHANGE UNIT




https://truckmanualshub.com/

T1110-05A0 : 1ST BOOM QUICK CHANGE UNIT

Item	Part No.	Description	Qty	Options
1	207-63-KA230	CYLINDER ASSY	1	
2	207-70-KC110	PLATE	1	
3	01010-81025	BOLT	2	
4	01643-31032	WASHER	2	
5	207-70-KC120	PLATE	1	
6	01010-81025	BOLT	2	
7	01643-31032	WASHER	2	
8	207-70-KC130	PLATE	2	
9	01010-81025	BOLT	8	
10	01643-31032	WASHER	8	
11	02783-10522	ELBOW	1	
12	0700212434	O-RING	1	
13	02896-11015	O-RING	1	
14	20E-62-K1930	UNION	2	
15	07002-12434	O-RING	4	
16	20G-60-K1740	DDC VALVE	2	
17	205-62-66181	ELBOW	2	
18	07002-12434	O-RING	2	
19	20G-966-K380	NIPPLE	2	
20	07210-00217	HOSE	1	
21	07121-00220	HOSE	1	
22	201-62-65530	ADAPTER	2	
23	07002-11423	O-RING	4	
24	04434-51810	CLIP	11	
25	01010-81020	BOLT	9	
26	01643-31032	WASHER	9	

https://truckmanualshub.com/

T1110-06A0 : 1ST BOOM WORKLAMP




https://truckmanualshub.com/

T1110-06A0 : 1ST BOOM WORKLAMP

Item	Part No.	Description	Qty	Options
1	207-06-71161	WIRING HARNESS	1	
2	207-06-K1520	WORK LAMP ASSY	1	
3	C12370	GUARD	1	
4	01010-81430	BOLT	1	
5	01643-31445	WASHER	1	
6	203-06-56570	BAND	11	

https://truckmanualshub.com/

T1110-07A0 : 1ST BOOM ANGLE INDICATOR




https://truckmanualshub.com/

T1110-07A0 : 1ST BOOM ANGLE INDICATOR

Item	Part No.	Description	Qty	Options
1	KV-1B23-3571	PLATE	1	
2	01010-80812	BOLT	1	
3	01643-30823	WASHER	1	
4	KV-1B27-2320	SEAT	1	
5	KV-1B23-3561	BOSS	1	

https://truckmanualshub.com/

T1110-08A0 : 2ND BOOM PIPING




https://truckmanualshub.com/

T1110-08A0 : 2ND BOOM PIPING

Item	Part No.	Description	Qty	Options
1	KV-B230-6440	TUBE	1	
2	07214-51013	CONNECTOR	1	
3	KV-X5X0-1140	BUSHING	1	
4	205-70-51390	NIPPLE	1	
5	207-70-KB910	HOSE	1	
6	08036-01014	CLIP	2	
7	01010-81016	BOLT	2	
8	01643-31032	WASHER	2	
9	07099-21010	HOSE	7	
10	07099-21011	HOSE	1	
11	07000-13032	O-RING	16	
12	07371-31049	FLANGE	16	
13	07372-21035	BOLT	32	
14	01643-51032	WASHER	32	
15	207-62-KB280	TUBE	8	
16	07000-13035	O-RING	8	
17	07372-21035	BOLT	32	
18	01643-51032	WASHER	32	
19	07379-01044	FLANGE	8	
20	207-70-KB170	CLAMP	2	
21	01010-81245	BOLT	8	
22	01643-31232	WASHER	8	

https://truckmanualshub.com/

T1110-09A0 : 3RD BOOM PIPING



https://truckmanualshub.com/

T1110-09A0 : 3RD BOOM PIPING

Item	Part No.	Description	Qty	Options
1	07099-21011	HOSE	8	
2	07000-13032	O-RING	16	
3	07371-31049	FLANGE	16	
4	07372-21035	BOLT	32	
5	01643-51032	WASHER	32	
6	207-62-KB270	TUBE	1	
7	207-62-KB251	TUBE	1	
8	207-62-KB260	TUBE	1	
9	07097-21016	HOSE	2	
10	07000-13032	O-RING	4	
11	07371-31049	FLANGE	4	
12	07372-21035	BOLT	8	
13	01643-51032	WASHER	8	
14	07099-21015	HOSE	6	
15	07000-13032	O-RING	12	
16	07371-31049	FLANGE	12	
17	07372-21035	BOLT	24	
18	01643-51032	WASHER	24	
19	207-70-KB170	CLAMP	2	
20	01010-81245	BOLT	4	
21	01643-31232	WASHER	4	
22	KV-B240-2170	CLAMP	2	
23	01010-81245	BOLT	4	
24	01643-31232	WASHER	4	
25	207-70-KB360	CLAMP	1	
26	205-62-54-622	SEAT	12	
27	01010-81245	BOLT	4	
28	01643-31232	WASHER	4	
29	207-70-KB370	CLAMP	1	
30	01010-81245	BOLT	4	
31	01643-31232	WASHER	4	
32	207-62-KB330	TUBE	3	
33	07371-30500	FLANGE	6	
34	01010-80830	BOLT	12	
35	01643-50823	WASHER	12	
36	07378-10500	HEAD	3	
37	07000-13022	O-RING	3	
38	07097-20515	HOSE	3	
39	07000-13022	O-RING	6	
40	07371-30500	FLANGE	6	
41	01010-80830	BOLT	12	
42	01643-50823	WASHER	12	
43	KV-B27-1800	CLAMP	2	
44	01010-81245	BOLT	4	
45	01643-31232	WASHER	4	
46	KV-B27-1770	CLAMP	2	
47	01010-81245	BOLT	4	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	01643-31232	WASHER	4	
49	KV-B230-6450	TUBE	1	
50	07214-51013	CONNECTOR	1	
51	KV-X5X0-1140	BUSHING	1	
52	205-70-51390	NIPPLE	2	
53	208-70-62190	DDC HOSE	2	
54	08036-01014	CLIP	1	
55	01010-81016	BOLT	1	
56	01643-31032	WASHER	1	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1110-10A0 : 1ST, 2ND, 3RD BOOM FASTER PIPING



https://truckmanualshub.com/

T1110-10A0 : 1ST, 2ND, 3RD BOOM FASTER PIPING

Item	Part No.	Description	Qty	Options
1	07108-20423	HOSE	1	
2	07096-00507	HOSE	2	
3	07096-00509	HOSE	1	
4	07108-20426	HOSE	3	
5	07096-00526	HOSE	3	
6	07108-20416	HOSE	3	
7	07108-20422	HOSE	1	
8	07108-20322	HOSE	1	
9	07096-00525	HOSE	2	
10	07096-00526	HOSE	1	
11	07108-20437	HOSE	2	
12	207-62-KB180	BLOCK	2	
13	07000-13025	O-RING	2	
14	01252-80880	BOLT	8	
15	07235-10522	ELBOW	2	
16	07002-12434	O-RING	2	
17	207-62-KB180	BLOCK	4	
18	07000-13025	O-RING	4	
19	01252-80880	BOLT	12	
20	07040-12412	PLUG	4	
21	07002-12434	O-RING	4	
22	07235-10522	ELBOW	4	
23	07002-12434	O-RING	4	
24	207-62-KB730	CONNECTOR	2	
25	207-62-KB490	JOINT	12	
26	207-62-KB471	SEAL	12	
27	20R-62-14330	NIPPLE	6	
28	07002-12034	O-RING	6	
29	07230-20422	NIPPLE	6	
30	07002-12034	O-RING	6	
31	207-70-KC911	PLATE	2	
32	01010-80850	BOLT	8	
33	01643-30823	WASHER	8	
34	207-62-KB740	CONNECTOR	2	
35	20R-62-14330	NIPPLE	6	
36	07002-12034	O-RING	6	
37	207-62-KB490	JOINT	12	
38	207-62-KB471	SEAL	12	
39	07230-20422	NIPPLE	6	
40	07002-12034	O-RING	6	
41	207-62-KB390	SOCKET	2	
42	207-62-KB380	PLUG	2	
43	207-62-KB190	PLUG	2	
44	207-62-KB170	PLUG	2	
45	21M-62-KA110	UNION	2	
46	207-62-KB461	SEAL	2	
47	207-62-KD330	BLOCK	16	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	07040-12012	PLUG	16	
49	07002-12034	O-RING	16	
50	207-62-KB480	JOINT	16	
51	207-62-KB461	SEAL	16	
52	203-973-5750	NIPPLE	16	
53	07002-1334	O-RING	16	
54	07371-31049	FLANGE	32	
55	07372-21035	BOLT	64	
56	01643-51032	WASHER	64	
57	207-62-KD370	PLUG	10	
58	207-62-KD380	SOCKET	10	
59	207-62-KD440	PLUG	10	
60	207-62-KD450	PLUG	10	
61	207-62-KD320	CONNECTOR	10	
62	207-62-KD350	SEAL	10	
63	207-62-KB461	SEAL	10	
64	207-62-KD390	PLUG	4	
65	207-62-KD410	SOCKET	4	
66	207-62-KD420	PLUG	4	
67	207-62-KD430	PLUG	4	
68	207-62-KD290	ADAPTER	10	
69	207-62-KD350	SEAL	10	
70	207-62-KD310	CONNECTOR	4	
71	207-62-KD360	SEAL	4	
72	207-62-KB461	SEAL	4	
73	207-62-KD280	ADAPTER	4	
74	207-62-KD360	SEAL	4	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1110-11A0 : 1ST, 2ND, 3RD BOOM FASTER PIPE CLAMPS



https://truckmanualshub.com/

T1110-11A0 : 1ST, 2ND, 3RD BOOM FASTER PIPE CLAMPS

Item	Part No.	Description	Qty	Options
1	KV-B240-8080	BLOCK	3	
2	198-33-12380	WASHER	3	
3	01010-81290	BOLT	3	
4	01643-31232	WASHER	3	
5	07230-20422	NIPPLE	3	
6	07002-12034	O-RING	3	
7	120-54-42430	SPACER	2	
8	04434-52512	CLIP	3	
9	01010-81275	BOLT	2	
10	01643-31232	WASHER	2	
11	01010-81255	BOLT	2	
12	01643-31232	WASHER	2	
13	120-54-42430	SPACER	2	
14	04434-52512	CLIP	3	
15	04434-53212	CLIP	3	
16	01010-81275	BOLT	2	
17	01643-31232	WASHER	2	
18	KV-B240-8080	BLOCK	1	
19	198-33-12380	WASHER	1	
20	01010-81290	BOLT	1	
21	01643-31232	WASHER	1	
22	07236-10422	ELBOW	1	
23	07235-10315	ELBOW	1	
24	07002-12034	O-RING	2	
25	KV-B240-8080	BLOCK	1	
26	198-33-12380	WASHER	1	
27	04434-53212	CLIP	1	
28	01010-81290	BOLT	1	
29	01643-31232	WASHER	1	
30	07236-10422	ELBOW	1	
31	07230-20422	NIPPLE	1	
32	07002-12034	O-RING	2	
33	20Y-62-19330	ELBOW	1	
34	120-54-42430	SPACER	1	
35	04434-53212	CLIP	2	
36	01010-81275	BOLT	1	
37	01643-31232	WASHER	1	
38	07236-10422	ELBOW	1	
39	07230-20422	NIPPLE	1	
40	07235-10422	ELBOW	1	
41	07002-12034	O-RING	2	
42	120-54-42430	SPACER	1	
43	04434-52512	CLIP	2	
44	01010-81275	BOLT	1	
45	01643-31232	WASHER	1	
46	120-54-42430	SPACER	1	
47	04434-52512	CLIP	2	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	01010-81275	BOLT	1	
49	01643-31232	WASHER	1	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1110-12A0 : MID LINK PINS AND BUSHINGS




https://truckmanualshub.com/

T1110-12A0 : MID LINK PINS AND BUSHINGS

Item	Part No.	Description	Qty	Options
1	207-70-82170	LINK	1	
2	207-70-12161	BUSHING	4	
3	07020-00900	FITTING	1	
4	207-70-31190	PIN	1	
5	205-70-66580	PLATE	1	
6	01010-81235	BOLT	2	
7	01643-31232	WASHER	2	
8	207-70-82290	PIN	1	
9	205-70-66580	PLATE	1	
10	01010-81235	BOLT	2	
11	01643-31232	WASHER	2	
12	202-62-21330	BUSHING	1	

https://truckmanualshub.com/

T1110-13A0 : DIG BOOM PIPING



https://truckmanualshub.com/

T1110-13A0 : DIG BOOM PIPING

Item	Part No.	Description	Qty	Options
1	207-62-KB540	TUBE	3	
2	207-62-KB180	BLOCK	3	
3	07000-13025	O-RING	3	
4	0125-80880	BOLT	12	
5	07040-12412	PLUG	3	
6	07002-12434	O-RING	3	
7	07235-10522	ELBOW	3	
8	07002-12434	O-RING	3	
9	207-62-KB530	TUBE	2	
10	KV-1B27-4180	CLAMP	2	
11	01010-81245	BOLT	4	
12	01643-31232	WASHER	4	
13	KV-1B27-1770	CLAMP	1	
14	01010-81245	BOLT	2	
15	01643-31232	WASHER	2	
16	KV-1B27-4190	CLAMP	1	
17	01010-81245	BOLT	4	
18	01643-31232	WASHER	4	
19	KV-1B27-1800	CLAMP	1	
20	01010-81245	BOLT	2	
21	01643-31232	WASHER	2	
22	207-62-KB510	TUBE	1	
23	207-62-KB520	TUBE	1	
24	207-62-31330	CLAMP	2	
25	01010-81235	BOLT	4	
26	01643-31232	WASHER	4	
27	207-62-54830	CLAMP	8	
28	207-970-KA30	SPACER	2	
29	01010-81660	BOLT	4	
30	01011-81630	BOLT	4	
31	01643-31645	WASHER	8	
32	07096-00517	HOSE	3	
33	20R-62-14330	NIPPLE	3	
34	07002-12034	O-RING	3	
35	07040-12012	PLUG	3	
36	07002-12034	O-RING	3	
37	207-62-KB740	CONNECTOR	1	
38	207-62-KB471	SEAL	6	
39	207-62-KB490	JOINT	6	
40	07085-01012	HOSE	2	
41	07099-01012	HOSE	2	
42	07371-31049	FLANGE	16	
43	07372-21035	BOLT	32	
44	01643-51032	WASHER	32	
45	07000-13032	O-RING	8	
46	203-973-5750	NIPPLE	6	
47	07002-13334	O-RING	6	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	207-62-KB480	JOINT	6	
49	207-62-KB461	SEAL	6	
50	07378-11000	HEAD	1	
51	07000-13032	O-RING	1	
52	07371-31049	FLANGE	2	
53	07375-21035	BOLT	4	
54	01643-51032	WASHER	4	
55	07085-01012	HOSE	1	
56	07085-01013	HOSE	1	
57	07371-31049	FLANGE	8	
58	07372-21035	BOLT	16	
59	01643-51032	WASHER	16	
60	07000-13032	O-RING	4	
61	205-70-51390	NIPPLE	1	
62	207-70-KB930	HOSE	1	
63	207-62-KD370	PLUG	4	
64	207-62-KD450	PLUG	4	
65	207-62-KD390	PLUG	2	
66	207-62-KD420	PLUG	2	
67	207-62-KD290	ADAPTER	4	
68	207-62-KD280	ADAPTER	4	
69	207-62-KD350	SEAL	4	
70	207-62-KD360	SEAL	2	
71	07379-01044	FLANGE	4	
72	07000-13032	O-RING	4	
73	07371-31049	FLANGE	8	
74	07372-21035	BOLT	16	
75	01643-51032	WASHER	16	
76	07379-00500	FLANGE	3	
77	07000-13022	O-RING	3	
78	07371-30500	FLANGE	6	
79	01010-80830	BOLT	12	
80	01643-50823	WASHER	12	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1120-01A0 : MID LINK CYLINDER DETAIL



https://truckmanualshub.com/

T1120-01A0 : MID LINK CYLINDER DETAIL

Item	Part No.	Description	Qty	Options
G-1	707-01-XZ980	MID LINK CYLINDER GROUP	1	
		MID LINK CYLINDER ASSY	1	
1	707-13-16710	• CYLINDER	1	
2	707-76-10310	• BUSHING	2	
3	07145-00100	• SEAL,DUST (KIT)	2	
4	707-58-11360	• ROD	1	
5	707-76-10310	• BUSHING	2	
6	07145-00100	• SEAL,DUST (KIT)	2	
7	707-71-32800	• COLLAR	1	
8	707-35-91640	• RING,BACK-UP (KIT)	2	
9	07000-15150	• O-RING (KIT)	1	
10	707-71-61130	• PLUNGER	1	
11	707-71-70290	• PLUNGER	1	
12	04260-00635	• BALL	12	
13	707-71-91270	• CAP	1	
14	07020-00000	• FITTING,GREASE	1	
15	707-27-16920	• HEAD	1	
16	198-63-94170	• SEAL,DUST (KIT)	1	
17	07179-13126	• RING,SNAP	1	
18	707-52-90850	• BUSHING	1	
19	707-51-11030	• PACKING,ROD (KIT)	1	
20	707-51-11640	• RING,BUFFER (KIT)	1	
21	707-35-91640	• RING,BACK-UP (KIT)	1	
22	07000-15150	• O-RING (KIT)	1	
23	01010-82085	• BOLT	12	
24	707-88-75310	• WASHER	12	
25	707-36-16580	• PISTON	1	
26	01310-01216	• SCREW	1	
27	707-44-16180	• RING,PISTON (KIT)	1	
28	707-39-16120	• RING,WEAR (KIT)	2	
29	707-44-16910	• RING	2	
30	07001-05100	• RING,BACK-UP (KIT)	2	
31	07000-15100	• O -RING (KIT)	1	
31A	707-83-13010	• VALVE	1	
31B	07750-01628	• SPRING	1	
31C	707-87-14070	• PLUG	1	
31D	07002-12034	• O-RING (KIT)	1	
32	707-86-11600	TUBE	1	
33	707-86-11610	BLOCK	1	
34	01435-01055	BOLT	4	
35	01435-01095	BOLT	4	
36	07000-13035	O-RING (KIT)	2	
37	707-88-22740	BRACKET	1	
38	707-88-21380	BAND	1	
39	207-63-64190	BRACKET	1	
40	707-88-21390	BAND	1	
41	01435-01235	BOLT	4	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
42	07283-23442	CLIP	2	
43	01643-31032	WASHER	4	
44	01599-01011	NUT	4	
45	707-88-33040	CAP (FOR SHIPPING)	3	
46	07371-31049	FLANGE (FOR SHIPPING)	6	
47	07372-21035	BOLT (FOR SHIPPING)	12	
48	01643-51032	WASHER (FOR SHIPPING)	12	
	707-99-67090	SERVICE KIT	1	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1140-01A0 : ARM CYLINDER DETAIL



https://truckmanualshub.com/

T1140-01A0 : ARM CYLINDER DETAIL

Item	Part No.	Description	Qty	Options
G-1	707-01-XY580	ARM CYLINDER GROUP	1	
	707-01-XC120	ARM CYLINDER ASSY	1	
1	707-13-14550	• CYLINDER	1	
2	707-76-80470	• BUSHING	2	
3	07145-00080	• SEAL,DUST (KIT)	2	
4	707-58-10680	• ROD,PISTON	1	
5	707-76-80470	• BUSHING	2	
6	07145-00080	• SEAL,DUST (KIT)	2	
7	707-27-14930	• HEAD CYLINDER	1	
8	07179-13114	• RING,SNAP	1	
9	176-63-56170	• SEAL,DUST (KIT)	1	
10	707-52-90780	• BUSHING	1	
11	707-51-10030	• PACKING,ROD (KIT)	1	
12	07000-15130	• O-RING (KIT)	1	
13	707-35-91420	• RING,BACK-UP (KIT)	1	
14	707-51-10640	• RING,BUFFER (KIT)	1	
15	01010-81875	• BOLT	12	
16	707-41-11840	• WASHER	12	
17	707-36-14650	• PISTON	1	
18	707-44-14180	• RING,PISTON (KIT)	1	
19	707-39-14110	• RING,WEAR (KIT)	2	
20	707-44-14910	• RING	2	
21	707-71-61080	• PLUNGER	1	
22	07000-15090	• O-RING (KIT)	1	
23	07001-05090	• RING,BACK-UP (KIT)	2	
24	01310-01216	• SCREW	1	
25	707-71-70270	• PLUNGER	1	
26	07020-00000	• FITTING,GREASE	1	
27	707-71-32780	• COLLAR	1	
28	707-35-91420	• RING,BACK-UP (KIT)	2	
29	07000-15130	• O-RING (KIT)	1	
30	04260-00635	• BALL	12	
31	707-71-91270	• CAP	1	
32	707-83-13010	• VALVE	1	
33	07750-01628	• SPRING	1	
34	707-87-14070	• PLUG	1	
35	07002-12034	• O-RING (KIT)	1	
36	707-86-66340	TUBE	1	
37	20D-62-17860	ELBOW	1	
38	01435-01055	BOLT	2	
39	01435-01040	BOLT	2	
40	07000-13035	O-RING (KIT)	1	
41	01435-01075	BOLT	4	
42	07000-13035	O-RING (KIT)	1	
43	707-88-22630	BRACKET	1	
44	707-88-21321	BAND	1	
45	01435-01030	BOLT	2	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
46	707-88-11560	PLATE	1	
47	07283-22738	CLIP	2	
48	01599-01011	NUT	4	
49	01643-31032	WASHER	4	
50	707-88-33030	HEAD	1	
51	07371-30640	FLANGE	2	
52	707-88-33040	CAP (FOR SHIPPING)	1	
53	07371-31049	FLANGE (FOR SHIPPING)	2	
54	07372-21035	BOLT (FOR SHIPPING)	8	
55	01643-51032	WASHER (FOR SHIPPING)	8	
	707-99-58070	SERVICE KIT	1	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1210-01A0 : ARM PINS AND BUSHINGS




https://truckmanualshub.com/

T1210-01A0 : ARM PINS AND BUSHINGS

Item	Part No.	Description	Qty	Options
1	207-70-82190	ARM	1	
2	20Y-70-32351	BUSHING	2	
3	20Y-70-32321	BUSHING	2	
4	KV-B52-1131	BUSHING	2	
5	20Y-70-23230	SEAL	4	
6	20Y-70-32331	BUSHING	2	
7	07020-00000	FITTING	2	
8	KV-B52-1120	PIN	1	
9	207-70-31230	PLATE	1	
10	01010-81640	BOLT	2	
11	01643-31645	WASHER	2	
12	207-70-11360	SPACER	1	
13	KV-B52-1140	HOLDER	1	
14	01010-82055	BOLT	3	
15	01643-32060	WASHER	3	
16	206-70-51170	PIN	1	
17	205-70-66580	PLATE	1	
18	01010-81235	BOLT	2	
19	01643-31232	WASHER	2	
20	205-70-71320	PIN	1	
21	205-70-66580	PLATE	1	
22	01010-81235	BOLT	2	
23	01643-31232	WASHER	2	
24	20Y-70-11340	SPACER	1	
25	205-70-51530	SPACER	2	

https://truckmanualshub.com/

T1210-02A0 : MID LINK AND ARM PIPING



https://truckmanualshub.com/

T1210-02A0 : MID LINK AND ARM PIPING

Item	Part No.	Description	Qty	Options
1	07020-00000	FITTING	3	
2	07214-50813	CONNECTOR	3	
3	KV-B230-5721	TUBE	1	
4	07217-50813	ELBOW	1	
5	08036-00814	CLIP	7	
6	01010-81220	BOLT	7	
7	01643-31232	WASHER	7	
8	KV-B230-2610	TUBE	1	
9	07214-50813	CONNECTOR	2	
10	KX-X5X0-2340	COUPLING	2	
11	21T-72-76570	HOSE	2	
12	205-70-51380	ELBOW	2	
13	KV-B230-2620	TUBE	1	
14	KV-B240-2260	TUBE	1	
15	KX-X5X0-6120	FLANGE	1	
16	01252-41025	BOLT	4	
17	07000-13032	O-RING	1	
18	KV-X2X0-1780	VALVE ASSY	1	
19	KV-B240-2270	TUBE	1	
20	07098-20612	HOSE	1	
21	07000-13025	O-RING	2	
22	07371-30640	FLANGE	4	
23	07372-21035	BOLT	8	
24	01643-51032	WASHER	8	
25	KV-B240-2210	TUBE	1	
26	07000-13032	O-RING	2	
27	07085-21012	HOSE	1	
28	07371-31049	FLANGE	4	
29	07372-21035	BOLT	8	
30	01643-51032	WASHER	8	
31	KV-B230-3470	TUBE	2	
32	07085-21015	HOSE	2	
33	07000-13032	O-RING	4	
34	07371-31049	FLANGE	8	
35	07372-21035	BOLT	16	
36	01643-51032	WASHER	16	
37	KV-B230-3440	TUBE	3	
38	07083-20515	HOSE	2	
39	07000-13022	O-RING	4	
40	07371-30500	FLANGE	8	
41	01010-80830	BOLT	16	
42	01643-30823	WASHER	16	
43	07083-20516	HOSE	1	
44	07000-13022	O-RING	2	
45	07371-30500	FLANGE	4	
46	01010-80830	BOLT	8	
47	01643-30823	WASHER	8	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	KV-B230-3610	TUBE	2	
49	KV-X2X0-1780	VALVE ASSY	2	
50	KV-B240-3440	TUBE	2	
51	07084-21A16	HOSE	2	
52	07000-13032	O-RING	4	
53	07371-31049	FLANGE	16	
54	07372-21035	BOLT	32	
55	01643-51032	WASHER	32	
56	KV-B230-3630	TUBE	2	
57	07084-21A07	HOSE	2	
58	07000-13032	O-RING	4	
59	07371-31049	FLANGE	16	
60	07372-21035	BOLT	32	
61	01643-51032	WASHER	32	
62	207-62-KB810	TUBE	4	
63	20Y-970-K542	DDC VALVE	2	
64	07371-31049	FLANGE	16	
65	07372-21035	BOLT	32	
66	01643-51032	WASHER	32	
67	07000-13032	O-RING	8	
68	207-62-KB760	TUBE	4	
69	KV-X5X0-3010	ELBOW	4	
70	KV-X5X0-2830	CAP	4	
71	KV-B230-3640	TUBE	2	
72	KV-B230-3650	TUBE	2	
73	KV-B230-3660	TUBE	2	
74	207-62-KB820	TUBE	6	
75	01024-80835	BOLT	24	
76	07000-13025	O-RING	6	
77	207-62-KC661	DDC VALVE	3	
78	07371-30500	FLANGE	24	
79	01010-80830	BOLT	48	
80	01643-50823	WASHER	48	
81	07000-13022	O-RING	12	
82	207-62-KB770	TUBE	6	
83	KV-X5X0-3000	ELBOW	6	
84	KV-X5X0-2840	CAP	6	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1210-03A0 : MID LINK AND ARM PIPING CLAMPS




https://truckmanualshub.com/

T1210-03A0 : MID LINK AND ARM PIPING CLAMPS

Item	Part No.	Description	Qty	Options
1	KV-B240-2130	CLAMP	1	
2	01010-81250	BOLT	3	
3	01643-31232	WASHER	3	
4	KV-B240-2170	CLAMP	2	
5	01010-81245	BOLT	4	
6	01643-31232	WASHER	4	
7	KV-B240-2150	CLAMP	1	
8	01010-81250	BOLT	3	
9	01643-31232	WASHER	3	
10	KV-B27-1770	CLAMP	2	
11	01010-81245	BOLT	4	
12	01643-31232	WASHER	4	
13	KV-B27-1800	CLAMP	2	
14	01010-81245	BOLT	4	
15	01643-31232	WASHER	4	
16	KV-B240-2150	CLAMP	4	
17	01010-81250	BOLT	12	
18	01643-31232	WASHER	12	
19	KV-B240-3230	CLAMP	2	
20	01010-81250	BOLT	10	
21	01643-31232	WASHER	10	
22	KV-B27-1770	CLAMP	4	
23	01010-81245	BOLT	8	
24	01643-31232	WASHER	8	
25	KV-B27-4180	CLAMP	6	
26	01010-81245	BOLT	12	
27	01643-31232	WASHER	12	
28	KV-B27-1800	CLAMP	4	
29	01010-81245	BOLT	8	
30	01643-31232	WASHER	8	
31	KV-B27-4190	CLAMP	6	
32	01010-81245	BOLT	12	
33	01643-31232	WASHER	12	

https://truckmanualshub.com/

T1210-04A0 : MID LINK AND ARM CYLINDER S/V PIPING



https://truckmanualshub.com/

T1210-04A0 : MID LINK AND ARM CYLINDER S/V PIPING

Item	Part No.	Description	Qty	Options
1	707-01-XZ980	MID LINK CYLINDER	1	
2	702-21-08710	PILOT VALVE	1	
3	07000-13035	O-RING	1	
4	01010-81065	BOLT	2	
5	01010-81055	BOLT	2	
6	01643-51032	WASHER	4	
7	207-70-K2911	TUBE	1	
8	07000-13035	O-RING	1	
9	07372-21035	BOLT	4	
10	01643-51032	WASHER	4	
11	207-63-KA410	TUBE	1	
12	07000-13035	O-RING	1	
13	01435-01055	BOLT	4	
14	207-63-KA430	BRACKET	1	
15	707-88-21380	BRACKET	1	
16	01435-01035	BOLT	2	
17	07283-23442	CLIP	2	
18	01599-01011	NUT	4	
19	01643-31032	WASHER	4	
20	07371-31049	FLANGE	4	
21	07372-21035	BOLT	8	
22	01643-51032	WASHER	8	
23	07040-11409	PLUG	1	
24	07002-11423	O-RING	1	
25	07235-10311	ELBOW	1	
26	07002-11423	O-RING	1	
27	07235-10422	ELBOW	1	
28	07002-12434	O-RING	1	
29	07108-20322	HOSE	1	
30	07108-20422	HOSE	1	
31	707-01-XY581	ARM CYLINDER	1	
32	702-21-08710	PILOT VALVE	1	
33	07000-13035	O-RING	1	
34	01010-81065	BOLT	2	
35	01010-81055	BOLT	2	
36	01643-51032	WASHER	4	
37	207-70-K2911	TUBE	1	
38	07000-13035	O-RING	1	
39	07372-21035	BOLT	4	
40	01643-51032	WASHER	4	
41	207-63-KA420	TUBE	1	
42	07371-30640	FLANGE	2	
43	07372-21035	BOLT	4	
44	01643-51032	WASHER	4	
45	07000-13030	O-RING	1	
46	01435-01055	BOLT	2	
47	01435-01040	BOLT	2	


https://truckmanualshub.com/

Item	Part No.	Description	Qty	Options
48	07371-31049	FLANGE	2	
49	07372-21035	BOLT	4	
50	01643-51032	WASHER	4	
51	207-63-KA440	BRACKET	1	
52	707-88-21320	BAND	1	
53	01435-01030	BOLT	2	
54	07283-22738	CLIP	1	
55	07283-23442	CLIP	1	
56	01599-01011	NUT	4	
57	01643-31032	WASHER	4	
58	07040-11409	PLUG	1	
59	07002-11423	O-RING	1	
60	07235-10311	ELBOW	1	
61	07002-11423	O-RING	1	
62	114-62-25210	ELBOW	1	
63	07002-12434	O-RING	1	
64	07108-20322	HOSE	2	
65	08034-20536	BAND	4	
66	KV-B240-8080	BLOCK	2	
67	198-33-12380	WASHER	2	
68	01010-81290	BOLT	2	
69	01643-31232	WASHER	2	
70	07230-20422	NIPPLE	2	
71	07230-20315	NIPPLE	2	
72	07002-12034	O-RING	4	

https://truckmanualshub.com/

https://truckmanualshub.com/

T1210-05A0 : ARM 3.2M (DIG BOOM)




https://truckmanualshub.com/

T1210-05A0 : ARM 3.2M (DIG BOOM)

Item	Part No.	Description	Qty	Options
1	207-62-KB750NK	TUBE	2	
2	20Y-970-K542	VALVE	2	
3	07371-31049	FLANGE	8	
4	07372-21035	BOLT	16	
5	01643-51032	WASHER	16	
6	07000-13032	O-RING	4	
7	207-62-KB760NK	TUBE	2	
8	KV-X5-X03010	ELBOW	2	
9	KV-X5-X0-2830	CAP	2	
10	KV-1B27-4180NK	CLAMP	3	
11	01010-81245	BOLT	6	
12	01643-31232	WASHER	6	
13	0709721023	HOSE	1	
14	07371-31049	FLANGE	8	
15	0737221035	BOLT	16	
16	01643-31232	WASHER	16	
17	07000-13032	O-RING	4	
18	207-62-KB780NK	TUBE	3	
19	207-62-KC661	VALVE	3	
20	07371-30-500	FLANGE	12	
21	01010-80830	BOLT	24	
22	01643-50823	WASHER	24	
23	07000-13022	O-RING	6	
24	207-62-KB770NK	TUBE	3	
25	KV-X5-X03000	ELBOW	3	
26	KV-X5-X02840	CAP	3	
27	KV-1B27-4190	CLAMP	1	
28	01010-81245	BOLT	4	
29	01643-31232	WASHER	4	
30	0709720521	HOSE	1	
31	0709720519	HOSE	2	
32	07371-30500	FLANGE	12	
33	01010-80830	BOLT	24	
34	01643-50823	WASHER	24	
35	07000-13022	O-RING	6	

https://truckmanualshub.com/

T1210-05A0 : ARM 2.5M (DIG BOOM)




https://truckmanualshub.com/

T1210-05A0 : ARM 2.5M (DIG BOOM)

Item	Part No.	Description	Qty	Options
1	207-62-KD670NK	TUBE	2	
2	20Y-970-K542	VALVE	2	
3	07371-31049	FLANGE	8	
4	07372-21035	BOLT	16	
5	01643-51032	WASHER	16	
6	07000-13032	O-RING	4	
7	207-62-KB760NK	TUBE	2	
8	KV-X5-X03010	ELBOW	2	
9	KV-X5-X0-2830	CAP	2	
10	KV-1B27-4180NK	CLAMP	3	
11	01010-81245	BOLT	6	
12	01643-31232	WASHER	6	
13	0709721023	HOSE	1	
14	07371-31049	FLANGE	8	
15	0737221035	BOLT	16	
16	01643-31232	WASHER	16	
17	07000-13032	O-RING	4	
18	207-62-KD660NK	TUBE	3	
19	207-62-KC661	VALVE	3	
20	07371-30-500	FLANGE	12	
21	01010-80830	BOLT	24	
22	01643-50823	WASHER	24	
23	07000-13022	O-RING	6	
24	207-62-KB770NK	TUBE	3	
25	KV-X5-X03000	ELBOW	3	
26	KV-X5-X02840	CAP	3	
27	KV-1B27-4190	CLAMP	3	
28	01010-81245	BOLT	6	
29	01643-31232	WASHER	6	
30	0709720521	HOSE	1	
31	0709720519	HOSE	2	
32	07371-30500	FLANGE	12	
33	01010-80830	BOLT	24	
34	01643-50823	WASHER	24	
35	07000-13022	O-RING	6	

https://truckmanualshub.com/

T1220-01A0 : ATTACHMENT CYLINDER DETAIL




https://truckmanualshub.com/

AT1220-01A0 : ATTACHMENT CYLINDER DETAIL

Item	Part No.	Description	Qty	Options
G-1	207-63-K1500	ATTACHMENT CYLINDER GROUP	1	
	207-63-K1510	ATTACHMENT CYLINDER ASSY	1	
1	207-63-K1520	• CYLINDER	1	
2	707-76-80010	• BUSHING	2	
3	07145-00080	• SEAL,DUST	2	
4	07020-00000	• FITTING,GREASE	1	
5	207-63-K1550	• ROD	1	
6	707-76-80010	• BUSHING	2	
7	07145-00080	• SEAL,DUST	2	
8	07020-00000	• FITTING	1	
9	207-63-K1580	• HEAD	1	
10	176-63-56170	• SEAL,DUST	1	
11	07179-13114	• RING,SNAP	1	
12	707-52-90750	• BUSHING	1	
13	707-51-10030	• PACKING,ROD	1	
14	707-51-10630	•RING,BUFFER	1	
15	07000-05135	•RING,BACK-UP	1	
16	07000-15135	• O-RING	1	
17	01011-81820	• BOLT	15	
18	707-41-11840	• WASHER	15	
19	707-36-14410	• PISTON	1	
20	01310-01216	• SCREW	1	
21	707-44-14180	• RING,PISTON	1	
22	707-39-14820	•RING,WEAR	2	
23	707-44-14910	• RING	2	
24	07001-05090	• RING,BACK-UP	2	
25	07000-15090	• O-RING	1	
26	207-63-K1590	TUBE	1	
28	01010-81060	BOLT	4	
28	01643-51035	WASHER	4	
29	07000-13035	O-RING	1	
30	707-88-87180	BRACKET	2	
31	707-88-87170	BAND	2	
32	01010-81240	BOLT	8	
32	01643-51032	WASHER	8	
33	707-88-10150	CLAMP	2	
34	01010-81245	BOLT	4	
34	01643-51032	WASHER	4	

https://truckmanualshub.com/

T1230-01A0 : LINK PINS AND BUSHINGS




https://truckmanualshub.com/

T1230-01A0 : LINK PINS AND BUSHINGS

Item	Part No.	Description	Qty	Options
1	20Y-973-1310	LINK	1	
2	206-70-53150	BUSHING	2	
3	205-70-67150	BUSHING	2	
4	07020-00000	FITTING	3	
5	20Y-70-23230	SEAL	6	
6	205-70-51530	SPACER	6	
7	20Y-70-11340	SPACER	4	
8	KV-B230-1240	LINK	1	
9	206-70-53141	PIN	2	
10	205-70-73190	BOLT	3	
11	01580-12016	NUT	8	
12	205-70-73280	O-RING	2	
13	207-70-81270	PIN	2	
14	362-46-11210	BOLT	1	
15	KV-B230-1250	LINK	1	

https://truckmanualshub.com/

X1000-01A0 : TRANSPORT PIN




https://truckmanualshub.com/

X1000-01A0 : TRANSPORT PIN

Item	Part No.	Description	Qty	Options
1	KV-B230-1260	ROD	1	
2	20Y-949-K250	PIN	2	
3	20Y-949-K250	PIN	2	

https://truckmanualshub.com/

X1000-02A0 : HIGH REACH WORK EQUIPMENT STANDS




https://truckmanualshub.com/

X1000-02A0 : HIGH REACH WORK EQUIPMENT STANDS

Item	Part No.	Description	Qty	Options
1	207-818-KA80	STAND	4	
2	207-818-KA90	ROD	4	
3	207-818-KA50	PIN	4	
4	207-818-KA60	PIN	8	
5	421-46-12740	LYNCH PIN	12	

https://truckmanualshub.com/

X1000-03A0 : DIG BOOM STAND



https://truckmanualshub.com/

X1000-03A0 : DIG BOOM STAND

Item	Part No.	Description	Qty	Options
1	207-818-KA20	STAND	2	
2	207-818-KA40	ROD	2	
3	207-818-KA50	PIN	2	
4	207-818-KA60	PIN	4	
5	421-46-12740	LYNCH PIN	6	

https://truckmanualshub.com/

https://truckmanualshub.com/

https://truckmanualshub.com/

UEPB005300

KOMATSU

©2004 Komatsu Europe International
All Rights Reserved
Printed in Europe 05-2004